
ITD Gun Manual


This manual is applicable to the following models:

- ITD-3500
- ITD-3500-A
- ITD-3500-INT
- ITD-3500-MCC
- ITD-3500-MCC-INT
- ITD-6500
- ITD-6500-MCC
- ITD-4000
- ITD-4000-A
- ITD-4000-INT
- ITD-4000-MCC
- ITD-400-MCC-INT
- ITD-6000





Rev. March 2019



CORPORATE HEADQUARTERS 2030 Falling Waters Rd, Suite 350, Knoxville, TN 37922 · USA · Tel: (865) 686-5670

DISTRIBUTION AND PURCHASING 642 Barbrow Ln, Knoxville, TN 37932 · USA · Tel: (865) 684-4416

TECHNOLOGY CENTER AND MANUFACTURING
1862 Ives Ave, Kent, WA 98032 · USA · Tel (253) 854-2660 · Fax (253) 854-1666

E-mail: info@mvpind.com

For a list of international distributors, visit our website at:

www.mvpind.com/mvp-international

Use of this product confirms that Magnum Venus Products, Inc.'s standard terms and conditions of sale apply.



▲ Table of Contents

Se	ection	Page
•	Table of Contents	3
•	Safety & Warning Information	4
•	Introduction	15
•	Disassembling Gun	17
•	Repairing Components	17
•	Repairing Gun Head	18
•	Troubleshooting	20
•	Parts Drawings	21



Safety & Warning Information

Warnings 4

Due to the vast number of chemicals that could be used and their varying chemical reactions, the buyer and user of this equipment should determine all factors relating to the fluids used, including any of the potential hazards involved. Particular inquiry and investigation should be made into potential dangers relating to toxic fumes, fires, explosions, reaction times, and exposure of human beings to the individual components or their resultant mixtures. MVP assumes no responsibility for loss, damage, expense or claims for bodily injury or property damage, direct or consequential, arising from the use of such chemical components.

The end user is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used and that all documentation is adhered to.

Recommended Occupational Safety & Health Act (OSHA) Documentation:

1910.94 Pertaining to ventilation Pertaining to flammable liquids 1910.106 Pertaining to spray finishing operations, particularly paragraph (m), 1910.107 Organic Peroxides and Dual Component Coatings

For Additional information, contact the Occupational Safety and Health Administration (OSHA) at https://www.osha.gov/about.html.

Recommended National Fire Protection Association (NFPA) Documentation:

Organic Peroxides and Dual Component Materials NFPA No.33 Chapter 14 NFPA No. 63 **Dust Explosion Prevention** National Electrical Code NFPA No. 70 Static Electricity NFPA No. 77 Blower and Exhaust System NFPA No. 91

Fire Extinguisher – code ABC, rating number 4a60bc using Extinguishing Media –Foam, Carbon Dioxide, Dry Chemical, Water Fog, is recommended for this product and applications.

Plastics Industry Dust Hazards

The following general warnings and guidelines are for the setup, use, grounding, maintenance, and repair of equipment. Additional product-specific warnings may be found throughout this manual as applicable. Please contact your nearest MVP Technical Service Representative if additional information is needed.



NFPA No. 654

Safety Precautions

- Avoid skin contact and inhalation of all chemicals.
- Review Material Safety Data Sheet (MSDS) to promote the safe handling of chemicals in
- Restrict the use of all chemicals to designated areas with good ventilation.
- Chemicals are flammable and reactive.
- Noxious fumes released when combusted.
- Operate equipment in a ventilated environment only.
- Uncured liquid resins are highly flammable unless specifically labeled otherwise.
- Cured laminate, accumulations of overspray, and laminate sandings are highly combustible.
- Do not operate or move electrical equipment when flammable fumes are present.
- Ground all equipment.
- If a spark is seen or felt, immediately halt operation. Do not operate the equipment until the issue has been identified and repaired.
- Contaminated catalyst may cause fire or explosion.
- Containers may explode if exposed to fire / heat.
- Use and store chemicals away from heat, flames, and sparks.
- Do not smoke in work areas or near stored chemicals.
- Do not mix Methyl Ethyl Ketone Peroxide (MEKP) with materials other than polyethylene.
- Do not dilute MEKP.
- Keep food and drink away from work area.



CORROSIVE



FLAMMABLE



GROUNDING



EXPLOSIVE



DANGER



DANGER



Physical Hazards

- Never look directly into the spray gun fluid tip. Serious injury or death can result.
- Never aim the spray gun at or near another person. Serious injury or death can result.
- Chemical compounds can be severely irritating to the eyes and skin.
- Inhalation, ingestion, or injection may damage internal organs and lead to pulmonary disorders, cancers, lymphomas, and other diseases or health conditions.
- Other potential health effects include: irritation of the eyes and upper respiratory tract, headache, light-headedness, dizziness, confusion, drowsiness, nausea, vomiting, and occasionally abdominal pain.
- Eye contact: Immediately flush with water for at least 15 minutes and seek immediate medical attention.
- Skin Contact: Immediately wash with soap and water and seek immediate medical attention.
- Inhalation: Move the person to fresh air and seek immediate medical attention.
- Do not remove shields, covers, or safety features on equipment that is in use.
- Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can shoot liquid through the skin.
- Keep hands and body parts away from any moving equipment or components.
- Do not stand under plunger
- An improperly loaded drum may lead to an imbalance, causing a unit to tip over





Personal Protective Equipment (PPE)

- MVP recommends the use of personal safety equipment with all products in our catalog.
- Wear safety goggles, hearing protection, a respirator, and chemical resistant gloves.
- Wear long sleeve shirts or jackets and pants to minimize skin exposure.
- PPE should be worn by operators and service technicians to reduce the risk of injury.



For Additional information, contact the Occupational Safety and Health Administration (OSHA). https://www.osha.gov/about.html



Symbol Definitions



Indicates the risk of contact with chemicals that are hazardous, which may lead to injury or death.



Indicates the risk of contact with voltage / amperage that may lead to serious injury or death



Indicates that the materials being used are susceptible to combustion



Indicates the risk of contact with moving components that may lead to serious injury or death.



Indicates that the system or component should be grounded before proceeding with use or repair.



Indicates the use of lit cigarettes or cigars is prohibited, because the materials being used are susceptible to combustion.



Indicates that the materials and/or the process being performed can lead to ignition and explosion.



A recommendation for the use of Personal Protective Equipment (PPE) before using or repairing the product.



Polymer Matrix Materials: Advanced Composites

Potential health hazards associated with the use of advanced composites can be controlled through the implementation of an effective industrial hygiene and safety program.

https://www.osha.gov/dts/osta/otm/otm_iii/otm_iii_1.html#t iii:1_1

Resins				
Composite Component	Organ System Target	Known (Possible) Health Effect		
	(Possible Target)			
Epoxy resins	Skin, lungs, eyes	Contact and allergic dermatitis,		
<u> Ероху гезінз</u>	Okin, langs, cycs	conjunctivitis		
Polyurethane resins	Lungs, skin, eyes	Respiratory sensitization, contact		
_		dermatitis, conjunctivitis		
Phenol formaldehyde	Skin, lungs, eyes	As above (potential carcinogen)		
Bismaleimides (BMI)	Skin, lungs, eyes	As above (potential carcinogen)		
Polyamides	Skin, lungs, eyes	As above (potential carcinogen)		
Reinforcing materials				
Composite Component	Organ System Target	Known (Possible) Health Effect		
	(Possible Target)			
Aramid fibers	Skin (lungs)	Skin and respiratory irritation, contact		
	_	dermatitis (chronic interstitial lung disease)		
Carbon/graphite fibers	Skin (lungs)	As noted for aramid fibers		
Glass fibers (continuous	Skin (lungs)	As noted for aramid fibers		
filament)	Gimi (iaiigo)			
Hardeners and curing agents				
Composite Component	Organ System Target	Known (Possible) Health Effect		
	(Possible Target)			
Diaminodiphenylsulfone	N/A	No known effects with workplace		
· -	-	exposure		
Methylenedianiline	Liver, skin	Hepatotoxicity, suspect human carcinogen		
Other aromatic amines				
Composite Component	Organ System Target	Known (Possible) Health Effect		
	(Possible Target)			
Meta-phenylenediamine (MPDA)	Liver, skin (kidney,	Hepatitis, contact dermatitis (kidney and		
-	bladder)	bladder cancer)		
Aliphatic andcyclo-aliphatic	Eyes, skin	Severe irritation, contact dermatitis		
amines				
Polyaminoamide	Eyes, skin	Irritation (sensitization)		
Anhydride	Eyes, lungs, skin	Severe eye and skin irritation, respiratory		
9 222	,, ,	sensitization, contact dermatitis		



Catalyst - Methyl Ethyl Ketone Peroxide (MEKP)

MEKP is among the more hazardous materials found in commercial channels. The safe handling of the "unstable (reactive)" chemicals presents a definite challenge to the plastics industry. The highly reactive property which makes MEKP valuable to the plastics industry in producing the curing reaction of polyester resins also produces the hazards which require great care and caution in its storage, transportation, handling, processing and disposal. MEKP is a single chemical. Various polymeric forms may exist which are more or less hazardous with respect to each other. These differences may arise not only from different molecular structures (all are, nevertheless, called "MEKP") and from possible trace impurities left from the manufacture of the chemicals, but may also arise by contamination of MEKP with other materials in its storage or use. Even a small amount of contamination with acetone, for instance, may produce an extremely shock-sensitive and explosive compound.



WARNING

Contamination with promoters, materials containing promoters (such as laminate sandings), or with any readily oxidizing material (such as brass or iron) will cause exothermic redox reactions which can be explosive in nature. Heat applied to MEKP or heat buildup from contamination reactions can cause the material to reach its Self-Accelerating Decomposition Temperature (SADT).

Researchers have reported measuring pressure rates-of-rise well over 100,000 psi per second when certain MEKP's reach their SADT. For comparison, the highest-pressure rate-of-rise listed in NFPA Bulletin NO.68, "Explosion Venting", is 12,000 psi per second for an explosion of 12% acetylene and air. The maximum value listed for a hydrogen explosion is 10,000 psi per second. Some forms of MEKP, if allowed to reach their SADT, will burst even an open topped container. This suggests that it is not possible to design a relief valve to vent this order of magnitude of pressure rate-of-rise. The user should be aware that any closed container, be it a pressure vessel, surge chamber, or pressure accumulator, could explode under certain conditions. There is no engineering substitute for care by the user in handling organic peroxide catalysts. If, at any time, the pressure relieve valve on top of the catalyst tank should vent, the area should be evacuated at once and the fire department called. The venting could be the first indication of a heat, and therefore, pressure build-up that could eventually lead to an explosion. Moreover, if a catalyst tank is sufficiently full when the pressure relief valve vents, some catalyst may spray out, which could cause eye injury. For this reason, and many others, anyone whose job puts them in an area where this vented spray might go, should always wear full eye protection even when laminating operations are not taking place.

Safety in handling MEKP depends to a great extent on employee education, proper safety instructions, and safe use of the chemicals and equipment. Workers should be thoroughly informed of the hazards that may result from improper handling of MEKP, especially regarding contamination, heat, friction and impact. They should be thoroughly instructed regarding the proper action to be taken in the storage, use, and disposal of MEKP and other hazardous materials used in the laminating operation. In addition, users should make every effort to:

- Store MEKP in a cool, dry place in original containers away from direct sunlight and away from other chemicals.
- Keep MEKP away from heat, sparks, and open flames.
- Prevent contamination or MEKP with other materials, including polyester over spray and sandings, polymerization accelerators and promoters, brass, aluminum, and non-stainless steels.



- Never add MEKP to anything that is hot, since explosive decomposition may result.
- Avoid contact with skin, eyes, and clothing. Protective equipment should be worn at all times. During clean-up of spilled MEKP, personal safety equipment, gloves, and eye protection must be worn. Firefighting equipment should be at hand and ready.
- Avoid spillage, which can heat up to the point of self-ignition.
- Repair any leaks discovered in the catalyst system immediately, and clean-up the leaked catalyst at once in accordance with the catalyst manufacturer's instructions.
- Use only original equipment or equivalent parts from Magnum Venus Products in the catalyst system (i.e.: hoses, fitting, etc.) because a dangerous chemical reaction may result between substituted parts and MEKP.
- Catalyst accumulated from the purging of hoses or the measurement of fluid output deliveries should never be returned to the supply tank, such catalyst should be diluted with copious quantities of clean water and disposed of in accordance with the catalyst manufacturer's instructions.

The extent to which the user is successful in accomplishing these ends and any additional recommendations by the catalyst manufacturer determines largely the safety that will be present in his operation.

Clean-Up Solvents and Resin Diluents



WARNING

A hazardous situation may be present in your pressurized fluid system! Hydro carbon solvents can cause an explosion when used with aluminum or galvanized components in a closed (pressurized) fluid system (pump, heaters, filters, valves, spray guns, tanks, etc.). An explosion could cause serious injury, death, and/or substantial property damage. Cleaning agents, coatings, paints, etc. may contain Halogenated Hyrdrocarbon solvents. Some Magnum Venus Products spray equipment includes aluminum or galvanized components and will be affected by Halogenated Hydrocarbon solvents.

There are three key elements to the Halogenated Hyrdocarbon (HHC) solvent hazard.

- 1. The presence of HHC solvents.
- Aluminum or Galvanized Parts.
- 3. Equipment capable of withstanding pressure.
- 1,1,1 Trichloroethane and Methylene Chloride are the most common of these solvents. However, other HHC solvents are suspect if used; either as part of paint or adhesives formulation, or for clean-up flushing. Most handling equipment contains these elements. In contact with these metals, HHC solvents could generate a corrosive reaction of a catalytic nature.
- When HHC solvent contact aluminum or galvanized parts inside a closed container such as a pump, spray gun, or fluid handling system, the chemical reaction can, over time, result in a build-up of heat and pressure, which can reach explosive proportions. When all three elements are present, the result can be an extremely violent explosion. The reaction can be sustained with very little aluminum or galvanized metal; any amount of aluminum is too much.



- The reaction is unpredictable. Prior use of an HHC solvent without incident (corrosion or explosion) does NOT mean that such use is safe. These solvents can be dangerous alone (as a clean-up or flushing agent) or when used as a component or a coating material. There is no known inhibitor that is effective under all circumstances. Mixing HHC solvents with other materials or solvents such as MEKP, alcohol, or toluene may render the inhibitors ineffective.
- The use of reclaimed solvents is particularly hazardous. Reclaimers may not add any inhibitors. The possible presence of water in reclaimed solvents could also feed the reaction.
- Anodized or other oxide coatings cannot be relied upon to prevent the explosive reaction. Such
 coatings can be worn, cracked, scratched, or too thin to prevent contact. There is no known way
 to make oxide coatings or to employ aluminum alloys to safely prevent the chemical reaction
 under all circumstances.
- Several solvent suppliers have recently begun promoting HHC solvents for use in coating systems. The increasing use of HHC solvents is increasing the risk. Because of their exemption from many state implementation plans as Volatile Organic Compounds (VOCs), their low flammability hazard, and their not being classified as toxic or carcinogenic substances, HHC solvents are very desirable in many respects.



WARNING

Do not use Halogenated Hydrocarbon (HHC) solvents in pressurized fluid systems having aluminum or galvanized wetted parts.

Magnum Venus Products is aware of NO stabilizers available to prevent HHC solvents from reaction under all conditions with aluminum components in closed fluid systems. HHC solvents are dangerous when used with aluminum components in a closed fluid system.

- Consult your material supplier to determine whether your solvent or coating contains Halogenated Hydrocarbon solvents.
- Magnum Venus Products recommends that you contact your solvent supplier regarding the best non-flammable clean-up solvent with the heat toxicity for your application.
- If, however, you find it necessary to use flammable solvents, they must be kept in approved, electrically grounded containers.
- Bulk solvent should be stored in a well-ventilated, separate building, 50 feet away from your main plant.
- You should only allow enough solvent for one day's use in your laminating area.
- NO SMOKING signs must be posted and observed in all areas of storage or where solvents and other flammable materials are used.
- Adequate ventilation (as covered in OSHA Section 1910.94 and NFPA No.91) is important wherever solvents are stored or used, to minimize, confine and exhaust the solvent vapors.
- Solvents should be handled in accordance with OSHA Section 1910.106 and 1910.107.



Catalyst Diluents

Magnum Venus Products spray-up and gel-coat systems currently produced are designed so that catalyst diluents are not required. Magnum Venus Products therefore recommends that diluents not be used to avoid possible contamination which could lead to an explosion due to the handling and mixing of MEKP and diluents. In addition, it eliminates any problems from the diluent being contaminated through rust particles in drums, poor quality control on the part of the diluents suppliers, or any other reason. If diluents are absolutely required, contact your catalyst supplier and follow his instructions explicitly. Preferably the supplier should premix the catalyst to prevent possible "on the job" contamination while mixing.



WARNING

If diluents are not used, remember that catalyst spillage and gun, hose, and packing leaks are potentially more hazardous since each drop contains a higher concentration of catalyst and will therefore react more quickly with overspray and the leak.

Cured Laminate, Overspray and Laminate Sandings Accumulation

- Remove all accumulations of overspray, Fiberglass Reinforced Plastic (FRP) sandings, etc. from the building as they occur. If this waste is allowed to build up, spillage of catalyst is more likely to start a fire; in addition, the fire would burn hotter and longer.
- Floor coverings, if used, should be non-combustible.
- Spilled or leaked catalyst may cause a fire if it comes in contact with an FRP product, oversprayed chop or resin, FRP sandings or any other material with MEKP.

To prevent spillage and leakage, you should:

the hoses at any point.

1.	Maintain your Magnum Venus	Check the gun several times daily for catalyst and
	Products System.	resin packing or valve leaks. REPAIR ALL LEAKS
		IMMEDIATELY.
2.	Never leave the gun hanging over	A catalyst leak in this situation would certainly
	or lying inside the mold.	damage the part, possibly the mold, and may cause
		a fire.
3.	Inspect resin and catalyst hoses	Replace if wear or weakness is evident or
	daily for wear or stress at the entry	suspected.
	and exits of the boom sections and	
	at the hose and fittings.	
4.	Arrange the hoses and fiberglass	If allowed to rub, the hose will be cut through,
	roving guides so that the fiberglass	causing a hazardous leakage of material which
	strands DO NOT rub against any of	could increase the danger of fire. Also, the material

may spew onto personnel in the area.



Toxicity of Chemicals

- Magnum Venus Products recommends that you consult OSHA Sections 1910.94, 1910.106, 1910.107 and NFPA No.33, Chapter 14, and NFPA No.91.
- Contact your chemical supplier(s) and determine the toxicity of the various chemicals used as well as the best methods to prevent injury, irritation and danger to personnel.
- Also determine the best methods of first aid treatment for each chemical used in your plant.

Equipment Safety

Magnum Venus Products suggest that personal safety equipment such as EYE GOGGLES, GLOVES, EAR PROTECTION, and RESPIRATORS be worn when servicing or operating this equipment. Ear protection should be worn when operating a fiberglass chopper to protect against hearing loss since noise levels can be as high as 116 dB (decibels). This equipment should only be operated or serviced by technically trained personnel!



CAUTION

Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can cause serious injury by shooting liquid through the skin. NEVER LOOK DIRECTLY INTO THE GUN SPRAY TIP OR POINT THE GUN AT OR NEAR ANOTHER PERSON OR AN ANIMAL.



DANGER

Contaminated catalyst may cause fire or explosion. Before working on the catalyst pump or catalyst accumulator, wash hands and tools thoroughly. Be sure work area is free from dirt, grease, or resin. Clean catalyst system components with clean water daily.



DANGER

Eye, skin, and respiration hazard. The catalyst MEKP may cause blindness, skin irritation, or breathing difficulty. Keep hands away from face. Keep food and drink away from work area.

Treatment of Chemical Injuries



CAUTION

Refer to your catalyst manufacturer's safety information regarding the safe handling and storage of catalyst. Wear appropriate safety equipment as recommended.

Great care should be used in handling the chemicals (resins, catalyst and solvents) used in polyester systems. Such chemicals should be treated as if they hurt your skin and eyes and as if they are poison to your body. For this reason, Magnum Venus Products recommends the use of protective clothing and eye wear in using polyester systems. However, users should be prepared in the event of such an injury.



Precautions include:

- 1. Know precisely what chemicals you are using and obtain information from your chemical supplier on what to do in the event the chemical gets onto your skin or into the eyes, or if swallowed.
- 2. Keep this information together and easily available so that it may be used by those administering first aid or treating the injured person.
- 3. Be sure the information from your chemical supplier includes instructions on how to treat any toxic effects the chemicals have.



WARNING

Contact your doctor immediately in the event of an injury. If the product's MSDS includes first aid instructions, administer first aid immediately after contacting a doctor.

Fast treatment of the outer skin and eyes that contact chemicals generally includes immediate and thorough washing of the exposed skin and immediate and continuous flushing of the eyes with lots of clean water for at least 15 minutes or more. These general instructions of first aid treatment may be incorrect for some chemicals; you must know the chemicals and treatment before an accident occurs. Treatment for swallowing a chemical frequently depends upon the nature of the chemical.

Emergency Stop Procedure

In an emergency, follow these steps to stop a system:

1. The ball valve located where the air enters the power head of the resin pump, should be moved to the "OFF" or closed position.

Note The "open" or "on" position is when the ball valve handle is parallel (in line) with the ball valve body. The "closed" or "off" position is when the ball valve handle is perpendicular (across) the ball valve body.

- 2. Turn all system regulators to the "OFF" position (counter-clockwise) position.
- 3. Verify / secure the catalyst relief line, located on the catalyst relief valve.
- 4. Verify / secure the resin return line, located on the resin filter.
- 5. Place a container under the resin pump ball valve to catch ejected resin.
- 6. Locate the ball valve on the resin pump.
- 7. Rotate the ball valve 90 degrees to the "On" or open position.

Grounding

Grounding an object means providing an adequate path for the flow of the electrical charge from the object to the ground. An adequate path is one that permits charge to flow from the object fast enough that it will not accumulate to the extent that a spark can be formed. It is not possible to define exactly what will be an adequate path under all conditions since it depends on many variables. In any event, the grounding means should have the lowest possible electrical resistance.



Grounding straps should be installed on all loose conductive objects in the spraying area. This includes material containers and equipment. Magnum Venus Products recommends grounding straps be made of AWG No.18 stranded wire as a minimum and the larger wire be used where possible. NFPA Bulletin No77 states that the electrical resistance of such a leakage path may be as low as 1 meg ohm (10 ohms) but that resistance as high as 10,000 meg ohms will produce an adequate leakage path in some cases.

CAUTION



Whenever flammable or combustible liquids are transferred from one container to another, or from one container to the equipment, both containers or container and equipment shall be effectively bonded and grounded to dissipate static electricity. For further information, see National Fire Protection Association (NFPA) 77, titled "Recommended Practice on Static Electrical". Refer especially to section 7-7 titled "Spray Application of Flammable and Combustible Materials".

Introduction

MVP's ITD guns are in the AT, or air trigger, series of guns. The AT series guns feature low maintenance, few adjustments, superb quality, and long service life. As the gun trigger is pulled, air is shifted from one side of a piston to the other. The pistons are attached to gun needles that open and close the gun.

This manual provides information for the operation, maintenance, and simple repair of the MVP ITD Gun. The following procedures are included:

- Step-by-step assembly and disassembly
- Troubleshooting information



Please read this manual carefully and retain for future reference. Follow the steps in the order given, otherwise you may damage the equipment or injure yourself.

As you disassemble the equipment, lay out the components on a clean surface in the correct order and direction to aid in reassembly.

This manual covers all of the variations of the ITD gun:

• ITD-3500-XXX External Mix Gelcoat Gun


• ITD-6500-XXX External Mix Gelcoat Gun – with Signal

• ITD-4000-XXX External Mix Chopper Gun

• ITD-6000-XXX External Mix Chopper Gun – with Signal



Gun Overview







Disassembling Gun

- 1. Remove the two Allen screws from the side of the gun to separate the handle from the head/cylinder.
- 2. Remove the two screws on the back of the cylinder.
- 3. Using caution, remove the cylinder from the back of the gun head.

Disassemble the Handle

- 4. Loosen the set screw on the trigger button assembly and remove the button.
- 5. Unscrew and remove the trigger lock.
- 6. Remove the trigger housing.
- 7. Remove the trigger valve assembly from the front of the gun.
- 8. Unscrew the refinement air adjustment screw and remove from the side of the gun.
- 9. Remove the refinement air spring and adjustment screw from the side of the gun.
- 10. Unscrew the refinement air packing nut from the side of the gun and remove the O-rings.
- 11. Remove the three O-rings on the top of the handle.



Repairing Components

Assemble the Handle

- 1. Thoroughly clean and inspect all parts for wear or damage.
- 2. Open the seal kit and match the O-rings with the ones being replaced.
- 3. Replace the O-rings on the trigger valve.

Note A special tool is available to install the O-rings on the trigger valve, part number ATC-40103-1.

- 4. Install the spring onto the trigger valve and install into the front of the gun.
- 5. Thread the trigger housing into the front of the gun over the trigger valve using a $\frac{7}{16}$ " wrench.
- 6. Thread the trigger lock into the trigger housing.
- 7. Place the trigger button onto the end of the trigger valve, depressing it all the way.
- 8. While holding the trigger down, tighten the set screw on the side of the trigger button to hold it in place.
- 9. Replace the O-rings in the air refinement needle valve on the side of the handle, placing the Buna (black) O-ring first and then the Teflon (white).
- 10. Install the packing nut just until it stops.
- 11. Place the spring onto the refinement air needle.



- 12. Lubricate the refinement air needle with Super O Lube and install into the side of the gun.
- 13. Replace the O-rings on top of the handle.
- 14. Set the handle aside.

Repair the Cylinder

- 15. Remove and check the spring from the inside of the cylinder.
- 16. Check the inside of the cylinder.
- 17. Check and clear air ports on the bottom of the cylinder.
- 18. If you have a gelcoat gun, lubricate the inside of the cylinder and then skip to step 26.
- 19. Remove the chopper air fitting from the back of the cylinder.
- 20. Push out the chopper air poppet valve and spring from the inside of the cylinder.
- 21. Replace the O-rings on the chopper poppet valve.
- 22. Lubricate the inside of the cylinder and the chopper poppet valve.
- 23. Push the chopper poppet valve and spring into the back of the cylinder.
- 24. Replace the O-ring on the chopper air fitting.
- 25. Push the end of the poppet valve from the inside of the cylinder to check that it is moving freely.
- 26. Reinstall the spring into the cylinder.



Repairing Gun Head

- 1. Remove the catalyst spool valve assembly.
- 2. Unscrew the valve back from the catalyst piston, using caution not to lose the lock nut.
- 3. Replace the O-rings on the valve back and catalyst piston.

Note A special tool is available to install the O-rings on the catalyst spool valve; part number ATC-40204-1.

- 4. Install the lock washer on the valve back.
- 5. Thread the valve back into the catalyst piston.

Note Use a drop of removable thread lock compound on threads of the valve front and back during reassembly.

6. Unscrew the valve front from the valve back.

Note The threads on the valve front are reverse threaded and will unscrew clockwise from the valve back.


- 7. Install new O-rings on the valve front and an O-ring between the valve front and valve back.
- 8. Thread the valve front into the valve back and set the catalyst spool aside.



- 9. Install a new O-ring onto the catalyst cylinder on the gun head.
- 10. Remove the two set screws on the side of the gun head assembly holding the catalyst cylinder in place.
- 11. Remove catalyst cylinder from the gun head.
- 12. Make note of the O-ring positions on the catalyst cylinder.

Note Installing the new O-rings in the wrong positions will cause the gun to work improperly.

- 13. Replace the old O-ring with the new O-rings from the seal kit.
- 14. Lubricate the O-rings with SSL-10 or petroleum jelly.
- 15. Reinstall the catalyst cylinder into the gun head by rotating it back and forth while pushing it into the gun, using caution not to damage the O-rings.
- 16. Align the hole in the catalyst cylinder with the hole in the side of the gun head.



- 17. Replace the set screws in the gun head.
- 18. Using a ½" nut driver, remove the diffuser seat from the front of the gun.
- 19. Pull the resin needle piston assembly from the back of the gun head.
- 20. Replace the O-ring on the resin needle piston.
- 21. Remove the packing retainer from the back of the gun head and replace the O-ring with a new one.
- 22. Replace the packing retainer into the back of the gun head.
- 23. Replace the O-ring for the resin cylinder seal.
- 24. Replace the two tip pin O-rings on the front of the gun.
- 25. Remove the catalyst cylinder plug on the front of the gun head and replace the O-ring.
- 26. Reinstall the catalyst cylinder plug into the front of the gun head.
- 27. Replace the O-rings on the diffuser seat.
- 28. Replace the packing, positioning it so that the resin needle can pass through it.
- 29. Press the diffuser seat as far as it will go into the front of the gun head.
- 30. Using a $\frac{1}{2}$ " nut driver, screw the diffuser seat in a few threads.



- 31. Install the resin needle assembly into the back of the gun head.
- 32. Using the ½" nut driver, adjust the diffuser seat to snug and then just a bit more.
- 33. Insert the catalyst spool valve assembly into the back of the gun head.
- 34. Using the two screws, attach the cylinder assembly to the gun head.
- 35. Attach the gun head and cylinder to the handle.

Troubleshooting

AT Gun Troubleshooti	ng			
Symptom	Possible Cause	Remedy		
Air leaking from exhaust port on back of handle while trigger is OFF	O-ring material worn or cut O-rings on catalyst piston worn or cut O-rings on trigger valve worn or cut	Replace O-rings		
Air leaking from exhaust port on back of handle while trigger is either ON or OFF	O-rings on trigger valve worn or cut O-rings on catalyst valve and/or material piston worn or cut	- Replace O-rings		
Catalyst leaking from catalyst tip while gun is not being triggered	O-rings on catalyst valve worn or cut	Replace O-rings		
Catalyst leaks from weep hole on catalyst side of gun	O-rings on catalyst valve worn or cut	Replace O-rings		
	Catalyst air piston not actuating	Check for clogged catalyst air passages (small holes under back cylinder) Note There is more than one passageway		
No catalyst coming from gun	Plugged catalyst restrictor (Allen screw with orifice located in front of catalyst valve)	Clean and clear orifice in front of catalyst valve		
	Plugged catalyst passageway in head of gun or catalyst tips	Inspect, clean, and clear passageways		
	No catalyst flow to gun	Service the slave pump. Refer to your system manual		
Material leaking from tip (front of gun)	Loose diffuser seat	Tighten diffuser seat ¼ to ½ turn at a time until snug and then one more ¼ turn. Note Overtightening may cause material needle binding		
	Worn needle packing	Replace packing and adjust as indicated above		




Parts Drawings

The following drawings are included in this manual for reference:

Parts Drawings	
Part Number	Description
ITD-3500	External Mix Gelcoat Gun
ITD-3500-A	External Mix Gelcoat Gun - Automatic
ITD-3500-INT	Gelcoat Gun - International
ITD-3500-MCC	External MCC Gun
ITD-3500-MCC-INT	External MCC Gun - International
ITD-6500	Gelcoat Gun – with Signal
ITD-6500-MCC	MCC Gun – with Signal
ITD-4000	External Mix Chopper Gun
ITD-4000-A	Chopper Gun - Automatic
ITD-4000-INT	Chopper Gun - International
ITD-4000-MCC	MCC Chopper Gun
ITD-4000-MCC-INT	MCC Chopper – International
ITD-6000	Chopper Gun – with Signal
ITD-EXT-SK	Seal Kit







ITD-	3:	500	
GEL	GI	UN	
10-0)5-	-12	
PART	S	KE	Y

ITEM	PART #	DESCRIPTION	QTY	ITRN	PART #	DESCRIPTION	QTY
1 2	ITD-4010-PL ITD-XXX	RETAINING RING SPRAY TIP ASSY.	1	51 52	PF-HN-02-04S F-FHCS-1032-08	FITTING MACHINE SCREW	1 2
3	ITD-35402	CAT TIP ASSY.	1	53	ATC-4003-2	HANDLE	1
4	ITD-3507	TIP HOLDER	1	54	ATC-40709	HANDLE GUARD	1
5*	ITD-4019	TIP SEAL	1		ATE-40505	MANA SULTANTAL SIV	
6*	CSP1-7	D-RING	1		ATE-40506	SPRING	1
7	ITD-4016	DIFFUSER SEAT	1		ATE-40509	TREZNI	1
8* 9*	ITD-4013 D-E-012	PACKING D-RING	1		ATC-40304-1 D-B-007	D-RING D-RING	1
10*	D-Z-008	O-RING	5		F-SS-1032-02-SS		1
11	ITD-4001	HEAD ASSY.	1		ATE-40616	SET SCREW	1
12*	D-Z-006	D-RING	2			oe i oenen	
13*	D-S-020	D-RING	2				
14	ATE-40701	ZEREW	2	SEAL	KIT SOLD SEPARATE	RLY:	
15*	D-Z-013	O-RING	3				
16	ITD-4026	MATERIAL TUBE	1	* IT	D-EXT-SK SEAL	KIT	
17	ATE-40213	FITTING	1				
18*	D-S-012A	D-RING	4	HOSES	AVAILABLE SEPARA	ATELY:	
19 20	ATE-40214	FITTING	1				
21	ATC-40611 ATC-40206	RESTRICTOR CATALYST CYLINDER	1	11:1	RATIO PUMP:		
22	ATE-40704	VALVE FRONT	1		FLUID HOSE - HAV		
23	ATE-40208	SPLIT WASHER	1		HAW-D344-5 (WHIF	, R/D)	
24*	D-T-008	D-RING	1	20 - 1	RATIO PUMP:		
25	ATE-40705	VALVE BACK	1	20.1	FLUID HOSE - HAV	V-0444-XX WITH	
26	ATC-40209	CATALYST PISTON	1		HAW D344-5 (WHIF		
27*	D-E-007	D-RING	1			7.74	2
28	ITD-4012	PACKING RETAINER	1	28:1	RATIO PUMP (MIN)	I MAG>	
29	ITD-4020	NEEDLE ASSY.	1		HTTID HOZE - HY	N-0444-10 WITH	
31	ATC-40325	SPRING	1		HAW-D344-5 (WHIF	B/D)	
32 33	ATG-3502	GUN BACK CAT. CYLINDER PLUG	1	3222203			
38	ATE-40201 ATE-40501	SEREW	5	ALL	RATIO PUMPS:		
41	ATE-40108	SET SCREW	1		REFINEMENT/TRIGO HA-D344-XX	PEK VIK HNZE -	
42	ATE-40113	TRIGGER	1		CATALYST HOSE -	UC_0224_VV	
43	ATE-40111	TRIGGER LOCK	1		CATALYST ATOMIZ		
44	ATE-40101	TRIGGER HOUSING	1		HA-D224-XX	ING AIR HUSE	
45	E0104-3TA	TRIGGER VALVE	1		THE OLL I AM		
46∗	D-E-006	D-RING	3	XX =	HOSE LENGTH DESI	IRED (25 FT, IS STAN	DARD
47	ATC-40105	SPRING	1		EXCEPT WITH 28:1		10 H31 H32
48*	D-B-008	O-RING	1				
49*	0-8-006 ATC-40106	O-RING	2				
50	A1L-40100	PLUG	1				



ITD-3500 GEL GUN 10-05-12 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40611-1 .020" CATALYST RESTRICTOR

ATC-40103-1 TRIGGER VALVE D-RING TOOL


ATC-40204-1 CAT. VALVE D-RING TOOL

ITD-4010 ALUMINUM RETAINING RING

NOTE A:

TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBER AND CAN ONLY BE LLERICATED WITH "SUPER O LUBE".








ITD-3500-A AUTOMATIC GEL GUN 10-05-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #		DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	62	F-SS-832-	22-E0	SET SCREW	1
2	ITD-XXX	SPRAY TIP ASSY.	1					
3	ITD-35402	CAT TIP ASSY.	1					
4	ITD-3507	TIP HOLDER	1	SEAL I	KIT SOLD S	BPARATI	RLY:	
5*	ITD-4019	TIP SEAL	1					
6*	CSP1-7	O-RING	1	* IT	D-EXT-SK	SEAL	KIT	
7	ITD-4016	DIFFUSER SEAT	1					
8+	ITD-4013	PACKING	1	HOSES	AVAILABLE	SEPARA	TELY:	
9*	D-E-012	O-RING	2	20020				
10*	D-Z-008	O-RING	5	11:1	RATIO PUM	P:		
11	ITD-4001	HEAD ASSY.	1	2000			V-0664-XX WITH	
12*	D-Z-006	O-RING	2		HAW-0344-			
13*	D-Z-020	O-RING	2			-	57/15/	
14	ATE-40701	ZCREW	2	20:1	RATIO PUM	IP:		
15*	D-Z-013	O-RING	3		FLUID HOS	E - HAV	W-0444-XX WITH	
16	ITD-4026	MATERIAL TUBE	1		HAW 0344-	5 (WHIE	BND)	
17	ATE-40213	FITTING	3					
18*	D-Z-012A	O-RING	4	28:1	RATIO PUM	P (MIN	(MAG)	
19	ATE-40214	FITTING	1			E - HAV	W-0444-1D WITH	
20	ATC-40611	RESTRICTOR	1		HAW-0344-	5 (WHIF	BND)	
21	ATC-40206	CATALYST CYLINDER	1					
22	ATE-40704	VALVE FRONT	1	ALL	RATIO PUMP	:2		
23	ATC-40208	SPLIT WASHER	1		REFINEMEN	IT/TRIGO	GER AIR HOSE -	
24*	D-T-008	O-RING	1		HA-034	4-XX		
25	ATC-40705	VALVE BACK	1		CATALYST	HOZE -	HC-D224-XX	
26	ATC-40209	CATALYST PISTON	1		CATALYST	ATOMIZ	ING AIR HOSE -	
27*	D-E-007	O-RING	1		HA-022	4-XX		
28	ITD-4012	PACKING RETAINER	1					
29	ITD-4020	NEEDLE ASSY.	1				IRED (25 FT. IS ST	ANDARD
31 32	ATC-40325 ATG-3502	ZPRING	1	3	EXCEPT WIT	H 28:1	MINI MAG PUMP)	
33	ATE-40201	GUN BACK CAT. CYLINDER PLUG	1					
38	ATE-40501	SEREW	2	OPTIO	NAL EQUIPM	DNT.		
48*	D-B-008	D-RING	1	OFIIO	MAL EQUIPM	PM1.		
49*	D-B-006	D-RING	2	ATC-40	0611-1	020* 0	ATALYST RESTRICTOR	,
51	PF-HN-02-04S	FITTING	1	A1C 4	5611 1	.020 0	AIALISI KESIKICIDI	`
53	ATE-4003-A	HANDLE	1	ATC-40	0204-1	CAT. VA	ALVE O-RING TOOL	
55	ATE-40505	AIR ADJUSTING SCREW	1	11111				
56	ATC-40506	SPRING	1	ITD-40	010	ALUMINL	M RETAINING RING	
57	ATC-40509	INSERT	1					
58*	ATC-40304-1	D-RING	1					
59*	D-B-007	O-RING	1					
60	F-CS-04C-12	CAP SCREW	1					
61	F-SS-1032-02-SS		1					







ITD-3500-INT GEL GUN 05-13-14 PARTS KEY

******	D.100 #	DECORT DETAY	omic	*******	DARM #	THOUSE THE LOW	p.mv
TTEM	PART #	DESCRIPTION	QTY	TTEN	PART #	DESCRIPTION	QTY
1		RETAINING RING	1		ATC-4003-2	HANDLE	1
2	ITD-XXX	SPRAY TIP ASSY.	1	S-100 S	ATC-40709	HANDLE GUARD	1
3	ITO-35402-INT		1	20 T T T		AIR ADJUSTING SCREW	1
4	ITD-3507	TIP HOLOER	1		ATC-40506	SPRING	1
5*	ITO-4019	TIP SEAL	1	57	ATC-40509	INSERT	1
	CSP1-7	O-RING	1	517-50	ATC-40304-1	D-RING	1
7	ITD-4016	DIFFUSER SEAT	1		□-B-007	D-RING	1
8*	ITD-4013	PACKING	1		F-SS-1032-02-SS		1
9*	D-E-012	O-RING	2	61	ATC-40616	ZET ZEREW	1
1(1)*	0-2-0	O-RING	5				
11	ITD-4001	HEAD ASSY.	1				
12*	D-Z-0	O-RING	2	SEAL	KIT SOLD SEPARATI	ELY:	
13*	D-S-020	O-RING	2				
14	ATC-40701	SCREW	2	* 11	D-EXT-2K	ZEYL KIL	
15*	0-2-013	O-RING	3				
16	ITO-4026	MATERIAL TUBE	1	HOSES	AVAILABLE SEPARA	ATELY:	
17	ATC-40213	FITTING	1				
18*	D-S-012A	O-RING	4	11:1	RATIO PUMP:		
19 20	ATC-40216	FITTING RESTRICTOR	1		FLUID HOSE - HA	W-0664-XX WITH	
77.75	ATC-40611 ATC-40206	CATALYST CYLINDER	1		HAW-0344-5 (WHIF	P END)	
22	ATC-40704	VALVE FRONT	1				
23	ATC-40704 ATC-40208	SPLIT WASHER	1	20:1	RATIO PUMP:		
24*	D-T-008	D-RING	1		HTTO HOZE - HY	W-0444-XX WITH	
25	ATC-40705	VALVE BACK	1		HAW 0344-5 (WHIF	P BND)	
26	ATC-40209	CATALYST PISTON	1				
27*	D-E-007	D-RING	î	28: [RATIO PUMP (MIN	I MAG)	
28	ITD-4012	PACKING RETAINER	1		HTTTD HOZE - HV	W-0444-10 WITH	
29	ITD-4020	NEEDLE ASSY.	1		HAW-0344-5 (WHIR	S BND)	
Эl	ATC-40325	SPRING	1				
32	ATG-3502	GUN BACK	1	ALL	RATIO PUMPS:		
33	ATC-40201	CAT. CYLINDER PLUG	1		REFINEMENT/TRIG	ER AIR HOSE -	
38	ATC-40501	SEREW	2		HA-0344-XX		
41	ATC-40108	SET SCREW	1			HCHP-023J3J-XXLC	
42	ATC-40113	TRIGGER	1		CATALYST ATOMIZ	INC VIK HOZE -	
43	ATC-40111	TRIGGER LOCK	1		HA-0224-XX		
44	ATC-40101	TRIGGER HOUSING	1	WW	LEGG LENGTH BOS	TOCO 4 DE ET 10 CT 14	
45	ATC-40103	TRIGGER VALVE	1			IRED (25 FT, IZ ZTANI	JAKU
45∗	D-E-006	O-RING	3		EXCEPT WITH 28:1	MINI WAG PUMP)	
47	ATC-40105	SPRING	1				
48*	0-8-008	O-RING	1				
49*	0-8-006	O-RING	2				
50	ATC-40106	PLUG	1				
51	PF-HN-02-04S	FITTING	1				
52	F-FHCS-1032-DB	MACHINE SCREW	2				



ITD-3500-INT GEL GUN 05-13-14 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40204-1 D-RING TOOL

ATC-40103-1 D-RING TOOL


ATC-40611-1 .020" CATALYST RESTRICTOR

ITO-4010 ALUMINUM RETAINING RING

NOTE A:

TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBBER AND CAN ONLY BE LUBRICATED WITH "SUPER O LUBE".








ITD-3500-MCC SPRAY GUN 10-05-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITRN	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	51	PF-HN-02-04S	FITTING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	52	F-FHCS-1032-SS	MACHINE SCREW	2
3	ITD-35402	CAT TIP ASSY.	1	53	ATC-4003-2	HANDLE	1
4	ITD-3507	TIP HOLDER	1	54	ATC-40709	HANDLE GUARD	1
5*	ITD-4019	TIP SEAL	1	55	ATE-40505	MERSOZ DNITZULDA SIA	1
6*	CSP1-7	□-RING	1	56	ATE-40506	SPRING	1
7	ITD-4016	DIFFUSER SEAT	1	57	ATC-40509	INSERT	1
8*	ITD-4013	PACKING	1	58+	ATC-40304-1	D-RING	1
g*	D-E-012	D-RING	2	59*	D-B-007	D-RING	1
10*	B00-Z-D	D-RING	5	60	F-SS-1032-02-SS	SET SCREW	1
11	ITD-4001	HEAD ASSY.	1	51	ATC-40616	SET SCREW	1
12*	D-Z-006	D-RING	2				
13*	0-2-020	O-RING	2				
14	ATE-40701	SCREW	2	SEAL	KIT SOLD SEPARAT	ELY:	
15*	D-Z-013	O-RING	3	10000		0041900	
16	ITD-4021	MATERIAL TUBE	1	* IT	'D -e xt-sk seal	_ KIT	
17	ATC-40213	FITTING	1				
18*	D-2-015V	D-RING	4	HOSES	AVAILABLE SEPAR	RATELY:	
19	ATC-40214	FITTING	1	10 400000			
20	ATC-40611	RESTRICTOR	1	ALL	RATIO PUMPS (22		
21	ATC-40206	CATALYST CYLINDER	1			AW-OBBB-XX WITH	
22	ATE-40704	VALVE FRONT	1		HC22-0606J-4		
23	ATE-40208	SPLIT WASHER	1			GGER AIR HOSE -	
24*	D-T-008	D-RING	1		HA-0344-XX		
25	ATC-40705	VALVE BACK	1		CATALYST HOSE -		
26	ATE-40209	CATALYST PISTON	1		CAT. ATOMIZING	AIR HOSE - HA-0224-X	×
27*	D-E-007	D-RING	1				
28	ITD-4012	PACKING RETAINER	1	XX =	: HOZE LENGTH DE	SIRED (25 FT, IS STAN	DARD >
29	ITD-4020	NEEDLE ASSY.	1				
31	ATC-40325	SPRING	1	OPTIO	NAL EQUIPMENT:		
32	ATG-3502	GLIN BACK	1				
33	ITD-4025	MIXER ELEMENT	1	ATC-4	0611-1 .020*	CATALYST RESTRICTOR	
34	ATE-40201	CAT, CYLINDER PLUG	1				
38	ATE-40501	SEREW	2	ATC-4	0103-1 TRIGGE	R VALVE O-RING TOOL	
41	ATE-40108	SET SCREW	1				
42	ATC-40113	TRIGGER	1	ATC-4	0204-1 CAT. \	ALVE O-RING TOOL	
43	ATE-40111	TRIGGER LOCK	1				- 1
44	ATC-40101	TRIGGER HOUSING	1	ITD-4	OIO ALUMIN	NUM RETAINING RING	
45	ATC-40103	TRIGGER VALVE	1		47.6		
46*	D-E-006	O-RING	3	NOTE	A:		
47	ATE-40105	SPRING	1	TRIGG	ER VALVE O-RINGS	ARE MADE OF EPR	
48*	D-B-00B	O-RING	1	RUBBE	R AND CAN ONLY B	BE LUBRICATED WITH	
49*	D-B-006	O-RING	2	*SUPE	R O LUBE*.		
50	ATC-40106	PLUG	1				








ITD-3500-MCC-INT SPRAY GUN 05-13-14 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEH	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	51	PF-HN-02-04S	FITTING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	52	E-EHCZ-1032-ZZ	MACHINE SCREW	2
3	ITD-35402-INT	CAT TIP ASSY.	1	53	ATC-4003-2	HANDLE	1
4	ITD-3507	TIP HOLDER	1	54	ATE-40709	HANDLE GUARD	1
5*	ITD-4019	TIP SEAL	1	55	ATC-40505	AIR ADJUSTING SCREW	1 1
6*	CSP1-7	D-RING	1	56	ATE-40506	SPRING	1
7	ITD-4016	DIFFUSER SEAT	1	57	ATC-40509	INSERT	1
8+	ITD-4013	PACKING	1	58+	1-40E04-1TA	D-RING	1
9∗	D-E-012	D-RING	2	59*	D-B-007	D-RING	1
10*	D-2-008	D-RING	5	60	E-22-1035-05-22	SET SCREW	1
11	ITD-4001	HEAD ASSY.	1	61	ATC-40616	SET SCREW	1
12*	D-Z-006	D-RING	2				
13*	0-2-020	D-RING	2				
14	ATC-40701	SCREW	2	SEAL	KIT SOLD SEPARAT	ELY:	
15*	D-2-013	D-RING	3				
16	ITD-4021	MATERIAL TUBE	1	* IT	D -E XL-ZK ZEYF	. KIT	
17	ATC-40213	FITTING	1	10.00		11 <u>1111111111</u>	
18*	D-2-015V	D-RING	4	HOSES	AVAILABLE SEPAR	ATELY:	
19	ATC-40216	FITTING	1	ALI	RATIO PUMPS (22:	1.8.40.13.	
20	ATC-40611	RESTRICTOR	1	ALL		W-O8BB-XX WITH	
21	ATC-40206	CATALYST CYLINDER	1		HESS-0606J-4		
22	ATC-40704	VALVE FRONT	1		REFINEMENT/TRIG		
23	ATC-40208	SPLIT WASHER	1		HA-0344-XX	IGEK YTK UDSE -	
24*	□-T-008	D-RING	1			HCHP-023J3J-XXLC	
25	ATC-40705	VALVE BACK	1			AIR HOSE - HA-0224-X	۰ I
26	ATC-40209	CATALYST PISTUN	1		CAT. ATUMIZING	WTK U02E _ UW_0554_V	^
27*	□-E-007	D-RING	1	VV.	. שחקב ו באמדע חבק	CIRED (25 FT. IS STAN	DVBDJ
28	ITD-4012	PACKING RETAINER	1	^^ =	HOSE CENDIN DES	TKED (52 FT. 12 21914	DAKO /
29	ITD-4020	NEEDLE ASSY.	1				
31	ATC-40325	SPRING	1	0PT10	NAL EQUIPMENT:		
32	ATG-3502	GUN BACK	1			100000	
33	ITD-4025	MIXER ELEMENT	1	ATC-4	0204-1 D-RIN	IG TIΙΙ.	
34	ATC-40201	CAT, CYLINDER PLUG	1				
38	ATC-40501	SCREW	2	ATC-4	0103-1 D-BIV	IG π 	
41	ATC-40108	SET SCREW	1	5500000			
42	ATC-40113	TRIGGER	1	ATC-4	0611-1 .020"	CATALYST RESTRICTOR	
43	ATC-40111	TRIGGER LOCK	1				
44	ATC-40101	TRIGGER HOUSING	1	ITO-4	OLO ALUMIN	LM RETAINING RING	
45	ATC-40103	TRIGGER VALVE	1				
46*	D-E-006	□-RING	3	NOTE	A:		
47	ATC-40105	SPRING	1	TRIGG	ER VALVE O-RINGS	ARE MADE OF EPR	
48*	D-8-008	D-RING	1	RUBBE	R AND CAN ONLY B	E LLBRICATED WITH	
49*	D-B-006	O-RING	2	"SUPE	R □ LUBE".		
50	ATC-40106	PLUG	1				







ITD-6500 GEL GUN 10-08-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	51	PF-HN-02-04S	FITTING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	52	F-FHCS-1032-08	MACHINE SCREW	2
3	ITD-35402	CAT TIP ASSY.	1	53	ATC-4003-SIG	HANDLE	1
4	ITD-3507	TIP HOLDER	1	54	ATC-40709	HANDLE GLIARD	1
5*	ITD-4019	TIP SEAL	1	55	ATC-40505	AIR ADJUSTING SCREW	1
6*	CSP1-7	D-RING	1	56	ATC-40506	SPRING	1
7	ITD-4016	DIFFUSER SEAT	1	57	ATC-40509	INSERT	1
8*	ITD-4013	PACKING	1	58*	ATC-40304-1	O-RING	1
9*	D-E-012	O-RING	2	59*	D-B-007	O-RING	1
10*	□-Z-008	O-RING	5	50	F-SS-1032-02-SS	SET SCREW	1
11	ITD-4001	HEAD ASSY.	1	61	ATC-40616	SET SCREW	1
12*	D-Z-006	O-RING	2	62	TRU-1021	ELBOW	1
13*	D-S-020	D-RING	2	63	TRU-1022	BARB	1
14	ATC-40701	SCREW	2	65	7304-3-1	ZEAL	1
15*	D-Z-013	O-RING	3				
16	ITD-4026	MATERIAL TUBE	1	CITAT :		77.37	
17	ATC-40213	FITTING	1	SEAL .	KIT SOLD SEPARATE	SLY:	
18*	D-S-012A	D-RING	4		D EVT SK SEM	KIT	
19	ATC-40214	FITTING	1	* []	D-EXT-SK SEAL	KII	
20	ATC-40611	RESTRICTOR	1				
21	ATC-40206	CATALYST CYLINDER	1	HOSES	AVAILABLE SEPARA	ATELY:	
22	ATC-40704	VALVE FRONT	1				
23	ATC-40208	SPLIT WASHER	1	11:1	RATIO PUMP:		
24*	D-T-008	D-RING	1		FLUID HOSE - HAI		
25	ATC-40705	VALVE BACK	1		HAW-0344-5 (WHIF	P END)	
26 27*	ATC-40209	CATALYST PISTON	1		B. T. T. B. W. B.		
28	D-E-007 ITD-4012	O-RING PACKING RETAINER	1	20:1	RATIO PUMP:	A DATA MA MITTO	
29	ITD-4020	NEEDLE ASSY.	1		FLUID HOSE - HAI		
31	ATC-40325	SPRING	1		HAW 0344-5 (WHIF	P END)	
32	ATG-3502	GUN BACK	1	20.1	DATTE DUND (MINI	T MAC \	
33	ATC-40201	CAT. CYLINDER PLUG	1972	2B: I	RATIO PUMP (MIN:		
38	ATC-40501	SCREW	2		FLUID HOSE - HAY		
41	ATC-40108	SET SCREW	1		HAW-U344-5 (WHI	- END)	
42	ATC-40113	TRIGGER	1	CALL	DATIO DUMPS.		
43	ATC-40111	TRIGGER LOCK	1	ALL	RATIO PUMPS: REFINEMENT/TRIGO	בבט עוט ווטגב	
44	ATC-40101	TRIGGER HOUSING	1		HA-0344-XX	JEK VIK UNZE -	
45	ATC-40103	TRIGGER VALVE	1		CATALYST HOSE -	UC_0224_VV	
46*	D-E-006	D-RING	3		CATALYST ADMIZ		
47	ATC-40105	SPRING	1		HA-0224-XX	ING MIK HOSE	
48*	D-B-008	D-RING	1		ווא טבבק אא		
49*	D-B-006	D-RING	2	XX -	HUZE LENGTH DEZ.	IRED (25 FT, IS STAND	IAPN
50	ATC-40106	PLUG	1		EXCEPT WITH 28:1		JAKD
			-		ENCEL WITH EDIT	TITUL TIPO FOR /	



ITD-6500 GEL GUN 10-08-12 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40611-1 .020" CATALYST RESTRICTOR

ATC-40103-1 TRIGGER VALVE D-RING TOOL


ATC-40204-1 CAT, VALVE D-RING TOOL

ITD-4010 ALUMINUM RETAINING RING

NOTE A:

TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBER AND CAN ONLY BE LUBRICATED WITH "SUPER O LUBE".








ITD-6500-MCC SPRAY GUN 10-08-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #	DESCRIPTION	QTY	
1	ITD-4010-PL	RETAINING RING	1	52	F-FHCS-1032-SS	MACHINE SCREW	2	
2	ITD-XXX	SPRAY TIP ASSY.	1	53	ATC-4003-SIG	HANDLE	1	
3	ITD-35402	CAT TIP ASSY.	1	54	ATE-40709	HANDLE GUARD	1	
4	ITD-3507	TIP HOLDER	1	55	ATC-40505	AIR ADJUSTING SCREW	1	
5*	ITD-4019	TIP SEAL	1	56	ATE-40506	SPRING	1	
6*	CSP1-7	D-RING	1	57	ATE-40509	INSERT	1	
7	ITD-4016	DIFFUSER SEAT	1	58*	ATC-40304-1	D-RING	1	
8*	ITD-4013	PACKING	1	59*	D-B-007	D-RING	1	
g*	D-E-012	D-RING	2	60	F-22-1032-02-22	SET SCREW	1	
10*	D-Z-008	O-RING	5	51	ATE-40515	SET SCREW	1	
11	ITD-4001	HEAD ASSY.	1	62	TRU-1021	BLBOV	1	
12*	D-Z-006	D-RING	2	63	TRU-1022	BARB	1	
13*	0-2-020	D-RING	2	65	7304-3-1	SEAL	1	
14	ATC-40701	ZCREW	2					
15*	D-Z-013	O-RING	3	SEAL	KIT SOLD SEPARAT	ELY:		
16	ITD-4021	MATERIAL TUBE	1					
17	ATC-40213	FITTING	1	* IT	D -E XT-SK SEAL	. KIT		
18*	D-Z-012A	O-RING	4					
19	ATE-40214	FITTING	1	HOSES	AVAILABLE SEPAR	ATELY:		
20	ATC-40611	RESTRICTOR	1					
21	ATC-40206	CATALYST CYLINDER	1	ALL	RATIO PUMPS (22:			
22	ATE-40704	VALVE FRONT	1			W-0888-XX WITH		
23	B0204-3TA	SPLIT WASHER	1		4-L9090-ZZJH			
24*	D-T-008	D-RING	1		REFINEMENT/TRIC	GER AIR HOSE -		
25	ATC-40705	VALVE BACK	1		HA-D344-XX	UC ODDA WY		
26	ATC-40209	CATALYST PISTON	1		CATALYST HOSE -		, I	
27*	D-E-007	O-RING	1		CAI. AIUMIZING	AIR HOSE - HA-0224-XX	·]	
28	ITD-4012	PACKING RETAINER	1	VV	LIDEE LENETH DES	TOCD 40C CT TO STAN	2100	
29	ITD-4020	NEEDLE ASSY.	1	XX =	HDZE CENDIH DES	SIRED (25 FT, IS STAND	JAKU	
31	ATC-40325	ZPRING	1					
32	ATG-3502	GUN BACK	1	OPTIO	NAL EQUIPMENT:			
33	ITD-4025	MIXER ELEMENT	1	1822 B	223 5 3 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5 5			
34	ATE-40201	CAT, CYLINDER PLUG	1	ATC-4	0611-1 .020*	CATALYST RESTRICTOR		
38	ATE-40501	SEREW	2					
41	ATC-40108	SET SCREW	1	ATC-4	0103-1 TRIGGE	R VALVE O-RING TOOL		
42	ATC-40113	TRIGGER	1	2000 V		1. 12 2002		
43	ATE-40111	TRIGGER LOCK	1	ATC-4	0204-1 CAT. V	ALVE O-RING TOOL		
44	ATE-40101	TRIGGER HOUSING	1		232 0000020			
45	E0104-3TA	TRIGGER VALVE	1	ITD-4	Old ALUMIN	UM RETAINING RING		
46*	D-E-006	O-RING	3	HARR				
47	ATE-40105	SPRING	1	NOTE	A:			
48*	D-B-00B	D-RING	1			ARE MADE OF EPR		
49*	D-B-006	D-RING	2	RUBBE	R AND CAN ONLY B	E LUBRICATED WITH		
50	ATC-40106	PLUG	1	*SUPE	R 🛘 LUBE" .			
51	PF-HN-02-04S	FITTING	1					







ITD-4000 CHOPPER GUN 10-05-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEN	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	47	ATC-40105	SPRING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	48*	D-B-008	O-RING	1
3	ITD-40402	CAT TIP ASSY.	1	49*	D-B-006	O-RING	2
4	ITD-4007	TIP HOLDER	1	50	ATC-40106	PLUG	1
5*	ITD-4019	TIP SEAL	1	51	PF-HN-02-04S	FITTING	1
6*	CSP1-7	D-RING	1	52	F-FHCS-1032-08	MACHINE SCREW	2
7	ITD-4016	DIFFUSER SEAT	1	53	ATC-4003-2	HANDLE	1
8*	ITD-4013	PACKING	1	54	ATC-40709	HANDLE GLIARD	1
9*	D-E-012	D-RING	2	55	ATC-40505	AIR ADJUSTING SCREW	1
10*	D-Z-008	D-RING	5	56	ATC-40506	SPRING	1
11	ITD-4001	HEAD ASSY.	1	57	ATC-40509	INSERT	1
12*	D-Z-006	D-RING	2	58*	ATC-40304-1	O-RING	1
13*	D-Z-020	D-RING	2	59*	□-B-007	O-RING	1
14	ATE-40701	SCREW	2	60	PF-SW-04M-06F	ZWIVEL	1
15*	D-Z-013	D-RING	3	61	F-SS-1032-02-SS	SET SCREW	1
16	ITD-4027	MATERIAL TUBE	1	62	ATC-40616	SET SCREW	1
17	ATE-40213	FITTING	1				
18*	D-Z-012A	D-RING	4				
19	ATE-40214	FITTING	1	SEAL	KIT SOLD SEPARATE	RLY:	
20	ATE-40611	RESTRICTOR	1	52112			
21	ATE-40206	CATALYST CYLINDER	1	* IT	D-EXT-SK SEAL	KIT	
22	ATE-40704	VALVE FRONT	1				
23	ATE-40208	SPLIT WASHER	1	HOSES	AVAILABLE SEPARA	TRI.Y•	
24*	0-T-008	D-RING	1	попры	ATAIDADDD DDI AK	11331.	
25	ATE-40705	VALVE BACK	1	EUB	6:[RATIO PUMP:		
26	ATE-40209	CATALYST PISTON	1		UID HOSE - HFL-O	566–XX	
27*	D-E-007	D-RING	1			300 AA	
28	ITD-4012	PACKING RETAINER	1	FNR	11:1 RATIO PUMP:		
29	ITD-4020	NEEDLE ASSY.	1			564-XX WITH HAW-0444-	-5
31	ATE-40325	SPRING	1				_
32	ATE-4002	GUN BACK	1	ALI	RATIO PUMPS:		
33	ATE-40201	CAT. CYLINDER PLUG	1		FINEMENT AIR HOSE	- HA-0324-XX	
34	ATE-40602	CHOPPER AIR VALVE	1		TALYST HOSE - HC-		
35*	D-B-003	O-RING	1		OPPER AIR HOSE -		
36*	D-B-00B	O-RING	1	CA	DAIZIMOTA TZYJAT	AIR HOSE - HA-0224-)	ΚX
37	ATE-40610	SPRING	1				1,000
38	ATE-40501	SCREW	2	XX =	HOSE LENGTH DEST	CRED (25 FT. IS STD.)
39*	D-S-012	O-RING	1				
40	ATE-40607	AIR FITTING	1				
41	ATE-40108	SET SCREW	1				
42	ATE-40113	TRIGGER	1				
43	ATE-40111	TRIGGER LOCK	1				
44	ATE-40101	TRIGGER HOUSING	1				
45 45	ATC-40103 D-E-006	TRIGGER VALVE	1				
46*	u-E-000	O-RING	3				



ITD-4000 CHOPPER GUN 10-05-12 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40611-1 .020" CATALYST RESTRICTOR

ATC-40103-1 TRIGGER VALVE D-RING TODL


ATC-40204-1 CAT. VALVE D-RING TODL

ITD-4010 ALUMINUM RETAINING RING

NOTE A:

TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBER AND CAN ONLY BE LUBRICATED WITH "SUPER O LUBE"








ITD-4000-A CHOPPER GUN 10-05-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEN	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	57	ATC-40509	TS=2NI	1
2	ITD-XXX	SPRAY TIP ASSY.	1	58*	ATE-40304-1	D-RING	1
3	ITD-40402	CAT TIP ASSY.	1	59*	D-B-007	D-RING	1
4	ITD-4007	TIP HOLDER	1	60	F-CS-04C-12	CAP SCREW	1
5*	ITD-4019	TIP SEAL	1	61	PF-SW-04M-06F	_HVIWZ	1
6*	CSP1-7	O-RING	1	62	F-SS-1032-02-	SS SET SCREW	1
7	ITD-4016	DIFFUSER SEAT	1	63	F-SS-832-03-S	S SET SCREW	1
8*	ITD-4013	PACKING	1				
9∗	D-E-012	O-RING	2				
10*	D-Z-008	O-RING	5	SRAI.	KIT SOLD SEPAR	ATRLY:	
11	ITD-4001	HEAD ASSY.	1				
12*	D-Z-006	O-RING	2	* IT	O-EXT-SK SE	AL KIT	
13*	0-2-020	O-RING	2				
14	ATC-40701	SCREW	2	HOSES	AVAILABLE SEP	ARATELY:	
15*	D-Z-013	O-RING	3				
16	ITD-4027	MATERIAL TUBE	1	FOR	6: L RATIO PUMP);	
17	ATC-40213	FITTING	3		UID HOSE - HFL		
18*	D-Z-012A	O-RING	4	20.00			
19	ATC-40214	FITTING	1	FOR	11:1 RATIO PUM	P:	
20	ATE-40611	RESTRICTOR	1	FL	WAH - 3ZDH DIU.	-0664-XX WITH HAW-0	444-5
21	ATC-40206	CATALYST CYLINDER	1				
22 23	ATE-40704 ATE-40208	VALVE FRONT SPLIT WASHER	1	ALL	RATIO PUMPS:		
24*	D-T-008	D-RING	1	RE	FINEMENT AIR H	IDSE - HA-0324-XX	
25	ATE-40705	VALVE BACK	1	CA	TALYST HOSE -	HC-0224-XX	
26	ATE-40209	CATALYST PISTON	1	CH	IOPPER AIR HOSE	- HA-0544-XX	
27*	D-E-007	D-RING	1	CA	IZIMOTA TZYJAT	NG AIR HOSE - HA-02	24-XX
28	ITD-4012	PACKING RETAINER	1				
29	ITD-4020	NEEDLE ASSY.	1	XX =	: HOZE LENGTH C	ESIRED (25 FT. IS S	TD. >
31	ATC-40325	SPRING	1				
32	ATC-4002	GUN BACK	1	OPTIO	NAL EQUIPMENT:		
34	ATC-40602	CHOPPER AIR VALVE	1		name a rot name and a		
35*	D-B-003	O-RING	1	ATC-4	0511-1 .020	" CATALYST RESTRICT	OR .
36∗	D-B-008	O-RING	1				
37	ATC-40610	SPRING	1	ATC-4	0204-L CAT.	VALVE O-RING TOOL	
38	ATC-40501	SCREW	2				
39∗	0-2-012	O-RING	1	ITD-4	OLO ALUM	INUM RETAINING RING	
40	ATC-40607	AIR FITTING	1				
41	ATE-40201	CAT, CYLINDER PLUG	1				
48*	D-B-008	D-RING	1				
49*	□-B-006	D-RING	2				
51	PF-HN-02-04S	FITTING	1				
53	ATC-4003-A	AUTO HANDLE	1				
55	ATC-40505	WESDZ DNITZULDA SIA					
56	ATC-40506	ZPRING	1				







ITD-4000-INT CHOPPER GUN 05-13-14 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEN	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	47	ATC-40105	SPRING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	48*	D-B-008	D-RING	1
3	ITD-40402-INT	CAT TIP ASSY.	1	49*	□-B-005	D-RING	2
4	ITD-4007	TIP HOLDER	1	50	ATE-40106	PLUG	1
5*	ITD-4019	TIP SEAL	1	51	PF-HN-02-04S	FITTING	1
6*	CSP1-7	D-RING	1	52	F-FHCS-1032-08	MACHINE SCREW	2
7	ITD-4016	DIFFUSER SEAT	1	53	ATE-4003-2	HANDLE	1
8*	ITD-4013	PACKING	1	54	ATE-40709	HANDLE GUARD	1
9*	D-E-012	D-RING	2	55	ATE-40505	MIR ADJUZTING SCREW	1
10*	B00-Z-D	D-RING	5	56	ATE-40506	SPRING	1
11	ITD-4001	HEAD ASSY.	1	57	ATC-40509	INSERT	1
12*	D-Z-006	D-RING	2	58*	ATE-40304-1	D-RING	1
13*	0-2-020	O-RING	2	59*	□-B-007	D-RING	1
14	ATC-40701	SCREW	2	60	PF-SW-04M-06F	ZMIABT	1
15*	E10-Z-0	D-RING	3	61	F-ZZ-1032-02-ZZ	SET SCREW	1
16	ITD-4027	MATERIAL TUBE	1	62	ATE-40616	SET SCREW	1
17	ATC-40213	FITTING	1				
18*	D-Z-012A	O-RING	4				
19	ATC-40216	FITTING	1	SEAL	KIT SOLD SEPARATI	ELY:	
20	ATC-40611	RESTRICTOR	1	10000			
21	ATC-40206	CATALYST CYLINDER	1	* 11	D-EXT-SK SEAL	KIT	
22	ATC-40704	VALVE FRONT	1				
23	ATC-40208	SPLIT WASHER	1	HOSES	AVAILABLE SEPAR	ATELY:	
24*	D-T-008	O-RING	1				
25	ATE-40705	VALVE BACK	1		6: L RATIO PUMP:		
26	ATC-40209	CATALYST PISTON	1	FL	.UID HOSE - HFL-0	666-XX	
27*	D-E-007	O-RING	1				
28 29	ITD-4012	PACKING RETAINER NEEDLE ASSY.	1		11:1 RATIO PUMP:		
31	ITD-4020	SPRING	1	FL	O-WAH - 32DH DIU.	664-XX WITH HAW-0444	-5
32	ATC-40325 ATC-4002	GUN BACK	1				
33	ATE-40201	CAT, CYLINDER PLUG	1		RATIO PUMPS:		
34	ATE-40602	CHOPPER AIR VALVE	1		FINEMENT AIR HOS		
35*	D-B-003	D-RING	1		TALYST HOSE - HO		
36*	D-B-008	D-RING	1		IOPPER AIR HOSE -		
37	ATC-40610	SPRING	1	CA	TALYST ATOMIZING	AIR HOSE - HA-0224-	XX
38	ATE-40501	SCREW	2	MM	LEGG LEVETU DES	TOTO 4 05 5T TO 5TD	.
39*	D-Z-015	O-RING	1	XX =	HUZE CENRIH DEZ	IRED (25 FT, IS STD.	2
40	ATE-40607	AIR FITTING	1				
41	ATE-40108	SET SCREW	1				
42	ATE-40113	TRIGGER	1				
43	ATE-40111	TRIGGER LOCK	1				
44	ATE-40101	TRIGGER HOUSING	1				
45	ATE-40103	TRIGGER VALVE	1				
45*	D-E-006	O-RING	3				
10.000000		704 CO (CO	.50				



ITD-4000-INT CHOPPER GUN 05-13-14 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40204-1 D-RING TOOL

ATC-40103-1 D-RING TOLL


ATC-40611-1 .020" CATALYST RESTRICTOR

ITD-4010 ALUMINUM RETAINING RING

NOTE A:

TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBER AND CAN ONLY BE LUBRICATED WITH "SUPER O LUBE"








ITD-4000-MCC CHOPPER GUN 10-08-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEN	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	47	ATE-40105	SPRING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	48*	D-B-008	D-RING	1
3	ITD-40402	CAT TIP ASSY.	1	49*	D-B-006	D-RING	2
4	ITD-4007	TIP HOLDER	1	50	ATE-40106	PLUG	1
5*	ITD-4019	TIP SEAL	1	51	PF-HN-02-04S	FITTING	1
6*	CSP1-7	O-RING	1	52	F-FHCS-1032-08	MACHINE SCREW	2
7	ITD-4016	DIFFUSER SEAT	1	53	ATC-4003-2	HANDLE	1
9∗	ITD-4013	PACKING	1	54	ATE-40709	HANDLE GUARD	1
9*	D-E-012	O-RING	2	55	ATE-40505	WERDS DNITSULDA RIA	1
10*	D-Z-008	O-RING	5	56	ATE-40506	ZPRING	1
11	ITD-4001	HEAD ASSY.	1	57	ATE-40509	INZERT	1
12*	D-Z-006	O-RING	2		ATE-40304-1	D-RING	1
13*	D-Z-020	D-RING	2		□-B-007	D-RING	1
14	ATE-40701	ZEKEM	2	60	ITD-4025	MIXING ELEMENT	1
15*	D-Z-013	O-RING	3	61	F-SS-1032-02-SS		1
16	ITD-4021	MATERIAL TUBE	1	62	ATC-40616	SET SCREW	1
17	ATC-40213	FITTING	1				
18*	D-S-012A	D-RING	4	SEAL	KIT SOLD SEPARATI	ELY:	
19	ATE-40214	FITTING	1				
20	ATC-40611 ATC-40206	RESTRICTOR	1	* 11	□ -E XT-SK SEAL	KIT	
21		CATALYST CYLINDER	1	плата	AVAILABLE SEPAR	ביי עייי ע	
22 23	ATE-40704 ATE-40208	VALVE FRONT SPLIT WASHER]]	DODA	AVAILABLE DEPAR	rieni:	
24*	D-T-008	D-RING	1	ALI	RATIO PUMPS (22:	1.8.40:10:	
25	ATE-40705	VALVE BACK	1	100	UID HDSE - HAW-O		
25	ATE-40209	CATALYST PISTON	1		HCSS-D6D6J-4 WH		
27*	D-E-007	D-RING	1	RE	FINEMENT AIR HOS		
28	ITD-4012	PACKING RETAINER	1	0.25.7	TALYST HOSE - HC		
29	ITD-4020	NEEDLE ASSY.	1	5300	OPPER AIR HOSE -		
31	ATE-40325	SPRING	1			AIR HOSE - HA-0224-	XX
32	ATE-4002	GUN BACK	i				
33	ATE-40201	CAT. CYLINDER PLUG	1	XX =	HOSE LENGTH DES	IRED (25 FT. IS STD.	>
34	ATC-40602	CHOPPER AIR VALVE	1				36
35*	D-B-003	D-RING	1	OPTIO	NAL EQUIPMENT:		
36*	D-B-00B	O-RING	1				
37	ATC-40610	SPRING	1	ATC-4	0611-1 .020* (CATALYST RESTRICTOR	
38	ATC-40501	SCREW	2	ATC-4	0103-l TRIGGE	R VALVE O-RING TOOL	
39*	D-Z-012	O-RING	1	ATC-4	0204-L CAT, V	ALVE O-RING TOOL	
40	ATE-40607	AIR FITTING	1	ITD-4	OLO ALUMINI	JM RETAINING RING	
41	ATC-40108	SET SCREW	1				
42	ATE-40113	TRIGGER	1	NOTE	A:		
43	ATE-40111	TRIGGER LOCK	1	TRIGG	ER VALVE O-RINGS	ARE MADE OF EPR	
44	ATE-40101	TRIGGER HOUSING	1	RUBBE	R AND CAN ONLY BE	E LUBRICATED WITH	
45	ATC-40103	TRIGGER VALVE	1	*SUPE	R D LUBE*		
46*	D-E-006	O-RING	3	draw	70 (8)		








ITD-4000-MCC-INT CHOPPER GUN 05-13-14 PARTS KEY

	TANIS KIII								
ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #	DESCRIPTION	QTY		
1	ITD-4010-PL	RETAINING RING	1	49*	D-B-006	O-RING	2		
2	ITD-XXX	SPRAY TIP ASSY.	1	50	ATC-40106	PLUG	1		
3	ITD-40402-INT	CAT TIP ASSY.	1	51	PF-HN-02-04S	FITTING	1		
4	ITD-4007	TIP HOLDER	1	52	F-FHCS-1032-08	MACHINE SCREW	2		
5*	ITD-4019	TIP SEAL	1	53	ATC-4003-2	HANDLE	1		
6*	CSP1-7	D-RING	1	54	ATC-40709	HANDLE GUARD	1		
7	ITD-4016	DIFFUSER SEAT	1	55	ATC-40505	AIR ADJUSTING SCREW	1		
8*	ITD-4013	PACKING	1	56	ATC-40506	SPRING	1		
9*	D-E-012	O-RING	2	57	ATC-40509	INSERT	1		
10*	B00-Z-D	D-RING	5	58*	ATC-40304-1	D-RING	1		
11	ITD-4001	HEAD ASSY.	1	59*	□-B-007	D-RING	1		
12*	D-S-006	D-RING	2	60	ITD-4025	MIXING ELEMENT	1		
13*	D-S-020	O-RING	2	61	F-SS-1032-02-SS	SET SCREW	1		
14	ATC-40701	SCREW	2	62	ATC-40616	SET SCREW	1		
15*	D-S-013	O-RING	3						
16	ITD-4021	MATERIAL TUBE	1						
17	ATC-40213	FITTING	1	SEAL	KIT SOLD SEPARATI	ELY:			
18*	D-S-012A	D-RING	4	922		material money			
19	ATC-40216	FITTING	1	* [D-EXT-SK	SEAL KIT			
20	ATC-40611	RESTRICTOR	1	посте	AVAILABLE GEDAD	A (1972) 37 -			
21	ATC-40206	CATALYST CYLINDER	1	HOSES	AVAILABLE SEPAR.	ATELI:			
22	ATC-40704	VALVE FRONT	1	ALI	DATTO DUMPS / 22.	1 9 40.10.			
23	ATC-40208	SPLIT WASHER	1		RATIO PUMPS (22:				
24*	□-T-008	O-RING	1	FL	UCSS OFFE A WILL				
25	ATC-40705	VALVE BACK	1	· DE	HW 4-Ladao-222H				
26	ATC-40209	CATALYST PISTON	1		FINEMENT AIR HOS TALYST HOSE - HC				
27*	□-E-007	O-RING	1		IOPPER AIR HOSE - HC				
28	ITD-4012	PACKING RETAINER	1			AIR HOSE - HA-0224-7	vv		
29	ITD-4020	NEEDLE ASSY.	1	LA	TIACIZI ATUNIZZINO	AIK HUSE - HA-0224-7	^^		
31	ATC-40325	SPRING	1	VV -	. שחפב ו באוכדע חבק	IRED (25 FT, IS STD,)		
32	ATC-4002	GUN BACK	1	^^ -	. HUSE EEMOTH DES	TVCD /50 1' 12 2 D'	′		
33	ATC-40201	CAT, CYLINDER PLUG	1	OPTIO	NAL EQUIPMENT:				
34	ATC-40602	CHOPPER AIR VALVE	1	01110	ndb agotimani:				
35*	□-B-003	O-RING	1	ΔTC-4	0204-1 D-RIN	G TOOL			
36*	□-B-008	O-RING	1	AIC T	0204 1 1 11111	- 100L			
37	ATC-40610	SPRING	1	ATC-4	0103-l	G TOOL			
38	ATC-40501	SCREW	2	,,,,	0103 (- 1 - O - C			
39*	D-S-012	O-RING	1	ATC-4	0611-1 .020" 1	CATALYST RESTRICTOR			
40	ATC-40607	AIR FITTING	1			emmeror neomizeran			
41	ATC-40108	SET SCREW	1	ITD-4	O1O ALLIMINIIM	RETAINING RING			
42	ATC-40113	TRIGGER	1						
43	ATC-40111	TRIGGER LOCK	1	NOTE	A:				
44	ATC-40101	TRIGGER HOUSING	1		ER VALVE D-RINGS	ARE MADE DE ERR			
45	ATC-40103	TRIGGER VALVE	1			E LUBRICATED WITH			
46*	D-E-006	O-RING	3		R D LUBE"	C COOKICATED WITH			
47	ATC-40105 D-B-008	SPRING	1	2UI L	N U LUDL				
48*	n_p_00g	O-RING	1						







ITD-6000 CHOPPER GUN 10-08-12 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #	DESCRIPTION	QTY
1	ITD-4010-PL	RETAINING RING	1	47	ATE-40105	SPRING	1
2	ITD-XXX	SPRAY TIP ASSY.	1	48*	D-B-008	D-RING	1
3	ITD-40402	CAT TIP ASSY.	1	49*	D-B-006	D-RING	2
4	ITD-4007	TIP HOLDER	1	50	ATE-40106	PLUG	1
5*	ITD-4019	TIP SEAL	1	51	240-20-NH-79	FITTING	1
6*	CSP1-7	O-RING	1	52	F-FHCS-1032-08	MACHINE SCREW	2
7	ITD-4016	DIFFUSER SEAT	1	53	ATC-4003-SIG	HANDLE	1
8∗	ITD-4013	PACKING	1	54	ATE-40709	HANDLE GUARD	1
9∗	D-E-012	O-RING	2	55	ATE-40505	MIR ADJUZTING SCREW	
10*	D-Z-008	D-KING	5	56	ATE-40506	SPRING	1
11	ITD-4001	HEAD ASSY.	1	57	ATC-40509	INSERT	1
12*	D-Z-006	O-RING	2		ATE-40304-1	D-RING	1
13*	D-S-020	O-RING	2		D-B-007	D-RING	1
14	ATE-40701	SCREW	2	60	PF-SW-04M-06F	ZMINET	1
15*	D-Z-013	O-RING	3	61	F-SS-1032-02-SS		1
16	ITD-4027	MATERIAL TUBE	1	62	ATC-40616	SET SCREW	1
17	ATC-40213	FITTING	1	64	TRU-1021	ELBOV	1
18*	D-S-012A	O-RING	4	65 65	TRU-1022	BARB	1
19 20	ATE-40214	FITTING RESTRICTOR	1	66	7304-3-1	SEAL	1
20	ATC-40611 ATC-40206	CATALYST CYLINDER	1				
22	ATE-40704	VALVE FRONT]				
23	ATE-40704 ATE-40208	SPLIT WASHER	1	SEAL	KIT SOLD SEPARATE	RLY:	
24*	D-T-008	D-RING	1	, TT	D EVT SK SEM	VIT	
25	ATE-40705	VALVE BACK	1	4 II	D-EXT-SK SEAL	KII	
26	ATE-40209	CATALYST PISTON	1				
27*	D-E-007	D-RING	1	HOSES	AVAILABLE SEPARA	ATELY:	
28	ITD-4012	PACKING RETAINER	1				
29	ITD-4020	NEEDLE ASSY.	1	2000	6:L RATIO PUMP:		
31	ATC-40325	SPRING	1	FL	NID HOZE - HET-O	app—XX	
32	ATC-4002	GUN BACK	1	COC	I DITTO 5:4:5		
33	ATC-40201	CAT. CYLINDER PLUG	1		11:1 RATIO PUMP:	C4 VV WITH HAW 0444	_
34	ATE-40602	CHOPPER AIR VALVE	1	FL	DID HD2F - HWA-OF	64-XX WITH HAW-0444	_2
35*	D-B-003	D-RING	1	ALI	DATED DUMPS		
36∗	D-B-00B	O-RING	1		RATIO PUMPS:	_ UA_0224 VV	
37	ATC-40610	SPRING	1		FINEMENT AIR HOSE		
38	ATE-40501	SEREW	2		TALYST HOSE - HC- OPPER AIR HOSE -		
39*	D-Z-012	O-RING	1			AIR HOSE - HA-0224-	vv
40	ATE-40607	AIR FITTING	1	LA	TACTOL WIGHTSTING	AIR 103E - 04-0224-	^^
41	ATC-40108	SET SCREW	1	XX -	HUZE LEWETH DEZI	(RED < 25 FT. IS STD.	5
42	ATE-40113	TRIGGER	1	^^ =	LEGE CENDIN DES	ויוו ובי ווי די אוחי	6
43	ATE-40111	TRIGGER LOCK	1				
44	ATE-40101	TRIGGER HOUSING	1				
45	ATC-40103	TRIGGER VALVE	1				
46*	D-E-006	O-RING	3				



ITD-6000 CHOPPER GUN 10-08-12 PARTS KEY, PAGE 2

OPTIONAL EQUIPMENT:

ATC-40611-1 .020" CATALYST RESTRICTOR

ATC-40103-1 TRIGGER VALVE D-RING TOOL

ATC-40204-1 CAT. VALVE D-RING TODL


ITD-4010 ALUMINUM RETAINING RING

NOTE A:


TRIGGER VALVE O-RINGS ARE MADE OF EPR RUBBER AND CAN ONLY BE LUBRICATED WITH "SUPER O LUBE"



ITD-EXT-SK







CORPORATE HEADQUARTERS 2030 Falling Waters Rd, Suite 350, Knoxville, TN 37922 · USA · Tel: (865) 686-5670

> DISTRIBUTION AND PURCHASING 642 Barbrow Ln, Knoxville, TN 37932 · USA · Tel: (865) 684-4416

TECHNOLOGY CENTER AND MANUFACTURING

1862 Ives Ave, Kent, WA 98032 · USA · Tel (253) 854-2660 · Fax (253) 854-1666

E-mail: info@mvpind.com

For a list of international distributors, visit our website at:

www.mvpind.com/mvp-international

