



NOTE: KEEP ROLL PIN SEPARATE UNTIL CONNECTING TO POWER HEAD

Parts List			
ITEM	PART NUMBER	QTY	DESCRIPTION
1	03501-1	2	BUSHING
2	03502-1	2	BEARING - UPPER SLAVE ARM
3	52106-1	1	QUICK PIN CABLE
4	86480-1	1	UPPER SLAVE ARM
5	CCP-1005	1	CONNECTING BAR
6	CCP-1006	1	LOWER SLAVE ARM
7	F-RP-04-20	2	ROLL PIN
8	F-RP-04-32	1	ROLL PIN

# MAGNUM VENUS PRODUCTS

SINGLE HIS SLAVE ARM	VLS-7100
----------------------	----------