
Patriot Powerhead


Component Manual

This manual is applicable to the following models:

- PAT-PH-3250
- PAT-PH-3250-INV
- PAT-PH-4250
- PAT-PH-5000
- PAT-PH-5000-CA
- PAT-PH-5000-SSB
- PAT-PH-5000-INV
- PAT-PH-5000-XD
- PAT-PH-7000
- PAT-PH-7000-CA
- PAT-PH-7000-D
- PAT-PH-7000-HD
- PAT-PH-7000-P
- PAT-PH-10000







CORPORATE HEADQUARTERS 2030 Falling Waters Rd, Suite 350, Knoxville, TN 37922 · USA · Tel: (865) 686-5670

DISTRIBUTION AND PURCHASING 642 Barbrow Ln, Knoxville, TN 37932 · USA · Tel: (865) 684-4416

TECHNOLOGY CENTER AND MANUFACTURING
1862 Ives Ave, Kent, WA 98032 · USA · Tel (253) 854-2660 · Fax (253) 854-1666

E-mail: info@mvpind.com

For a list of international distributors, visit our website at : www.mvpind.com/mvp-international

Use of this product confirms that Magnum Venus Products, Inc.'s standard terms and conditions of sale apply.



▲ Table of Contents

S	ection	Page
•	Table of Contents	3
•	Safety & Warning Information	4
•	Introduction	15
•	Disassembling Valve Block	16
•	Reassembling Valve Block	18
•	Disassembling Air Cylinder	19
•	Rebuilding Pilot Valve	20
•	Reassembling Air Cylinder	20
•	Parts Drawings	21



Safety & Warning Information

Warnings 4

Due to the vast number of chemicals that could be used and their varying chemical reactions, the buyer and user of this equipment should determine all factors relating to the fluids used, including any of the potential hazards involved. Particular inquiry and investigation should be made into potential dangers relating to toxic fumes, fires, explosions, reaction times, and exposure of human beings to the individual components or their resultant mixtures. MVP assumes no responsibility for loss, damage, expense or claims for bodily injury or property damage, direct or consequential, arising from the use of such chemical components.

The end user is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used and that all documentation is adhered to.

Recommended Occupational Safety & Health Act (OSHA) Documentation:

1910.94 Pertaining to ventilation Pertaining to flammable liquids 1910.106 Pertaining to spray finishing operations, particularly paragraph (m), 1910.107 Organic Peroxides and Dual Component Coatings

For Additional information, contact the Occupational Safety and Health Administration (OSHA) at https://www.osha.gov/about.html.

Recommended National Fire Protection Association (NFPA) Documentation:

Organic Peroxides and Dual Component Materials NFPA No.33 Chapter 14 NFPA No. 63 **Dust Explosion Prevention** National Electrical Code NFPA No. 70 Static Electricity NFPA No. 77 Blower and Exhaust System NFPA No. 91 Plastics Industry Dust Hazards NFPA No. 654

Fire Extinguisher – code ABC, rating number 4a60bc using Extinguishing Media –Foam, Carbon Dioxide, Dry Chemical, Water Fog, is recommended for this product and applications.

The following general warnings and guidelines are for the setup, use, grounding, maintenance, and repair of equipment. Additional product-specific warnings may be found throughout this manual as applicable. Please contact your nearest MVP Technical Service Representative if additional information is needed.



Safety Precautions

- Avoid skin contact and inhalation of all chemicals.
- Review Material Safety Data Sheet (MSDS) to promote the safe handling of chemicals in
- Restrict the use of all chemicals to designated areas with good ventilation.
- Chemicals are flammable and reactive.
- Noxious fumes released when combusted.
- Operate equipment in a ventilated environment only.
- Uncured liquid resins are highly flammable unless specifically labeled otherwise.
- Cured laminate, accumulations of overspray, and laminate sandings are highly combustible.
- Do not operate or move electrical equipment when flammable fumes are present.
- Ground all equipment.
- If a spark is seen or felt, immediately halt operation. Do not operate the equipment until the issue has been identified and repaired.
- Contaminated catalyst may cause fire or explosion.
- Containers may explode if exposed to fire / heat.
- Use and store chemicals away from heat, flames, and sparks.
- Do not smoke in work areas or near stored chemicals.
- Do not mix Methyl Ethyl Ketone Peroxide (MEKP) with materials other than polyethylene.
- Do not dilute MEKP.
- Keep food and drink away from work area.







FLAMMABLE



GROUNDING



EXPLOSIVE



DANGER



DANGER



Physical Hazards

- Never look directly into the spray gun fluid tip. Serious injury or death can result.
- Never aim the spray gun at or near another person. Serious injury or death can result.
- Chemical compounds can be severely irritating to the eyes and skin.
- Inhalation, ingestion, or injection may damage internal organs and lead to pulmonary disorders, cancers, lymphomas, and other diseases or health conditions.
- Other potential health effects include: irritation of the eyes and upper respiratory tract, headache, light-headedness, dizziness, confusion, drowsiness, nausea, vomiting, and occasionally abdominal pain.
- Eye contact: Immediately flush with water for at least 15 minutes and seek immediate medical attention.
- Skin Contact: Immediately wash with soap and water and seek immediate medical attention.
- Inhalation: Move the person to fresh air and seek immediate medical attention.
- Do not remove shields, covers, or safety features on equipment that is in use.
- Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can shoot liquid through the skin.
- Keep hands and body parts away from any moving equipment or components.
- Do not stand under plunger
- An improperly loaded drum may lead to an imbalance, causing a unit to tip over





Personal Protective Equipment (PPE)

- MVP recommends the use of personal safety equipment with all products in our catalog.
- Wear safety goggles, hearing protection, a respirator, and chemical resistant gloves.
- Wear long sleeve shirts or jackets and pants to minimize skin exposure.
- PPE should be worn by operators and service technicians to reduce the risk of injury.



For Additional information, contact the Occupational Safety and Health Administration (OSHA). https://www.osha.gov/about.html



Symbol Definitions



Indicates the risk of contact with chemicals that are hazardous, which may lead to injury or death.



Indicates the risk of contact with voltage / amperage that may lead to serious injury or death



Indicates that the materials being used are susceptible to combustion



Indicates the risk of contact with moving components that may lead to serious injury or death.



Indicates that the system or component should be grounded before proceeding with use or repair.



Indicates the use of lit cigarettes or cigars is prohibited, because the materials being used are susceptible to combustion.



Indicates that the materials and/or the process being performed can lead to ignition and explosion.



A recommendation for the use of Personal Protective Equipment (PPE) before using or repairing the product.



Polymer Matrix Materials: Advanced Composites

Potential health hazards associated with the use of advanced composites can be controlled through the implementation of an effective industrial hygiene and safety program.

https://www.osha.gov/dts/osta/otm/otm_iii/otm_iii_1.html#t iii:1_1

Resins					
Composite Component Organ System Target Known (Possible) Health Effect					
	(Possible Target)				
Epoxy resins	Skin, lungs, eyes	Contact and allergic dermatitis,			
грому геото	Orani, rango, oyoo	conjunctivitis			
Polyurethane resins	Lungs, skin, eyes	Respiratory sensitization, contact			
-		dermatitis, conjunctivitis			
Phenol formaldehyde	Skin, lungs, eyes	As above (potential carcinogen)			
Bismaleimides (BMI)	Skin, lungs, eyes	As above (potential carcinogen)			
Polyamides	Skin, lungs, eyes	As above (potential carcinogen)			
Reinforcing materials					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Aramid fibers	Skin (lungs)	Skin and respiratory irritation, contact			
Aramid fibers	Okiii (iuligs)	dermatitis (chronic interstitial lung disease)			
Carbon/graphite fibers	Skin (lungs)	As noted for aramid fibers			
Glass fibers (continuous	Skin (lungs)	As noted for aramid fibers			
filament)	Okiii (idiigs)				
Hardeners and curing agents					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Diaminodiphenylsulfone	N/A	No known effects with workplace			
Diaminodiphenyisunone	14/74	exposure			
Methylenedianiline	Liver, skin	Hepatotoxicity, suspect human carcinogen			
Other aromatic amines					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Meta-phenylenediamine (MPDA)	Liver, skin (kidney,	Hepatitis, contact dermatitis (kidney and			
Meta-prierryleriediamine (Mi DA)	bladder)	bladder cancer)			
Aliphatic andcyclo-aliphatic	Eyes, skin	Severe irritation, contact dermatitis			
amines					
Polyaminoamide	Eyes, skin	Irritation (sensitization)			
Anhydride	Eyes, lungs, skin	Severe eye and skin irritation, respiratory			
, aa.		sensitization, contact dermatitis			



Catalyst - Methyl Ethyl Ketone Peroxide (MEKP)

MEKP is among the more hazardous materials found in commercial channels. The safe handling of the "unstable (reactive)" chemicals presents a definite challenge to the plastics industry. The highly reactive property which makes MEKP valuable to the plastics industry in producing the curing reaction of polyester resins also produces the hazards which require great care and caution in its storage, transportation, handling, processing and disposal. MEKP is a single chemical. Various polymeric forms may exist which are more or less hazardous with respect to each other. These differences may arise not only from different molecular structures (all are, nevertheless, called "MEKP") and from possible trace impurities left from the manufacture of the chemicals, but may also arise by contamination of MEKP with other materials in its storage or use. Even a small amount of contamination with acetone, for instance, may produce an extremely shock-sensitive and explosive compound.



WARNING

Contamination with promoters, materials containing promoters (such as laminate sandings), or with any readily oxidizing material (such as brass or iron) will cause exothermic redox reactions which can be explosive in nature. Heat applied to MEKP or heat buildup from contamination reactions can cause the material to reach its Self-Accelerating Decomposition Temperature (SADT).

Researchers have reported measuring pressure rates-of-rise well over 100,000 psi per second when certain MEKP's reach their SADT. For comparison, the highest-pressure rate-of-rise listed in NFPA Bulletin NO.68, "Explosion Venting", is 12,000 psi per second for an explosion of 12% acetylene and air. The maximum value listed for a hydrogen explosion is 10,000 psi per second. Some forms of MEKP, if allowed to reach their SADT, will burst even an open topped container. This suggests that it is not possible to design a relief valve to vent this order of magnitude of pressure rate-of-rise. The user should be aware that any closed container, be it a pressure vessel, surge chamber, or pressure accumulator, could explode under certain conditions. There is no engineering substitute for care by the user in handling organic peroxide catalysts. If, at any time, the pressure relieve valve on top of the catalyst tank should vent, the area should be evacuated at once and the fire department called. The venting could be the first indication of a heat, and therefore, pressure build-up that could eventually lead to an explosion. Moreover, if a catalyst tank is sufficiently full when the pressure relief valve vents, some catalyst may spray out, which could cause eye injury. For this reason, and many others, anyone whose job puts them in an area where this vented spray might go, should always wear full eye protection even when laminating operations are not taking place.

Safety in handling MEKP depends to a great extent on employee education, proper safety instructions, and safe use of the chemicals and equipment. Workers should be thoroughly informed of the hazards that may result from improper handling of MEKP, especially regarding contamination, heat, friction and impact. They should be thoroughly instructed regarding the proper action to be taken in the storage, use, and disposal of MEKP and other hazardous materials used in the laminating operation. In addition, users should make every effort to:

- Store MEKP in a cool, dry place in original containers away from direct sunlight and away from other chemicals.
- Keep MEKP away from heat, sparks, and open flames.
- Prevent contamination or MEKP with other materials, including polyester over spray and sandings, polymerization accelerators and promoters, brass, aluminum, and non-stainless steels.



- Never add MEKP to anything that is hot, since explosive decomposition may result.
- Avoid contact with skin, eyes, and clothing. Protective equipment should be worn at all times. During clean-up of spilled MEKP, personal safety equipment, gloves, and eye protection must be worn. Firefighting equipment should be at hand and ready.
- Avoid spillage, which can heat up to the point of self-ignition.
- Repair any leaks discovered in the catalyst system immediately, and clean-up the leaked catalyst at once in accordance with the catalyst manufacturer's instructions.
- Use only original equipment or equivalent parts from Magnum Venus Products in the catalyst system (i.e.: hoses, fitting, etc.) because a dangerous chemical reaction may result between substituted parts and MEKP.
- Catalyst accumulated from the purging of hoses or the measurement of fluid output deliveries should never be returned to the supply tank, such catalyst should be diluted with copious quantities of clean water and disposed of in accordance with the catalyst manufacturer's instructions.

The extent to which the user is successful in accomplishing these ends and any additional recommendations by the catalyst manufacturer determines largely the safety that will be present in his operation.

Clean-Up Solvents and Resin Diluents



WARNING

A hazardous situation may be present in your pressurized fluid system! Hydro carbon solvents can cause an explosion when used with aluminum or galvanized components in a closed (pressurized) fluid system (pump, heaters, filters, valves, spray guns, tanks, etc.). An explosion could cause serious injury, death, and/or substantial property damage. Cleaning agents, coatings, paints, etc. may contain Halogenated Hyrdrocarbon solvents. Some Magnum Venus Products spray equipment includes aluminum or galvanized components and will be affected by Halogenated Hydrocarbon solvents.

There are three key elements to the Halogenated Hyrdocarbon (HHC) solvent hazard.

- 1. The presence of HHC solvents.
- Aluminum or Galvanized Parts.
- 3. Equipment capable of withstanding pressure.
- 1,1,1 Trichloroethane and Methylene Chloride are the most common of these solvents. However, other HHC solvents are suspect if used; either as part of paint or adhesives formulation, or for clean-up flushing. Most handling equipment contains these elements. In contact with these metals, HHC solvents could generate a corrosive reaction of a catalytic nature.
- When HHC solvent contact aluminum or galvanized parts inside a closed container such as a pump, spray gun, or fluid handling system, the chemical reaction can, over time, result in a build-up of heat and pressure, which can reach explosive proportions. When all three elements are present, the result can be an extremely violent explosion. The reaction can be sustained with very little aluminum or galvanized metal; any amount of aluminum is too much.



- The reaction is unpredictable. Prior use of an HHC solvent without incident (corrosion or explosion) does NOT mean that such use is safe. These solvents can be dangerous alone (as a clean-up or flushing agent) or when used as a component or a coating material. There is no known inhibitor that is effective under all circumstances. Mixing HHC solvents with other materials or solvents such as MEKP, alcohol, or toluene may render the inhibitors ineffective.
- The use of reclaimed solvents is particularly hazardous. Reclaimers may not add any inhibitors. The possible presence of water in reclaimed solvents could also feed the reaction.
- Anodized or other oxide coatings cannot be relied upon to prevent the explosive reaction. Such
 coatings can be worn, cracked, scratched, or too thin to prevent contact. There is no known way
 to make oxide coatings or to employ aluminum alloys to safely prevent the chemical reaction
 under all circumstances.
- Several solvent suppliers have recently begun promoting HHC solvents for use in coating systems. The increasing use of HHC solvents is increasing the risk. Because of their exemption from many state implementation plans as Volatile Organic Compounds (VOCs), their low flammability hazard, and their not being classified as toxic or carcinogenic substances, HHC solvents are very desirable in many respects.



WARNING

Do not use Halogenated Hydrocarbon (HHC) solvents in pressurized fluid systems having aluminum or galvanized wetted parts.

Magnum Venus Products is aware of NO stabilizers available to prevent HHC solvents from reaction under all conditions with aluminum components in closed fluid systems. HHC solvents are dangerous when used with aluminum components in a closed fluid system.

- Consult your material supplier to determine whether your solvent or coating contains Halogenated Hydrocarbon solvents.
- Magnum Venus Products recommends that you contact your solvent supplier regarding the best non-flammable clean-up solvent with the heat toxicity for your application.
- If, however, you find it necessary to use flammable solvents, they must be kept in approved, electrically grounded containers.
- Bulk solvent should be stored in a well-ventilated, separate building, 50 feet away from your main plant.
- You should only allow enough solvent for one day's use in your laminating area.
- NO SMOKING signs must be posted and observed in all areas of storage or where solvents and other flammable materials are used.
- Adequate ventilation (as covered in OSHA Section 1910.94 and NFPA No.91) is important wherever solvents are stored or used, to minimize, confine and exhaust the solvent vapors.
- Solvents should be handled in accordance with OSHA Section 1910.106 and 1910.107.



Catalyst Diluents

Magnum Venus Products spray-up and gel-coat systems currently produced are designed so that catalyst diluents are not required. Magnum Venus Products therefore recommends that diluents not be used to avoid possible contamination which could lead to an explosion due to the handling and mixing of MEKP and diluents. In addition, it eliminates any problems from the diluent being contaminated through rust particles in drums, poor quality control on the part of the diluents suppliers, or any other reason. If diluents are absolutely required, contact your catalyst supplier and follow his instructions explicitly. Preferably the supplier should premix the catalyst to prevent possible "on the job" contamination while mixing.



WARNING

If diluents are not used, remember that catalyst spillage and gun, hose, and packing leaks are potentially more hazardous since each drop contains a higher concentration of catalyst and will therefore react more quickly with overspray and the leak.

Cured Laminate, Overspray and Laminate Sandings Accumulation

- Remove all accumulations of overspray, Fiberglass Reinforced Plastic (FRP) sandings, etc. from the building as they occur. If this waste is allowed to build up, spillage of catalyst is more likely to start a fire; in addition, the fire would burn hotter and longer.
- Floor coverings, if used, should be non-combustible.
- Spilled or leaked catalyst may cause a fire if it comes in contact with an FRP product, oversprayed chop or resin, FRP sandings or any other material with MEKP.

To prevent spillage and leakage, you should:

the hoses at any point.

1.	Maintain your Magnum Venus	Check the gun several times daily for catalyst and
	Products System.	resin packing or valve leaks. REPAIR ALL LEAKS IMMEDIATELY.
0	Navanja sva tlas sva lasasia s sva	
2.	Never leave the gun hanging over	A catalyst leak in this situation would certainly
	or lying inside the mold.	damage the part, possibly the mold, and may cause
		a fire.
3.	Inspect resin and catalyst hoses	Replace if wear or weakness is evident or
	daily for wear or stress at the entry	suspected.
	and exits of the boom sections and	·
	at the hose and fittings.	
	<u></u>	
4.	Arrange the hoses and fiberglass	If allowed to rub, the hose will be cut through,
	roving guides so that the fiberglass	causing a hazardous leakage of material which
	strands DO NOT rub against any of	could increase the danger of fire. Also, the material

may spew onto personnel in the area.



Toxicity of Chemicals

- Magnum Venus Products recommends that you consult OSHA Sections 1910.94, 1910.106, 1910.107 and NFPA No.33, Chapter 14, and NFPA No.91.
- Contact your chemical supplier(s) and determine the toxicity of the various chemicals used as well as the best methods to prevent injury, irritation and danger to personnel.
- Also determine the best methods of first aid treatment for each chemical used in your plant.

Equipment Safety

Magnum Venus Products suggest that personal safety equipment such as EYE GOGGLES, GLOVES, EAR PROTECTION, and RESPIRATORS be worn when servicing or operating this equipment. Ear protection should be worn when operating a fiberglass chopper to protect against hearing loss since noise levels can be as high as 116 dB (decibels). This equipment should only be operated or serviced by technically trained personnel!



CAUTION

Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can cause serious injury by shooting liquid through the skin. NEVER LOOK DIRECTLY INTO THE GUN SPRAY TIP OR POINT THE GUN AT OR NEAR ANOTHER PERSON OR AN ANIMAL.



DANGER

Contaminated catalyst may cause fire or explosion. Before working on the catalyst pump or catalyst accumulator, wash hands and tools thoroughly. Be sure work area is free from dirt, grease, or resin. Clean catalyst system components with clean water daily.



DANGER

Eye, skin, and respiration hazard. The catalyst MEKP may cause blindness, skin irritation, or breathing difficulty. Keep hands away from face. Keep food and drink away from work area.

Treatment of Chemical Injuries



CAUTION

Refer to your catalyst manufacturer's safety information regarding the safe handling and storage of catalyst. Wear appropriate safety equipment as recommended.

Great care should be used in handling the chemicals (resins, catalyst and solvents) used in polyester systems. Such chemicals should be treated as if they hurt your skin and eyes and as if they are poison to your body. For this reason, Magnum Venus Products recommends the use of protective clothing and eye wear in using polyester systems. However, users should be prepared in the event of such an injury.



Precautions include:

- 1. Know precisely what chemicals you are using and obtain information from your chemical supplier on what to do in the event the chemical gets onto your skin or into the eyes, or if swallowed.
- 2. Keep this information together and easily available so that it may be used by those administering first aid or treating the injured person.
- 3. Be sure the information from your chemical supplier includes instructions on how to treat any toxic effects the chemicals have.



WARNING

Contact your doctor immediately in the event of an injury. If the product's MSDS includes first aid instructions, administer first aid immediately after contacting a doctor.

Fast treatment of the outer skin and eyes that contact chemicals generally includes immediate and thorough washing of the exposed skin and immediate and continuous flushing of the eyes with lots of clean water for at least 15 minutes or more. These general instructions of first aid treatment may be incorrect for some chemicals; you must know the chemicals and treatment before an accident occurs. Treatment for swallowing a chemical frequently depends upon the nature of the chemical.

Emergency Stop Procedure

In an emergency, follow these steps to stop a system:

1. The ball valve located where the air enters the power head of the resin pump, should be moved to the "OFF" or closed position.

Note The "open" or "on" position is when the ball valve handle is parallel (in line) with the ball valve body. The "closed" or "off" position is when the ball valve handle is perpendicular (across) the ball valve body.

- 2. Turn all system regulators to the "OFF" position (counter-clockwise) position.
- 3. Verify / secure the catalyst relief line, located on the catalyst relief valve.
- 4. Verify / secure the resin return line, located on the resin filter.
- 5. Place a container under the resin pump ball valve to catch ejected resin.
- 6. Locate the ball valve on the resin pump.
- 7. Rotate the ball valve 90 degrees to the "On" or open position.

Grounding

Grounding an object means providing an adequate path for the flow of the electrical charge from the object to the ground. An adequate path is one that permits charge to flow from the object fast enough that it will not accumulate to the extent that a spark can be formed. It is not possible to define exactly what will be an adequate path under all conditions since it depends on many variables. In any event, the grounding means should have the lowest possible electrical resistance.



Grounding straps should be installed on all loose conductive objects in the spraying area. This includes material containers and equipment. Magnum Venus Products recommends grounding straps be made of AWG No.18 stranded wire as a minimum and the larger wire be used where possible. NFPA Bulletin No77 states that the electrical resistance of such a leakage path should be 1 meg ohm (10⁶ ohms) or less.

CAUTION



Whenever flammable or combustible liquids are transferred from one container to another, or from one container to the equipment, both containers or container and equipment shall be effectively bonded and grounded to dissipate static electricity. For further information, see National Fire Protection Association (NFPA) 77, titled "Recommended Practice on Static Electrical". Refer especially to section 7-7 titled "Spray Application of Flammable and Combustible Materials".

Introduction

This manual provides information for the maintenance and simple repair of the MVP Patriot Powerhead. The following procedures are included:

- Step-by-step assembly and disassembly
- Parts information



Please read this manual carefully and retain for future reference. Follow the steps in the order given, otherwise you may damage the equipment or injure yourself.

Note

The Duo unit is also a heavy duty assembly.



WARNING

Before beginning any service work, release all fluid and air pressure from the system and remove the air lines from the motor. You do not need to completely remove the air motor from the system for service.

As you disassemble the equipment, lay out the components in the correct order and direction to assist with reassembly. Reassembly will require the use of removable thread lock compound, lithium grease, and SUPERLUBE O-ring lubricant. Reference the current parts drawing during repair to ensure you have a guide and the correct part numbers.

Requirements

You will need the following:


- Medium removable thread locking compound
- Brown grease
- Super O-ring lubricant (SUPERLUBE)
- ⁷/₁₆" socket wrench




- Hex wrench set
- 9/₁₆" wrench
- 12" adjustable wrench
- Flat head screwdriver
- Snap-ring pliers

Disassembling Valve Block


1. Remove the two hex head screws from the front of the muffler and remove the muffler from the side of the powerhead.




- 2. Remove the air line from the side of the valve block.
- 3. Remove the valve block from the side of the powerhead by removing the screws.
- 4. Remove the two end caps from the valve block.
- 5. Remove the pipe plug from the side of the lower valve block.
- 6. Rotate either the two valve pistons until the hole in the valve poppet aligns with the pipe plug port in the lower valve block.
- 7. Insert a hex wrench through the pipe plug port and into the hole in the valve poppet.
- 8. Unscrew the valve pistons while the hex wrench holds the poppet in place.









9. Using an open-end wrench, remove the two hex cap screws from the front of the lower valve block.



- 10. Twist and pull the upper valve block from the lower valve block.
- 11. Remove the valve rod assembly from the valve block.
- 12. Remove the two cap screws from each of the valve exhausts and pull the valve exhausts off the valve blocks.






13. Use a screwdriver to push the center riser on each diaphragm to one side then remove the diaphragm from each of the valve blocks.

Note Avoid scratching the valve blocks.





- 14. Remove each O-ring and replace with a new one, coating each new O-ring with brown grease.
- 15. Coat the diaphragm bore and both valve piston bores with brown grease.
- 16. Use a wire brush to clean the valve rod threads of any dry thread locking compound.


Reassembling Valve Block


Note


Replace all O-rings and seals you remove with new ones from the seal kit. Apply brown grease to all O-rings and seal areas before assembling.

- 1. Apply one to two drops of removable thread locking compound to the threads of the valve poppet and reassemble.
- 2. Push the valve piston all the way into the lower valve block.
- 3. Apply a small amount of removable thread locking compound to the threads on one end of the valve poppet and thread it into the


valve piston in the lower block while







- Apply a small amount of removable thread locking compound to the threads on the other end of the valve poppet.
- Apply some brown grease to the O-ring that goes on the upper valve block, then push the upper valve block into the lower valve block and over the valve poppet.
- Insert the hex wrench back through the side port and into the valve poppet and hold it in place, then tighten the other piston; do



9. Install the two hex bolts to hold the lower valve block to the upper valve block.



- 10. Use Teflon tape or pipe seal compound on the threads of the pipe plug and install it into the side port of the lower valve block.
- 11. Insert the diaphragms into the upper and lower valve blocks with the outside leading edge facing out, then push them all the way down into the valve block bore.
- 12. Install the valve exhausts onto the upper and lower valve blocks using socket head cap screws.
- 13. Install the valve end caps into the upper and lower valve blocks and lightly
- 14. Connect the air line on the side of the valve block.



Disassembling Air Cylinder

Note Refer to a current drawing for the powerhead you are working on to reference for part numbers.

1. Remove the E-ring or snap ring from the lower piston rod.



- 2. Lift the sleeve or sleeve clip and remove the two connectors or half-shells.
- 3. Remove the upper hex nuts from the tie rods and pull the upper end cap off the cylinder and upper piston rod.


Note You can remove the unit from the system for repair or leave it mounted in place.

- 4. Slide the piston assembly up from the lower end cap.
- 5. Remove the snap ring from the upper bushing using snap-ring pliers.
- 6. Push the upper bushing out of the upper end cap.



- 7. Remove the snap ring from the lower bushing and push the bushing out of the lower end cap.
- 8. Replace all O-rings and coat the new ones with brown grease.
- 9. Coat the inside of the cylinder, piston rods, and piston rod bushing with brown grease.









Rebuilding Pilot Valve

Note The two pilot valves in the upper and lower end caps are the same.

- 1. Remove the inlet spring housing from the upper end cap.
- 2. Remove the spring with the inlet rod.
- 3. Turn the end cap over and a small spring will fall out.
- 4. Replace the O-ring on the inlet spring housing and the O-ring on the inlet rod.
- 5. Coat the new O-rings and springs with a light coat of SUPERLUBE grease.
- 6. Set the larger spring into the inlet spring housing with the inlet rod facing up.
- 7. Screw the inlet spring housing into the upper end cap.

Note Do not install the smaller spring at this time; it will be installed from the bottom.


8. Remove the stem seal from the bottom of the upper end cap.



- 9. Remove the valve stem and seal guide with the spring.
- 10. Replace the O-ring on the stem seal and coat with SUPERLUBE grease.
- 11. Drop the small spring into the stem seal bore; it should center itself on the inlet rod.
- 12. Insert the spring with the seal guide into the end cap.
- 13. Set the small end of the seal guide onto the spring.
- 14. Set a new O-ring on top of the seal guide.
- 15. Screw the stem seal with the valve stem into the upper end cap.
- 16. Repeat the pilot valve rebuild on the lower end cap.

Reassembling Air Cylinder

- 1. Apply a thin coat of brown grease to the inner bore of the lower end cap and install the lower bushing.
- 2. Install snap ring to secure the lower bushing in place.
- 3. Apply a thin coat of brown grease to the inner bore of the upper end cap and install the upper bushing.
- 4. Install the snap ring to secure the upper bushing in place.
- 5. Insert the lower piston rod through the piston rod bushing of the lower end cap.






- 6. Slide the cylinder over the piston and down onto the lower end cap O-ring.
- 7. Set the upper end cap onto the cylinder with the valve block flats facing the same direction.
- 8. Screw the hex nuts onto the tie rods and snug.

Note

Tightening sequence should always be the across method. Tighten the first nut or bolt a little more than hand tight, then go to the nut or bolt directly opposite and tighten. Repeat this through a 3-step (minimum) torque procedure. For the tie rod nuts, first torque all to 5 - 7 ft/lbs, then to 15 ft/lbs, then to 23 ft/lbs.

- 9. Install the connectors or half shells, sleeve (sleeve clip), and E-ring onto the piston rod.
- 10. Reinstall the valve block onto the side of the cylinder.
- 11. Connect the pilot air hose and regulated air hose.
- 12. Install the muffler.



Parts Drawings


The following illustrated breakdowns are included for reference when you are working on the equipment. Refer to the correct drawing for the specific powerhead you are servicing to make sure you have the correct part numbers and to assist with the orientation of parts.

Parts Drawings					
Part Number	Description				
PAT-PH-3250	3.25" Patriot Powerhead Assembly				
PAT-PH-3250-INV	3.25" Innovator Powerhead Assembly				
PAT-PH-3250-SK	Powerhead Seal Kit				
PAT-PH-4250	4.25" Patriot Powerhead Assembly				
PAT-PH-4250-SK	4.25" Powerhead Seal Kit				
PAT-PH-SB	Shift Block Assembly				
PAT-PH-5000	5" Patriot Powerhead Assembly				
PAT-PH-5000-CA	5" Patriot Powerhead Assembly - Multi-Color				
PAT-PH-5000-SSB	5" Patriot Powerhead Assembly - Patriot SSB				
PAT-PH-5000-INV	5" Patriot Powerhead Assembly - Innovators				
PAT-PH-5000-XD	5" Patriot Powerhead Assembly - Heavy Duty Drive				
PAT-PH-5000-SK	5" Patriot Powerhead Seal Kit				
PAT-PH-7000	7" Patriot Powerhead Assembly				
PAT-PH-7000-CA	7" Patriot Powerhead – Multi-Color				
PAT-PH-7000-D	7" Patriot Powerhead – Duo Unit				
PAT-PH-7000-HD	7" Patriot Powerhead - Heavy Duty				



Parts Drawings				
Part Number	Description			
PAT-PH-7000-P	7" Patriot Powerhead - Putty			
PAT-PH-7000-CA-SK	Seal Kit – Multi-Color Powerhead			
PAT-PH-7000-HD-SK	Seal Kit – Heavy Duty Powerhead			
PAT-PH-7000-SK	Seal Kit – 7" Patriot Powerhead			
PAT-PH-10000	10" Patriot Powerhead Assembly			
PAT-PH-10000-SK	Seal Kit – 10" Patriot Powerhead			
PAT-GRD-1000	CE Norms Guard			
PAT-GRD-1100	CE Norms Guard			
PAT-PH-SB-XL	Shift Block Assembly			






3-1/4 PATRIOT POWER HEAD

PAT-PH-3250







3-1/4" PATRIOT POWER HEAD

PAT-PH-3250



TEM	PART NUMBER	OTY	DESCRIPTION
1	PAT-PH-3204	1	LOWER END CAP
2	MPH-2533	2	COMPRESSION SPRING
3	MPH-2540	2	INLET ROD- PILOT VALVE
4	O-B-012	6	O-RING
5	MPH-2528	2	SPRING
6	MPH-2526	2	SPRING
7	O-U-006	2	O-RING
8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
9	O-B-008	4	O-RING
10	MPH-2513	2	VALVE STEM- PILOT VALVE
11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
12	MPH-2541	2	SPRING HOUSING- PILOT VALVE
13	PAT-PH-3203	1	CYLINDER - Ø3-1/4x 2" STROKE
14	O-B-152	2	O-RING
15	PAT-PH-3206	3	TIE ROD
16	PAT-PH-3212	1	UPPER END CAP
17	VPH-4254	2	BUSHING- 7/8 DIA. PISTON ROD
18	O-B-118	2	O-RING
19	O-B-121	2	O-RING
20	MPH-3261	2	SNAP RING - EXTERNAL
21	F-HN-05F	6	HEX NUT
22	PAT-PH-5009	1	LOWER ROD
23	PAT-PH-5008	i	UPPER ROD ASSY
24	MPH-3251	1	PISTON - 3-1/4" POWER HEAD
25	PAT-PH-5011	4	TIE ROO
26	F-HB-06C-24-GR8	4	HEX BOLT
27	F-HB-05C-12	2	HEX BOLT
28	PAT-PH-3201	1	UPPER VALVE BLOCK
29	PAT-PH-3202	1	LOWER VALVE BLOCK
30	PAT-PH-3205	1	VALVE ROD POPPET
31	MPH-2517	2	VALVE PISTON
32	O-U-204-90	2	O-RING
33	O-B-116	2	O-RING
34	O-D-010-90	2	O-RING
35	MPH-3262	2	PISTON STOP
36	O-B-020	3	O-RING
37	F-HB-04C-08	2	HEX BOLT
38	O-B-013	2	O-RING
40	F-SS-832-02-SS	4	SET SCREW
41	F-CS-04C-32-SS	4	SOCKET HEAD CAP SCREW
42	MPH-2529	2	DIAPHRAGM
43	MPH-2522	2	VALVE EXHAUST PORT
44	F-CS-1024-06-SS	4	CAP SCREW
45	MPH-2521	2	VALVE END CAP
46	O-B-019	2	O-RING
47	PF-AP-02-SS	2	PIPE PLUG
48	O-B-404	2	O-RING
49	O-B-336	1	O-RING
50	MPH-2539	1	MALE ELBOW
51	MPH-2538	1	MALE POLY TEE FITTING
52	MS-2052-1	.40ft	POLY TUBE
53	PAT-PH-3210-01	1	MUFFLER ASSY2" STROKE
54	MPH-2546-01	1	VALVE STEM ASSY
55	PF-ST-02-BR	1	TEE FITTING
56	MPH-2545	1	SEAL
57	F-SW-06	4	LOCK WASHER
58	F-HB-04C-56-SS	2	HEX BOLT
59	F-SW-04-SS	2	LOCK WASHER
60	PF-HN-06-08S	1	HOSE ADAPTER
61	F-FW-04	2	FLAT WASHER

*ASTERISKS DENOTE PARTS INCLUDED IN PAT-PH-3250-SK SEAL KIT

OPTIONAL PARTS AND ASSEMBLIES

 PART No.
 QTY.
 DESCRIPTION

 MPH-2542
 1
 RESET PUTTON ASSY


 PAT-PH-SB
 1
 SHIFT BLOCK ASSY

MAGNUM VENUS PLASTECH

3-1/4" PATRIOT POWER HEAD

PAT-PH-3250






3-1/4 PATRIOT POWER HEAD

PAT-PH-3250-INV





3-1/4" PATRIOT POWER HEAD

PAT-PH-3250-INV



ITEM	PART NUMBER	OTY	DESCRIPTION
1	PAT-PH-3204	1	LOWER END CAP
2	MPH-2533	2	COMPRESSION SPRING
3	MPH-2540	2	INLET ROD- PILOT VALVE
4	O-B-012	6	O-RING
5	MPH-2528	2	SPRING
6	MPH-2526	2	SPRING
7	O-U-006	2	O-RING
8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
9	O-B-008	4	O-RING
10	MPH-2513	2	VALVE STEM- PILOT VALVE
11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
12	MPH-2541	2	SPRING HOUSING- PILOT VALVE
13	PAT-PH-3203	1	CYLINDER - Ø3-1/4x 2" STROKE
14	O-B-152	2	O-RING
15	PAT-PH-3206	3	TIE ROD
16	PAT-PH-3212	1	UPPER END CAP
17	VPH-4254	2	BUSHING- 7/8 DIA. PISTON ROD
18	O-B-118	2	O-RING
19	O-B-121	2	O-RING
20	MPH-3261	2	SNAP RING - EXTERNAL
21	F-HN-05F	6	HEX NUT
22	PAT-PH-5009	1	LOWER ROD
23	PAT-PH-5008	1	UPPER ROD ASSY
24	MPH-3251	1	PISTON - 3-1/4" POWER HEAD
25	PAT-PH-5011	4	TIE ROD
26	F-HB-06C-24-GR8	4	HEX BOLT
27	F-HB-05C-12	2	HEX BOLT
28	PAT-PH-3201	1	UPPER VALVE BLOCK
29	PAT-PH-3202	1	LOWER VALVE BLOCK
30	PAT-PH-3205	1	VALVE ROD POPPET
31	MPH-2517	2	VALVE PISTON
32	O-U-204-90	2	O-RING
33	O-B-116	2	O-RING
34	O-D-010-90	2	O-RING
35	MPH-3262	2	PISTON STOP
36	O-B-020	3	O-RING
37	F-HB-04C-08	2	HEX BOLT
38	O-B-013	2	O-RING
40	F-SS-832-02-SS	4	SET SCREW
41	F-CS-04C-32-5S	4	SOCKET HEAD CAP SCREW
42	MPH-2529	2	DIAPHRAGM
43	MPH-2522	2	VALVE EXHAUST PORT
44 4E	F-CS-1024-06-SS	4	CAP SCREW
45	MPH-2521	2	VALVE END CAP
46	O-B-019	2	O-RING
47	PTF90-02-4MM	1	MALE ELBOW
48	O-B-404	2	O-RING
49	O-B-336	1	O-RING
50	MPH-2539	1	MALE ELBOW
	MPH-2538	.40ft	MALE POLY TEE FITTING
52	MS-2052-1		POLY TUBE
53	PAT-PH-3210-01	1	MUFFLER ASSY2" STROKE
54 55	MPH-2546-01	1 1	VALVE STEM ASSY TEE FITTING
56	PF-ST-02-BR		
57	MPH-2545	1 4	SEAL NOCK WASHED
58	F-SW-06	2	LOCK WASHER HEX BOLT
59	F-HB-04C-56-SS F-SW-04-SS	2	LOCK WASHER
60	PTF90-06-05	1	MALE ELBOW
61	F-FW-04	2	FLAT WASHER
62	PTF-02-4MM	1	MALE CONNECTOR

* ASTERISKS DENOTE PARTS INCLUDED IN PAT-PH-3250-SK SEAL KIT

OPTIONAL PARTS AND ASSEMBLIES

 PART No.
 QTY.
 DESCRIPTION

 MPH-2542
 1
 RESET PUTTON ASSY

 PAT-PH-SB
 1
 SHIFT BLOCK ASSY


MAGNUM VENUS PLASTECH

3-1/4" PATRIOT POWER HEAD


PAT-PH-3250-INV



PAT-PH-3250-SK SEAL KIT 3-1/4" AIR MOTOR








4-1/4" PATRIOT POWER HEAD

PAT-PH-4250





4-1/4" PATRIOT POWER HEAD

PAT-PH-4250



ITEM	PART NUMBER	QTY	DESCRIPTION
1	MPH-2533	2	COMPRESSION SPRING
2	MPH-2540	2	INLET ROD- PILOT VALVE
3	O-B-012	6	O-RING
4	MPH-2528	2	SPRING
5	MPH-2526	2	SPRING
6	O-U-006	2	O-RING
7	MPH-2512	2	SEAL GUIDE- PILOT VALVE
8	O-B-008	4	O-RING
9	MPH-2513	2	VALVE STEM- PILOT VALVE
10	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
11	MPH-2541	2	SPRING HOUSING- PILOT VALVE
12	PAT-PH-3206	3	TIE ROD - 2" STROKE P.H.
13	VPH-4254	2	BUSHING- 7/8 DIA, PISTON ROD
14	O-B-118	2	O-RING
15	O-B-121	2	O-RING
16	MPH-3261	2	SNAP RING - EXTERNAL
17	F-HN-05F	6	HEX NUT
18	PAT-PH-5009	1	LOWER ROD
19	PAT-PH-5008	1	UPPER ROD ASSY
20	PAT-PH-5011	4	TIE ROD
21	F-HB-06C-24-GR8	4	HEX BOLT
22	F-HB-05C-12	2	HEX BOLT
23	PAT-PH-3201	1	UPPER VALVE BLOCK
24	PAT-PH-3202	1	LOWER VALVE BLOCK
25	PAT-PH-3205	1	VALVE ROD POPPET
26	MPH-2517	2	VALVE PISTON
27	O-U-204-90	2	O-RING
28	O-B-116	2	O-RING
29	O-D-010-90	2	O-RING
30	MPH-3262	2	PISTON STOP
31	O-B-020	3	O-RING
32	F-HB-04C-08	2	HEX BOLT
33	O-B-013	2	O-RING
35	F-SS-832-02-SS	4	SET SCREW
36	F-CS-04C-32-SS	4	SOCKET HEAD CAP SCREW
37	MPH-2529	2	DIAPHRAGM
38	MPH-2522	2	VALVE EXHAUST PORT
39	F-CS-1024-06-SS	4	CAP SCREW
40	MPH-2521	2	VALVE END CAP
41	O-B-019	2	O-RING
42	PF-AP-02-SS	2	PIPE PLUG
43	MPH-2539	1	MALE ELBOW
44	MPH-2538	1	MALE POLY TEE FITTING
45	MS-2052-1	.400	POLY TUBE
46	PAT-PH-3210-01	1	MUFFLER ASSY, -2" STROKE
47	VPH-4251	1	PISTON
48	0-B-344	1	O-RING
49	PAT-PH-4204	1	LOWER END CAP
50	PAT-PH-4212	1	UPPER END CAP
51	PAT-PH-4203	1	CYLINDER CAP
52	O-B-409	2	O-RING
53	O-B-156	2	O-RING
		1	
55 56	PF-HN-06-08S F-HB-04C-56-SS	2	HOSE ADAPTER HEX BOLT
		_	
57	F-SW-04-SS PF-ST-02-BR	2	1/4" LOCK WASHER
58		1	TEE FITTING
100	MPH-2546-01	1	RESET STEM ASSEMBLY
59 60	MPH-2545	1	SEAL

OPTIONAL PARTS AND ASSEMBLIES

 PART No.
 QTY.
 DESCRIPTION

 MPH-2542
 1
 RESET PUTTON ASSY

 PAT-PH-SB
 1
 SHIFT BLOCK ASSY

* ASTERISKS DENOTE PARTS INCLUDED IN PAT-PH-4250-SK SEAL KIT

MAGNUM VENUS PLASTECH


4-1/4" PATRIOT POWER HEAD

PAT-PH-4250



PAT-PH-4250-SK SEAL KIT 4-1/4" AIR MOTOR 2 PCS 0-U-006 0-RING 4 PCS 0-B-008 0-RING 6 PCS 0-B-012 O-RING 2 PCS 0-B-121 O-RING 2 PCS 0-B-013 0-RING 2 PCS 0-B-409 O-RING 2 PCS 0-B-019 0-RING 2 PCS O-B-156 O-RING 2 PCS MPH-2529 1/4" DIAPHRAGM 2 PCS 0-B-116 0-RING 3 PCS 0-B-020 O-RING 2 PCS 0-B-118 O-RING 2 PCS 0-U-204-90 O-RING 1 PC 0-B-344 O-RING 2 PCS 0-D-010-90 0-RING





SHIFT BLOCK ASSEMBLY - 3.25" POWER HEAD	PAT-PH-SB	
REV:B	SHEET 1 / 2	10/3/2012



Parts List				
ITEM	PART NUMBER	QTY	DESCRIPTION	
1	PAT-PH-3201	1	UPPER VALVE BLOCK	
2	PAT-PH-3202	1	LOWER VALVE BLOCK	
3	PAT-PH-3205	1	VALVE ROD POPPET	
4	MPH-2517	2	VALVE PISTON	
5	O-U-204-90	2	O-RING	
6	O-D-010-90	2	O-RING	
7	O-B-116	2	O-RING	
8	MPH-3262	2	PISTON STOP	
9	MPH-2521	2	VALVE END CAP	
10	O-B-019	2	O-RING	
11	PF-AP-02-SS	2	PIPE PLUG	
12	F-SS-832-02-SS	4	SS SET SCREW	
13	PF-ST-02-BR	1	TEE FITTING	
14	MPH-2545	1	SEAL	
15	MPH-2546-01	1	RESET STEM ASSEMBLY	
16	MPH-2529	2	DIAPHRAGM	
17	MPH-2522	2	VALVE EXHAUST PORT	
18	O-B-020	3	O-RING	
19	F-CS-1024-08	4	CAP SCREW	
20	F-HB-04C-08	2	HEX BOLT	
21	O-B-012	2	O-RING	
22	O-B-013	2	O-RING	
23	O-B-008	2	O-RING	
24	F-CS-04C-32-SS	4	SOCKET HEAD CAP SCREW	
25	PF-HN-06-08S	1	HOSE ADAPTER	
26	MPH-2539	1	MALE ELBOW	
27	MPH-2538	1	MALE POLY TEE FITTING	
28	MS-2052-1	.313 FT	POLY TUBE	

OPTIONAL PARTS AND ASSEMBLIES

ITEM PART No. QTY DESCRIPTION

30 MPH-2542 1 RESET BUTTON ASSEMBLY

REPAIR KIT


PART No. DESCRIPTION
* PAT-PH-SB-SK SEAL KIT

MAGNUM VENUS PLASTECH

SHIFT BLOCK ASSEMBLY - 3.25" POWER HEAD PAT-PH-SB


REV: B SHEET 2 / 2 10/3/2012





5" PATRIOT POWER HEAD	PAT-PH-5000		
REV:B 09/16/13	SHEET 1 / 3	10/22/2009	





5" PATRIOT POWER HEAD		PAT-PH-5000
REV:B 09/16/13	SHEET 2 / 3	10/22/2009



TEM	PART NUMBER	OTY	Parts List DESCRIPTION
1	MPH-2541	2	SPRING HOUSING- PILOT VALVE
2	O-B-012	6	O-RING
3	MPH-2533	2	COMPRESSION SPRING
4	MPH-2540	2	INLET ROD- PILOT VALVE
5	O-U-006	2	O-RING
6	MPH-2526	2	SPRING
7	MPH-2528	2	SPRING
_			
8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
9	O-B-008		O-RING
10	MPH-2513	2	VALVE STEM- PILOT VALVE
11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
12	O-B-159	2	O-RING
13	PAT-PH-5002	1	LOWER VALVE BLOCK
14	O-B-014	4	O-RING
16	O-B-011	2	O-RING
17	F-SS-832-02-SS	4	SS SET SCREW
18	PAT-PH-5003	1	CYLINDER - Ø5"
19	MPH-5006	1	PISTON - Ø5"
20	O-B-425	1	O-RING
21	O-B-415	2	O-RING
22	PAT-PH-5006	4	TIE ROD - 2" STROKE
23	PAT-PH-5012	1	UPPER END CAP - 5"
24	PAT-PH-5001	1	UPPER VALVE BLOCK
25	O-B-024	1	O-RING
26	F-HN-06F	8	HEX NUT
27	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
28	MPH-2517	2	VALVE PISTON
29	O-U-206-90	2	O-RING
30	O-D-010-90	2	O-RING
31	O-B-116	2	O-RING
32	MPH-3262	2	PISTON STOP
33	MPH-2521	2	VALVE END CAP
34	O-B-019	2	O-RING
35		-	
	7205-2-26	1	EXTERNAL SNAP RING
36	MPH-5010	2	DIAPHRAGM
37	O-B-026	2	O-RING
38	F-CS-04C-40-SS	4	SOCKET HEAD CAP SCREW
39	F-CS-04C-08-SS	4	CAP SCREW
40	F-HB-04C-08	2	HEX BOLT
41	PF-AP-02-SS	2	PIPE PLUG
42	PF-HP-08	1	HEX PLUG
43	MPH-2539	1	MALE ELBOW
44	MPH-2538	1	MALE POLY TEE FITTING
45	MS-2052-1	.313 FT	POLY TUBE
46	MPH-2546-01	1	RESET STEM ASSEMBLY
47	MPH-2545	1	SEAL
48	PF-ST-02-BR	1	TEE FITTING
49	MPH-5009	2	EXHAUST PORT
50	PAT-PH-5004	1	LOWER END CAP - 5" POWER HEAD
51	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
52	O-B-121	1	O-RING
53	O-B-118	2	O-RING
54	MPH-3261	1	SNAP RING - EXTERNAL
55	PAT-PH-5007	1	UPPER BUSHING
56	O-B-127	1	O-RING
57	PAT-PH-5009	1	LOWER ROD
		_	
58	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
59	PAT-PH-5011	4	TIE ROD
60	F-HB-06C-24-GR8	4	HEX BOLT
	F-HB-06C-12	2	HEX BOLT
	PAT-PH-5008	1	UPPER ROD ASSY
	PF-HN-08-08S	1	HOSE ADAPTER
_	F-SW-06	4	LOCK WASHER
65	F-SW-04-SS	2	LOCK WASHER
66	F-HB-04C-56-SS	2	HEX BOLT
67	F-FW-04	2	FLAT WASHER

 OPTIONAL PARTS AND ASSEMBLIES

 PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS PART No. DESCRIPTION PAT-PH-5000-SK SEAL KIT

* ASTERISKS DENOTE PARTS IN SEAL KIT


MAGNUM VENUS PLASTECH






10/22/2009

REV: B 09/16/13 SHEET 3 / 3



5" PATRIOT POWER HEAD	PAT-PH-5000-CA		
REV:C 09/16/13	SHEET 1 / 3	1/13/2010	





5" PATRIOT POWER HEAD	PAT	-PH-5000-CA
DEV:C 09/16/13	SHEET 7 / 3	1/13/2010



ITEM	PART NUMBER	QTY	DESCRIPTION
1	MPH-2541	2	SPRING HOUSING- PILOT VALVE
2	O-8-012	.6	O-RING
3	MPH-2533	2	COMPRESSION SPRING
4	MPH-2540	2	INLET ROD- PILOT VALVE
- 5	O-U-006	2	O-RING
- 6	MPH-2526	2	SPRING
7	MPH-2528	2	SPRING
8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
9	O-B-008	4	O-RING
10	MPH-2513	2	VALVE STEM- PILOT VALVE
11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
12	O-B-159	2	O-RING
13	PAT-PH-5002	1	LOWER VALVE BLOCK
14	O-B-014	4	O-RING
16	O-B-011	2	O-RING
17	F-SS-832-02-SS	4	SS SET SCREW
18	PAT-PH-5003	1	CYLINDER - Ø5*
19	MPH-5006	1	PISTON - Ø5*
20	O-8-425	1	O-RING
21	O-B-415	2	O-RING
22	PAT-PH-5006	4	TIE ROD - 2" STROKE
23	PAT-PH-5012	1	UPPER END CAP - 5"
24	PAT-PH-5001	1	UPPER VALVE BLOCK
25	O-B-024	1	O-RING
_			7.
26	F-HN-06F	8	HEX NUT
_	PAT-PH-5005		POPPET VALVE - 2" STROKE
28	MPH-2517	2	VALVE PISTON
29	O-U-206-90	2	O-RING
30	O-D-010-90	2	O-RING
31	O-B-116	2	O-RING
32	MPH-3262	2	PISTON STOP
33	MPH-2521	2	VALVE END CAP
34	O-B-019	2	O-RING
35	7205-2-26	1	EXTERNAL SNAP RING
36	MPH-5010	2	DIAPHRAGM
37	O-B-026	2	O-RING
38	F-CS-04C-40-55	4	SOCKET HEAD CAP SCREW
39	F-CS-04C-08-SS	4	CAP SCREW
40	F-HB-04C-08	2	HEX BOLT
41	PF-AP-02-SS	2	PIPE PLUG
42	PF-HP-08	1	HEX PLUG
43	MPH-2539	1	MALE ELBOW
44	MPH-2538	1	MALE POLY TEE FITTING
45	MS-2052-1	.50 FT	POLY TUBE
46	MPH-2546-01	1	RESET STEM ASSEMBLY
47	MPH-2545	1	SEAL
48	PF-ST-02-BR	1	TEE FITTING
49	MPH-5009	2	EXHAUST PORT
50	PAT-PH-5004	1	LOWER END CAP - 5" POWER HEAD
51	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
52	O-8-121	1	O-RING
53	O-B-118	2	O-RING
54	MPH-3261	1	SNAP RING - EXTERNAL
55	PAT-PH-5007	1	UPPER BUSHING
56	O-B-127	1	O-RING
57	PAT-PH-5009	1	LOWER ROD
58	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
	PAT-PH-5011	4	TIE ROD
60	F-HB-06C-24-GR8	4	HEX BOLT
61	F-HB-06C-12	2	HEX BOLT
62	PAT-PH-5008	1	UPPER ROD ASSY
63	PF-ME-08	1	MALE ELBOW
64	F-SW-06	4	LOCK WASHER
65	F-SW-04-55	2	LOCK WASHER
66	F-HB-04C-56-SS	2	HEX BOLT
	F-FW-04	2	FLAT WASHER
68	RC-1007-MOD	1	SHUT OFF VALVE

OPTIONAL PARTS AND ASSEMBLIES
PARTS LIST
PART No. QTY DESCRIPTION
WHH-1542 I RESET BUTTON ASSY
WAT-PH-SB-KL I SHEFT BLOCK ASSY


REPAIR KITS
PART No. DESCRIPTION
PAT-PH-5000-5K SEAL KIT

* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH

5" PATRIOT POWER HEAD PAT-PH-5000-CA REV:C 09/16/13 SHEET 3 / 3 1/13/2010






5" PATRIOT POWER HEAD

PAT-PH-5000-SSB





5" PATRIOT POWER HEAD

PAT-PH-5000-SSB

REV:A 05/27/11



-	ITEM	PART NUMBER	QTY	Parts List DESCRIPTION
	1	MPH-2541	2	SPRING HOUSING- PILOT VALVE
	2	O-B-012	6	O-RING
	3	MPH-2533	2	COMPRESSION SPRING
-	4	MPH-2540	2	INLET ROD- PILOT VALVE
	5	O-U-006	2	O-RING
3	6	MPH-2526	2	SPRING
-5.5	7	MPH-2528	2	SPRING
	8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
-	9	O-B-008	4	O-RING
	10	MPH-2513	2	VALVE STEM- PILOT VALVE
	11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
Ť	12	O-B-159	2	O-RING
ŕ	13	PAT-PH-5002	1	LOWER VALVE BLOCK
	14	O-B-014	4	O-RING
	16	O-B-011	2	O-RING
ì	17	F-SS-832-02-SS	4	SET SCREW
	18	PAT-PH-5003	1	CYLINDER - Ø5"
	20	O-B-425	1	O-RING
	21	O-B-425	2	O-RING
	22	PAT-PH-5006	4	TIE ROD - 2" STROKE
3	23	PAT-PH-5012	1	UPPER END CAP - 5"
	24	PAT-PH-5012	1	UPPER VALVE BLOCK
	25	O-B-024	1	O-RING
	26	F-HN-06F	8	HEX NUT
	27	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
	28	MPH-2517	2	VALVE PISTON
	29	THE THIRD CONTRACTOR CO.	2	
		O-U-206-90		O-RING
8	30	O-D-010-90	2	O-RING
3	31	O-B-116	2	O-RING
	32	MPH-3262	2	PISTON STOP
	33	MPH-2521	2	VALVE END CAP
	34	O-B-019	2	O-RING
	35	7205-2-26	1	EXTERNAL SNAP RING
	36	MPH-5010	2	DIAPHRAGM
	37	O-B-026	2	O-RING
	38	F-CS-04C-40-SS	4	CAP SCREW
	39	F-CS-04C-08-SS	4	CAP SCREW
	40	F-HB-04C-08	2	HEX BOLT
	42	PF-HP-08	1	HEX PLUG
	43	PTF90-02-4MM	3	MALE ELBOW
	44	06559	1	MALE ELBOW
	45	PTF-02-4MM	1	MALE CONNECTOR
Ĺ	46	MPH-2546-01	1	RESET STEM ASSEMBLY
	47	MPH-2545	1	SEAL
	48	PF-ST-02-BR	1	TEE FITTING
Ļ	49	MPH-5009	2	EXHAUST PORT
	50	PAT-PH-5004	1	LOWER END CAP - 5" POWER HEAD
	51	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
	52	O-B-121	1	O-RING
L	53	O-B-118	2	O-RING
	54	MPH-3261	1	SNAP RING - EXTERNAL
	55	PAT-PH-5007	1	UPPER BUSHING
	56	O-B-127	1	O-RING
	57	PAT-PH-5009	1	LOWER ROD
_	58	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
	59	PAT-PH-5011	4	TIE ROD
3	60	F-HB-06C-24-GR8	4	HEX BOLT
	61	F-HB-06C-12	2	HEX BOLT
j	62	PAT-PH-5008	1	UPPER ROD ASSY
Ī	64	F-SW-06	4	SPLIT WASHER
ì	65	MPH-5006-MAG	1	PISTON WITH MAGNET
	67	F-SW-04-SS	2	LOCK WASHER
î	68	F-HB-04C-56-SS	2	HEX BOLT
_	69	F-FW-04	2	FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES

PART No. QTY. DESCIPTION MPH-2542 1 RESET BUTTON ASSY REPAIR KITS

PAT-PH-5000-SK

SEAL KIT


* DENOTES COMPONENTS INCLUDED IN SEAL KIT

MAGNUM VENUS PLASTECH

5" PATRIOT POWER HEAD


PAT-PH-5000-SSB





5" PATRIOT POWER HEAD	PAT-PH-5000-INV	
REV:A 08/11/2016	SHEET 1 / 3	10/22/2009





5" PATRIOT POWER HEAD	PAT	-PH-5000-INV
DEV: A 08/11/2016	SHEET 2 / 3	10/22/2009



-	BANK FORTHER	Parts	
ITEM	PART NUMBER	QTY	DESCRIPTION
1	MPH-2541	2	SPRING HOUSING- PILOT VALVE
2	O-B-012	- 6	O-RING
3	MPH-2533	2	COMPRESSION SPRING
4	MPH-2540	2	INLET ROD- PILOT VALVE
5	O-U-006	2	D-RING
6	MPH-2526	2	SPRING
7	MPH-2528	2	SPRING
8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
9	O-B-008	4	O-RING
10	MPH-2513	2	VALVE STEM- PILOT VALVE
11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
12	O-B-159	2	O-RING
13	PAT-PH-5002	1	LOWER VALVE BLOCK
14	O-B-014	4	O-RING
16	O-B-011	2	O-RING
17	F-SS-832-02-SS	4	SS SET SCREW
18	PAT-PH-5003	1	CYLINDER - Ø5*
19		1	
	MPH-5006	_	PISTON - Ø5"
20	O-B-425	1	O-RING
21	O-B-415	2	O-RING
22	PAT-PH-5006	4	TIE ROD - 2" STROKE
23	PAT-PH-S012	1	UPPER END CAP - 5*
24	PAT-PH-5001	1	UPPER VALVE BLOCK
25	O-B-024	1	O-RING
26	F-HN-06F	8	HEX NUT
27	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
28	MPH-2517	2	VALVE PISTON
29	O-U-206-90	2	O-RING
30	O-D-010-90	2	O-RING
31	O-B-116	2	O-RING
32	MPH-3262	2	PISTON STOP
33	MPH-2521	2	VALVE END CAP
34	O-B-019	2	D-RING
35	7205-2-26	1	EXTERNAL SNAP RING
36	MPH-5010	2	DIAPHRAGM
37	O-B-026	2	O-RING
38	F-CS-04C-40	4	CAP SCREW
39	F-CS-04C-08-SS	4	SOCKET HEAD CAP SCREW
40	F-HB-04C-08	2	HEX BOLT
41	PTF90-02-4MM	1	MALE ELBOW
42	PF-HP-08	1	HEX PLUG
43	MPH-2539	_	MALE ELBOW
44	MPH-2538	1	MALE POLY TEE FITTING
45	MS-2052-1	.313 FT	POLY TUBE
46	MPH-2546-01	1	RESET STEM ASSEMBLY
47	MPH-2545	1	SEAL
48	PF-ST-02-BR	1	TEE FITTING
49	MPH-5009	2	EXHAUST PORT
50	PAT-PH-5004	1	LOWER END CAP - 5" POWER HEAD
51	VPH-4254	1	BUSHING- 7/8 DIA, PISTON ROD
52	O-B-121	1	O-RING
53	O-B-118	2	O-RING
54	MPH-3261	1	SNAP RING - EXTERNAL
55	PAT-PH-5007	1	UPPER BUSHING
56	O-B-127	1	O-RING
57	PAT-PH-5009	1	LOWER ROD
58	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
59	PAT-PH-5011	4	TIE ROD
60	F-HB-06C-24-GR8	4	HEX BOLT
61	F-HB-06C-12	2	HEX BOLT
62	PAT-PH-5008	1	UPPER ROD ASSY
63	PTF90-06-05	1	MALE ELBOW
-		-	
64	F-SW-06	4	LOCK WASHER
65	F-SW-04-SS	2	LOCK WASHER
66	F-HB-04C-56-SS	2	HEX BOLT
67	F-FW-04	2	FLAT WASHER
68	PTF-02-4MM	1	MALE CONNECTOR
	PF-RB-08-06	1	BUSHING FITTING

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS

PART No. DESCRIPTION PAT-PH-5000-SK SEAL KIT


* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH

5" PATRIOT POWER HEAD PAT-PH-5000-INV


REV: A 08/11/2016 SHEET 3 / 3 10/22/2009





5" PATRIOT POWER HEAD	PAT-PH-5000-XD	
REV:	SHEET 1 / 3	2/20/2015





5" PATRIOT POWER HEAD	PAT-PH-5000-XD		
DE//·	SHFFT 2 / 3	2/20/2015	



1			Part	s List
	ITEM	PART NUMBER	QTY	DESCRIPTION
	1	MPH-2541	2	SPRING HOUSING- PILOT VALVE
c _	2	O-B-012	6	O-RING
	3	MPH-2533	2	COMPRESSION SPRING
Œ	4	MPH-2540	2	INLET ROD- PILOT VALVE
c	5	O-U-006	2	O-RING
	6	MPH-2526	2	SPRING
Œ	7	MPH-2528	2	SPRING
	8	MPH-2512	2	SEAL GUIDE- PILOT VALVE
	9	O-B-008	4	O-RING
Г	10	MPH-2513	2	VALVE STEM- PILOT VALVE
	11	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
:	12	O-B-159	2	O-RING
	13	PAT-PH-5002	1	LOWER VALVE BLOCK
	14	O-B-014	4	O-RING
:	16	O-B-011	2	O-RING
	17	F-SS-832-02-SS	4	SS SET SCREW
	18	PAT-PH-5003	1	CYLINDER - Ø5"
	19	MPH-5006	1	PISTON - Ø5"
:	20	O-B-425	1	O-RING
-	21	O-B-415	2	O-RING
	22	PAT-PH-5006	4	TIE ROD - 2" STROKE
	23	PAT-PH-5012	1	UPPER END CAP - 5"
	24	PAT-PH-5001	1	UPPER VALVE BLOCK
	25	O-B-024	1	O-RING
1	26	F-HN-06F	8	HEX NUT
	27	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
	28	MPH-2517	2	VALVE PISTON
	29	O-U-206-90	2	O-RING
-	30	O-D-010-90	2	O-RING
-	31	O-B-116	2	O-RING
-	32	MPH-3262	2	PISTON STOP
	33	MPH-2521	2	VALVE END CAP
	34	O-B-019	2	O-RING
-	35	7205-2-26	1	EXTERNAL SNAP RING
	36	MPH-5010	2	DIAPHRAGM
-	37	O-B-026	2	O-RING
	38	F-CS-04C-40-SS	4	SOCKET HEAD CAP SCREW
-	39	F-CS-04C-08-SS	4	SOCKET HEAD CAP SCREW
	40	F-HB-04C-08	2	HEX BOLT
F	41	PF-AP-02-SS	2	PIPE PLUG
1	42	PF-HP-08	1	HEX PLUG
di.	43	MPH-2539	1	MALE ELBOW
-	44	MPH-2539	1	MALE POLY TEE FITTING
-	45	MS-2052-1	_	POLY TUBE
-	46	MPH-2546-01	1	RESET STEM ASSEMBLY
-	47		-	
	48	MPH-2545	1	SEAL TEE FITTING
-		PF-ST-02-BR		
L	50	MPH-5009 PAT-PH-5054	1	EXHAUST PORT LOWER END CAP - 5" POWER HE

ſ			Pa	rts List
t	ITEM	PART NUMBER	QTY	DESCRIPTION
T	51	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
*	52	O-B-121	1	O-RING
k	53	O-B-118	2	O-RING
Ī	54	MPH-3261	1	SNAP RING - EXTERNAL
ſ	55	PAT-PH-5007	1	UPPER BUSHING
ķ	56	O-B-127	1	O-RING
T	57	PAT-PH-5009	1	LOWER ROD
T	58	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
Γ	59	PAT-PH-5011	4	TIE ROD
T	60	F-HB-06C-24-GR8	4	HEX BOLT
Γ	61	F-HB-06C-12	2	HEX BOLT
ſ	62	PAT-PH-5008	1	UPPER ROD ASSY
T	63	PF-HN-08-08S	1	HOSE ADAPTER
Γ	64	F-SW-06	4	LOCK WASHER
T	65	F-SW-04-SS	2	LOCK WASHER
Ī	66	F-HB-04C-56-SS	2	HEX BOLT
T	67	F-FW-04	2	FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KIT

PART No. DESCRIPTION
PAT-PH-5000-SK SEAL KIT


* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH


5" PATRIOT POWER HEAD PAT-PH-5000-XD

REV: SHEET 3 / 3 2/20/2015










7" PATRIOT POWER HEAD		PAT-PH-7000
PEV-B 09/16/13	SHFFT 1 /3	10/22/2009





7" PATRIOT POWER HEAD		PAT-PH-7000
REV:B 09/16/13	SHEET 2 / 3	10/22/2009



	DART AN IMPER	and the second second	s List
ITE		QTY	DESCRIPTION
1	PAT-PH-7004	1	LOWER END CAP
2	F-HB-06C-24-GR8	4	HEX BOLT
3	PAT-PH-5011	4	TIE ROD
4	PAT-PH-7012	1	UPPER END CAP - 7"
5	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
6	MPH-3261	-	SNAP RING - EXTERNAL
7	O-B-121	1	O-RING
8	O-B-118	2	O-RING
9	PAT-PH-5009	1	LOWER ROD
10		2	O-RING
11	PAT-PH-5007	1	UPPER BUSHING
12	7205-2-26	1	EXTERNAL SNAP RING
13		1	O-RING
14	1.0.1.2.2.2.2	2	VALVE STEM- PILOT VALVE
15		6	O-RING
16		4	O-RING
17		2	SEAL GUIDE- PILOT VALVE
18		2	SPRING
19		2	SPRING
20		2	INLET ROD- PILOT VALVE
21	O-U-006	2	O-RING
22		2	COMPRESSION SPRING
23		2	SPRING HOUSING- PILOT VALVE
24		2	STEM SEAL ASSY- PILOT VALVE
25		1	CYLINDER
26		5	TIE ROD - 2" STROKE
27		1	PISTON - 7"
28		1	O-RING
29	4 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3 3	2	O-RING
30		4	O-RING
32	The state of the s	2	O-RING
33		1	UPPER VALVE BLOCK
34		4	SET SCREW
35	2000 - 2000 - 2000	1	POPPET VALVE - 2" STROKE
36		2	O-RING
37		2	VALVE PISTON
38		2	O-RING
39		2	PISTON STOP
40		2	O-RING
41	MPH-2521	2	VALVE END CAP
42		2	O-RING
43		2	PIPE PLUG
44		1	O-RING
45	THE PERSON NAMED IN COLUMN TWO IS NOT THE PERSON NAMED IN COLUMN TWO IS NAMED IN C	1	LOWER VALVE BLOCK
47		2	DIAPHRAGM
48	The second second	2	EXHAUST PORT
49		4	CAP SCREW
50	The second secon	2	O-RING
51	F-HB-04C-08	2	HEX BOLT
52		1 242 57	MALE ELBOW
53		-	POLY TUBE
54	THE RESERVE THE PARTY OF THE PA	1	MALE POLY TEE FITTING
55		4	SOCKET HEAD CAP SCREW
56		1	MUFFLER ASSEMBLY
57	PARTITION TO THE	10	HEX NUT
58	N. 77 N. 77 N. W. C.	1	RESET STEM ASSEMBLY
59		1	TEE FITTING
60		1	SEAL
61		2	HEX BOLT
62	5701 051 444	1	UPPER ROD ASSY
63		4	LOCK WASHER
64		1	HOSE ADAPTER
65		2	LOCK WASHER
66		2	HEX BOLT
67		1	HEX PLUG
68	F-FW-04	2	FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES

PARTS LIST


PART No. MPH-2542 PAT-PH-SB-XL QTY DESCRIPTION
1 RESET BUTTON ASSY
L 1 SHIFT BLOCK ASSY

REPAIR KITS PART No. DESCRIPTION
* PAT-PH-7000-SK SEAL KIT

* ASTERISKS DENOTE PARTS IN SEAL KIT

7" PATRIOT POWER HEAD		PAT-PH-7000
REV:B 09/16/13	SHEET 3 / 3	10/22/2009






7" PATRIOT POWER HEAD

PAT-PH-7000-CA





7" PATRIOT POWER HEAD

PAT-PH-7000-CA



ITEM	PART NUMBER	QTY	DESCRIPTION
1	PAT-PH-7004-HD	1	LOWER END CAP
2	F-HB-06C-24-GR8	4	HEX BOLT
3	PAT-PH-5011	4	TIE ROD
4	PAT-PH-7012	1	UPPER END CAP - 7"
5	O-B-118	2	O-RING
6	PAT-PH-5009	1	LOWER ROD
7	O-B-167	2	O-RING
8	PAT-PH-5007	2	UPPER BUSHING
9	7205-2-26	2	EXTERNAL SNAP RING
11	MPH-2513	2	VALVE STEM- PILOT VALVE O-RING
12	O-8-012 O-8-008	6	O-RING
14	MPH-2512	2	SEAL GUIDE- PILOT VALVE
15	MPH-2528	2	SPRING
16	MPH-2526	2	SPRING
17	MPH-2540	2	INLET ROD- PILOT VALVE
18	O-U-006	2	O-RING
19	MPH-2533	2	COMPRESSION SPRING
20	MPH-2541	2	SPRING HOUSING- PILOT VALVE
21	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
22	PAT-PH-7003	1	CYLINDER
23	PAT-PH-5006	5	TIE ROD - 2" STROKE
24	MPH-7004	1	PISTON - 7"
25	O-B-439	1	O-RING
26	O-B-431	2	O-RING
27	O-B-014	4 2	O-RING
28	O-B-011		O-RING
30	PAT-PH-5001 F-SS-832-02-SS	1 4	UPPER VALVE BLOCK SET SCREW
31	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
32	O-U-206-90	2	O-RING
33	MPH-2517	2	VALVE PISTON
34	O-D-010-90	2	O-RING
35	MPH-3262	2	PISTON STOP
36	O-B-116	2	O-RING
37	MPH-2521	2	VALVE END CAP
38	O-B-019	2	O-RING
39	PF-AP-02-SS	2	PIPE PLUG
40	O-B-024	1	O-RING
41	PAT-PH-5002	1	LOWER VALVE BLOCK
43	MPH-5010	2	DIAPHRAGM
44	MPH-5009 F-CS-04C-08-SS	4	CAP SCREW
46	O-8-026	2	O-RING
47	F-HB-04C-08	2	HEX BOLT
48	MPH-2539	1	MALE ELBOW
49	MS-2052-1	.50 FT	POLY TUBE
50	MPH-2538	1	MALE POLY TEE FITTING
51	F-CS-04C-40-SS	4	CAP SCREW
52	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
53	F-HN-06F	10	HEX NUT
54	MPH-2546-01	1	RESET VALVE STEM
55	PF-ST-02-BR	1	TEE FITTING
56	MPH-2545	1	SEAL
57	F-HB-06C-12	2	HEX BOLT
58	PAT-PH-5008	1	UPPER ROD ASSY
59	F-SW-06	4	LOCK WASHER
63	PF-ME-08 O-B-127	2	MALE ELBOW O-RING
64	PF-HP-08	1	HEX PLUG
65	F-SW-04-SS	2	LOCK WASHER
66	F-HB-04C-56-SS	2	HEX BOLT
67	F-FW-04	2	FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS

PART No. DESCRIPTION
* PAT-PH-7000-CA-SK SEAL KIT


* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH

7" PATRIOT POWER HEAD


PAT-PH-7000-CA





7" PATRIOT POWER HEAD -DUO PUMP PAT-PH-7000-D





7" PATRIOT POWER HEAD - DUO PUMP PAT-PH-7000-D



ITEM	PART NUMBER	OTY	DESCRIPTION
1	PAT-PH-7004-HD	1	LOWER END CAP
2	F-HB-06C-24-GR8	4	HEX BOLT
3	PAT-PH-7013	4	LOWER TIE ROD
4	PAT-PH-7012	1	UPPER END CAP - 7"
5	O-B-118	1	O-RING
6	PAT-PH-7009	1	LOWER ROD - HD
7	O-B-167	2	O-RING
8	PAT-PH-5007	1	UPPER BUSHING
9	7205-2-26	2	VALVE STEM- PILOT VALVE
12	MPH-2513 O-B-012	6	O-RING
13	O-B-012	4	O-RING
14	MPH-2512	2	SEAL GUIDE- PILOT VALVE
15	MPH-2528	2	SPRING
16	MPH-2526	2	SPRING
17	MPH-2540	2	INLET ROD- PILOT VALVE
18	O-U-006	2	O-RING
19	MPH-2533	2	COMPRESSION SPRING
20	MPH-2541	2	SPRING HOUSING- PILOT VALVE
21	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
22	PAT-PH-7003	1	CYLINDER TIE ROD - 2" STROKE
24	PAT-PH-5006 MPH-7004	1	PISTON - 7"
25	O-B-439	1	O-RING
26	O-B-431	2	O-RING
27	O-B-014	4	O-RING
28	O-B-011	2	O-RING
29	PAT-PH-5001	1	UPPER VALVE BLOCK
30	F-SS-832-02-SS	4	SET SCREW
31	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
32	O-U-206-90	2	O-RING
33	MPH-2517	2	VALVE PISTON
35	O-D-010-90 MPH-3262	2	O-RING PISTON STOP
36	O-B-116	2	O-RING
37	MPH-2521	2	VALVE END CAP
38	O-B-019	2	O-RING
39	PF-AP-02-SS	2	PIPE PLUG
40	O-B-024	1	O-RING
41	PAT-PH-5002	1	LOWER VALVE BLOCK
43	MPH-5010	2	DIAPHRAGM
45	MPH-5009 F-CS-04C-08-SS	2	EXHAUST PORT CAP SCREW
46	O-B-026	2	O-RING
47	F-HB-04C-08	2	HEX BOLT
48	MPH-2539	1	MALE ELBOW
49	MS-2052-1	.40ft	POLY TUBE
50	MPH-2538	1	MALE POLY TEE FITTING
51	F-CS-04C-40-SS	4	CAP SCREW
52	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
53 54	F-HN-06F	10	HEX NUT
	MPH-2546-01	1	RESET VALVE STEM
55	PF-ST-02-BR	1	TEE FITTING
56 58	MPH-2545 PAT-PH-5008	1	UPPER ROD ASSY
59	F-SW-06	4	LOCK WASHER
60	PF-HN-08-08S	1	HOSE ADAPTER
61	VPH-7005	i	BUSHING
62	O-B-124	1	O-RING
63	O-B-127	2	O-RING
64	PF-HP-08	1	HEX PLUG
65	F-SW-04-SS	2	LOCK WASHER
66	F-HB-04C-56-SS F-PW-04	2	HEX BOLT FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS

PART No. DESCRIPTION


* PAT-PH-7000-HD-SK SEAL KIT

* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH

7" PATRIOT POWER HEAD - DUO PUMP PAT-PH-7000-D






7" PATRIOT POWER HEAD -HD

PAT-PH-7000-HD





7" PATRIOT POWER HEAD - HD

PAT-PH-7000-HD



TEM	PART NUMBER	OTY	DESCRIPTION
1	PAT-PH-7004-HD	1	LOWER END CAP
2	F-HB-06C-24-GR8	4	HEX BOLT
3	PAT-PH-5011	4	TIE ROD
4	PAT-PH-7012	1	UPPER END CAP - 7"
5	O-B-118	1	O-RING
6	PAT-PH-7009	1	LOWER ROD - HD
7	O-B-167	2	O-RING
8	PAT-PH-5007	1	UPPER BUSHING EXTERNAL SNAP RING
11	7205-2-26 MPH-2513	2 2	VALVE STEM- PILOT VALVE
12	O-B-012	6	O-RING
13	O-B-008	4	O-RING
14	MPH-2512	2	SEAL GUIDE- PILOT VALVE
15	MPH-2528	2	SPRING
16	MPH-2526	2	SPRING
17	MPH-2540	2	INLET ROD- PILOT VALVE
18	O-U-006	2	O-RING
19	MPH-2533	2	COMPRESSION SPRING
20	MPH-2541	2	SPRING HOUSING- PILOT VALVE
21	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
22	PAT-PH-7003	1	CYLINDER
23	PAT-PH-5006 MPH-7004	1	TIE ROD - 2" STROKE PISTON - 7"
25	O-B-439	1	O-RING
26	O-B-431	2	O-RING
27	O-B-014	4	O-RING
28	O-B-011	2	O-RING
29	PAT-PH-5001	1	UPPER VALVE BLOCK
30	F-SS-832-02-SS	4	SET SCREW
31	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
32	O-U-206-90	2	O-RING
33	MPH-2517	2	VALVE PISTON
34	O-D-010-90	2	O-RING
35	MPH-3262	2	PISTON STOP
36	O-B-116	2	O-RING
38	MPH-2521 O-B-019	2 2	VALVE END CAP O-RING
39	PF-AP-02-SS	2	PIPE PLUG
40	O-B-024	1	O-RING
41	PAT-PH-5002	1	LOWER VALVE BLOCK
43	MPH-5010	2	DIAPHRAGM
44	MPH-5009	2	EXHAUST PORT
45	F-CS-04C-08-SS	4	CAP SCREW
46	O-B-026	2	O-RING
47	F-HB-04C-08	2	HEX BOLT
48	MPH-2539	1 400	MALE ELBOW
49	MS-2052-1	.40ft	POLY TUBE
50	MPH-2538 F-CS-04C-40-SS	1 4	MALE POLY TEE FITTING CAP SCREW
52	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
53	F-HN-06F	10	HEX NUT
54	MPH-2546-01	1	RESET VALVE STEM
55	PF-ST-02-BR	1	TEE FITTING
56	MPH-2545	1	SEAL
57	F-HB-06C-12	2	HEX BOLT
58	PAT-PH-5008	1	UPPER ROD ASSY
59	F-SW-06	4	LOCK WASHER
60	PF-HN-08-06S	1	HOSE ADAPTER
61	VPH-7005	1	BUSHING
62	O-B-124	3 1	O-RING
63	O-B-127	2	O-RING
65	PF-HP-08	1	HEX PLUG
66	F-SW-04-SS F-HB-04C-56-SS	2	LOCK WASHER HEX BOLT
67	F-FW-04	4	FLAT WASHER

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION

 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS

PART No. DESCRIPTION

* PAT-PH-7000-HD-SK SEAL KIT


* ASTERISKS DENOTE PARTS IN SEAL KIT

MAGNUM VENUS PLASTECH

7" PATRIOT POWER HEAD - HD

PAT-PH-7000-HD






7" Patriot Power Head - Putty

PAT-PH-7000-P

REV:B 07/01/15





7" Patriot Power Head - Putty

PAT-PH-7000-P

REV: B 07/01/15



I	TEM	PART NUMBER	QTY	Parts List DESCRIPTION
Ľ	1	PAT-PH-7004	1	LOWER END CAP
	2	F-HB-06C-24-GR8	4	HEX BOLT
	3	PAT-PH-5011	4	TIE ROD
	4	PAT-PH-7012	1	UPPER END CAP - 7"
	5	VPH-4254	1	BUSHING- 7/8 DIA. PISTON ROD
	6	MPH-3261	1	SNAP RING - EXTERNAL
	7	O-B-121	1	O-RING
	8	O-B-118	1	O-RING
	9	PAT-PH-5009	1	LOWER ROD
	10	O-B-167	2	O-RING
	12	7205-2-26	1	EXTERNAL SNAP RING
	13	O-B-127	1	O-RING
	14	MPH-2513	2	VALVE STEM- PILOT VALVE
	15	O-B-012	6	O-RING
	16	O-B-008	4	O-RING
	17	MPH-2512	2	SEAL GUIDE- PILOT VALVE
	18	MPH-2528	2	SPRING
	19	MPH-2526	2	SPRING
9	20	MPH-2540	2	INLET ROD- PILOT VALVE
	21	O-U-006	2	O-RING
3	22	MPH-2533	2	COMPRESSION SPRING
	23	MPH-2541	2	SPRING HOUSING- PILOT VALVE
9	24	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
3	25	PAT-PH-7003	1	CYLINDER
	26	PAT-PH-5006	5	TIE ROD - 2" STROKE
1	27	MPH-7004	1	PISTON - 7"
:	28	O-B-439	1	O-RING
	29	O-B-431	2	O-RING
:	30	O-B-014	4	O-RING
	32	O-B-011	2	O-RING
. 1	33	PAT-PH-5001	1	UPPER VALVE BLOCK
	34	F-SS-832-02-SS	4	SET SCREW
3	35	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
:	36	O-U-206-90	2	O-RING
s/s 8	37	MPH-2517	2	VALVE PISTON
	38	O-D-010-90	2	O-RING
1	39	MPH-3262	2	PISTON STOP
:	40	O-B-116	2	O-RING
	41	MPH-2521	2	VALVE END CAP
<	42	O-B-019	2	O-RING
. 9	43	PF-AP-02-SS	2	PIPE PLUG
۲ .	44	O-B-024	1	O-RING
	45	PAT-PH-5002	1	LOWER VALVE BLOCK
3 : 1	46	PF-HP-08	1	PIPE PLUG
: 🗆	47	MPH-5010	2	DIAPHRAGM
	48	MPH-5009	2	EXHAUST PORT
3 8	49	F-CS-04C-08-SS	4	CAP SCREW
	50	O-B-026	2	O-RING
	51	F-HB-04C-08	2	HEX BOLT
9	52	MPH-2539	1	MALE ELBOW
3	53	MS-2052-1	.40 FT	POLY TUBE
	54	MPH-2538	1	MALE POLY TEE FITTING
	55	F-CS-04C-40-SS	4	CAP SCREW
	56	PAT-PH-5010-01	1	MUFFLER ASSEMBLY
	57	F-HN-06F	10	HEX NUT
3	58	MPH-2546-01	1	RESET STEM ASSEMBLY
	59	PF-ST-02-BR	1	TEE FITTING
3	60	MPH-2545	1	SEAL
	63	F-SW-06	4	LOCK WASHER
	64	PF-HN-08-08S	1	HOSE ADAPTER
32 9	65	PAT-PH-7008	1	UPPER ROD - PUTTY
	66	VPH-7005	1	BUSHING - UPPER PISTON ROD
	67	F-SW-04-SS	2	LOCK WASHER
	68	F-HB-04C-56-SS	2	HEX BOLT
<	69	O-B-124	1	O-RING

OPTIONAL PARTS AND ASSEMBLIES

PART No. QTY DESCRIPTION
MPH-2542 1 RESET BUTTON ASSY
PAT-PH-SB-XL 1 SHIFT BLOCK ASSY

REPAIR KIT


* PAT-PH-7000-SK (ASTERISKS DENOTE PARTS IN KIT)

MAGNUM VENUS PLASTECH


e | 66

PAT-PH-7000-P


7" Patriot Power Head - Putty












10" PATRIOT POWER HEAD		PAT-PH-10000
REV:C 03/02/2017	SHEET 1 /3	4/20/2010





10" PATRIOT POWER HEAD		PAT-PH-10000
REV:C 03/02/2017	SHEET 2 / 3	4/20/2010



TEM	PART NUMBER	OTY	Parts List DESCRIPTION
	7205-2-26	2	EXTERNAL SNAP RING
-	MPH-2513	2	VALVE STEM- PILOT VALVE
_	D-B-012	6	O-RING
	D-B-008	4	O-RING
	MPH-2512	2	SEAL GUIDE- PILOT VALVE
-	MPH-2528	2	SPRING
	MPH-2526	2	SPRING
	MPH-2540	2	INLET ROD- PILOT VALVE
	MPH-2533	2	COMPRESSION SPRING
	MPH-2541	2	SPRING HOUSING- PILOT VALVE
	MPH-2511-01	2	STEM SEAL ASSY- PILOT VALVE
-	AT-PH-5006	5	TIE ROD - 2" STROKE
	D-B-014	4	O-RING
100	O-B-011	2	O-RING
	PAT-PH-5001	1	UPPER VALVE BLOCK
	-SS-832-02-SS	4	SS SET SCREW
	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
	MPH-2517	2	VALVE PISTON
-	MPH-3262	2	PISTON STOP
	MPH-2521	2	VALVE END CAP
	D-B-019	2	O-RING
	7-AP-02-SS	2	PIPE PLUG
_	PAT-PH-5002		LOWER VALVE BLOCK
_		1	DIAPHRAGM
	MPH-5010	2	
_	MPH-5009	4	EXHAUST PORT
	-CS-04C-08-SS		SOCKET HEAD CAP SCREW
	D-B-026 F-HB-04C-08	2	O-RING
	The state of the s	_	HEX BOLT
	MPH-2539 MS-2052-1	1	MALE ELBOW TUBING
_		1	
	MPH-2538		MALE POLY TEE FITTING
	-CS-04C-40-SS	4	SOCKET HEAD CAP SCREW
_	PAT-PH-5010-01		MUFFLER ASSEMBLY
	-HN-06F	10	HEX NUT RESET STEM ASSEMBLY
	MPH-2546-01	1	
_	F-ST-02-BR		TEE FITTING
	MPH-2545	1	SEAL HOSE ADAPTED
_	F-HN-08-08S	1	HOSE ADAPTER
	PAT-PH-10004	1	LOWER END CAP 10"
	PAT-PH-10012	1	UPPER END CAP 10"
	PAT-PH-10003	1	CYLINDER
	/PH-10006	1	PISTON - 10" POWER HEAD
_	/PH-7005	2	BUSHING - UPPER PISTON ROD
	D-B-445	2	O-RING
	O-B-448	1	O-RING
_	D-B-178	2	O-RING
	D-B-124	2	O-RING
	PAT-PH-10011	4	TIE ROD
	-HB-08C-28-GR5	4	HEX BOLT
	-SW-08	4	LOCK WASHER
	PAT-PH-10009	1	LOWER ROD
	PAT-PH-10008	1	
	-HB-08C-16	2	HEX BOLT
	D-B-127	2	O-RING
_	D-U-206-90	2	O-RING
_	D-D-010-90	2	O-RING
	D-B-116	2	O-RING
	¥F-HP-08	1	HEX PLUG
	D-U-006	2	O-RING
	F-FW-04	2	FLAT WASHER
_	-SW-04-SS	2	LOCK WASHER
	-HB-04C-56-SS	2	HEX BOLT
63 (D-B-024	1	O-RING
	/4X28		GREASE FITTING

OPTIONAL PARTS AND ASSEMBLIES PARTS LIST

 PART No.
 QTY
 DESCRIPTION


 MPH-2542
 1
 RESET BUTTON ASSY

 PAT-PH-SB-XL
 1
 SHIFT BLOCK ASSY

REPAIR KITS

PART No. DESCRIPTION * PAT-PH-10000-SK SEAL KIT

* ASTERISKS DENOTE PARTS IN SEAL KIT




MAGNUM VENUS PLASTECH


10" PATRIOT POWER HEAD PAT-PH-10000

REV: C 03/02/2017 SHEET 3 / 3 4/20/2010










CE NORM GUARD - PAT-PH-10000		PAT-GRD-1000
REV:	SHEET 1 / 2	7/3/2014



		P	arts List
ITEM	PART NUMBER	QTY	DESCRIPTION
1	PAT-HIN-2	1	CONTINUOUS HINGE
2	PAT-BUM	2	RUBBER BUMPER
3	F-BHCS-1024-06	6	BUTTON HEAD CAP SCREW
4	F-FW-1024	3	FLAT WASHER
5	F-SW-1024	2	HELICAL SPRING LOCK WASHER
6	F-HN-1024	2	HEX NUT
7	04571	1	THREAD INSERT
8	F-LN-1024	1	NYLOCK NUT
9	F-FW-1032-NY	1	NYLON WASHER
10	PAT-GRD-3-3	1	LATCH
11	F-BHCS-1024-08	2	BUTTON HEAD CAP SCREW
12	F-PR-6-2	6	POP RIVET
13	PAT-GRD-10-4	1	VIEW PANEL
14	PAT-GRD-10-2	1	HOOD WELDMENT
15	PAT-GRD-10-1	1	BOX WELDMENT

CE NORM GUARD - PAT-PH-10000		PAT-GRD-1000
REV:	SHEET 2 / 2	7/3/2014





CE NORM GUARD - BASE SHROUD ASSEMBLY - PAT-PH-10000		PAT-GRD-1100
REV:	SHEET 1 / 2	7/3/2014




		P	arts List
ITEM	PART NUMBER	QTY	DESCRIPTION
1	PAT-GRD-1101	2	BASE SHROUD
2	F-FW-1024	2	FLAT WASHER
3	F-LN-1024	2	NYLOCK NUT
4	F-BHCS-1024-08	2	BUTTON HEAD CAP SCREW

 CE NORM GUARD - BASE SHROUD ASSEMBLY - PAT-PH-10000
 PAT-GRD-1100

 REV:
 SHEET 2 / 2
 7/3/2014





SHIFT BLOCK ASSEMBLY - 5" AND 7" POWER HEADS		PAT-PH-SB-XL
REV:A	SHEET 1 / 2	10/3/2012



		Par	ts List
ITEM	PART NUMBER	QTY	DESCRIPTION
1	PAT-PH-5001	1	UPPER VALVE BLOCK
2	PAT-PH-5002	1	LOWER VALVE BLOCK
3	O-B-024	1	O-RING
4	O-B-012	2	O-RING
5	PAT-PH-5005	1	POPPET VALVE - 2" STROKE
6	O-U-206-90	2	O-RING
7	MPH-2517	2	VALVE PISTON
8	O-D-010-90	2	O-RING
9	O-B-116	2	O-RING
10	MPH-3262	2	PISTON STOP
11	MPH-2521	2	VALVE END CAP
12	PF-AP-02-SS	2	PIPE PLUG
13	O-B-019	2	O-RING
14	O-B-014	4	O-RING
15	F-SS-832-02-SS	4	SS SET SCREW
16	PF-HP-08	1	HEX PLUG
17	PF-HN-08-08S	1	HOSE ADAPTER
18	MPH-2539	1	MALE ELBOW
19	MPH-2538	1	MALE POLY TEE FITTING
20	MS-2052-1	.313 FT	TUBING
21	O-B-008	2	O-RING
22	O-B-011	2	O-RING
23	MPH-5010	2	DIAPHRAGM
24	MPH-5009	2	EXHAUST PORT
25	O-B-026	2	O-RING
26	F-CS-04C-08-SS	4	SOCKET HEAD CAP SCREW
27	F-CS-04C-40-SS	4	SOCKET HEAD CAP SCREW
28	F-HB-04C-08	2	HEX BOLT
29	PF-ST-02-BR	1	TEE FITTING
30	MPH-2546-01	1	RESET STEM ASSEMBLY
31	MPH-2545	1	SEAL

OPTIONAL PARTS AND ASSEMBLIES

ITEM PART No. QTY DESCRIPTION

32 MPH-2542 1 RESET BUTTON ASSEMBLY

REPAIR KIT


PART No. DESCRIPTION * PAT-PH-SB-XL-SK SEAL KIT

MAGNUM VENUS PLASTECH

SHIFT BLOCK ASSEMBLY - 5" AND 7" POWER HEADS PAT-PH-SB-XL

REV: A SHEET 2 / 2 10/3/2012





CORPORATE HEADQUARTERS

2030 Falling Waters Rd, Suite 350, Knoxville, TN 37922 · USA · Tel: (865) 686-5670

DISTRIBUTION AND PURCHASING

642 Barbrow Ln, Knoxville, TN 37932 · USA · Tel: (865) 684-4416

TECHNOLOGY CENTER AND MANUFACTURING

1862 Ives Ave, Kent, WA 98032 · USA · Tel (253) 854-2660 · Fax (253) 854-1666

E-mail: info@mvpind.com

For a list of international distributors, visit our website at:

www.mvpind.com/mvp-international

