
Cipher Gun Manual


This manual is applicable to the following models:

- CPR-2000
- CSG-8000
- GSG-8000





Rev. March 2019



CORPORATE HEADQUARTERS 2030 Falling Waters Rd, Suite 350, Knoxville, TN 37922 · USA · Tel: (865) 686-5670

DISTRIBUTION AND PURCHASING 642 Barbrow Ln, Knoxville, TN 37932 · USA · Tel: (865) 684-4416

TECHNOLOGY CENTER AND MANUFACTURING

1862 Ives Ave, Kent, WA 98032 · USA · Tel (253) 854-2660 · Fax (253) 854-1666

E-mail: info@mvpind.com

For a list of international distributors, visit our website at:

www.mvpind.com/mvp-international

Use of this product confirms that Magnum Venus Products, Inc.'s standard terms and conditions of sale apply.



▲ Table of Contents

S	Section	Page
•	Table of Contents	3
•	Safety & Warning Information	4
•	Introduction	15
•	Disassembling the Gun	15
•	Assembling Gun	17
•	Adjusting and Starting Up	19
•	Troubleshooting	19
•	Parts Drawings	22



Safety & Warning Information

Warnings 4

Due to the vast number of chemicals that could be used and their varying chemical reactions, the buyer and user of this equipment should determine all factors relating to the fluids used, including any of the potential hazards involved. Particular inquiry and investigation should be made into potential dangers relating to toxic fumes, fires, explosions, reaction times, and exposure of human beings to the individual components or their resultant mixtures. MVP assumes no responsibility for loss, damage, expense or claims for bodily injury or property damage, direct or consequential, arising from the use of such chemical components.

The end user is responsible for ensuring that the end product or system complies with all the relevant laws in the country where it is to be used and that all documentation is adhered to.

Recommended Occupational Safety & Health Act (OSHA) Documentation:

1910.94 Pertaining to ventilation Pertaining to flammable liquids 1910.106 Pertaining to spray finishing operations, particularly paragraph (m), 1910.107 Organic Peroxides and Dual Component Coatings

For Additional information, contact the Occupational Safety and Health Administration (OSHA) at https://www.osha.gov/about.html.

Recommended National Fire Protection Association (NFPA) Documentation:

Organic Peroxides and Dual Component Materials NFPA No.33 Chapter 14 NFPA No. 63 **Dust Explosion Prevention** National Electrical Code NFPA No. 70 Static Electricity NFPA No. 77 Blower and Exhaust System NFPA No. 91

Fire Extinguisher – code ABC, rating number 4a60bc using Extinguishing Media –Foam, Carbon Dioxide, Dry Chemical, Water Fog, is recommended for this product and applications.

Plastics Industry Dust Hazards

The following general warnings and guidelines are for the setup, use, grounding, maintenance, and repair of equipment. Additional product-specific warnings may be found throughout this manual as applicable. Please contact your nearest MVP Technical Service Representative if additional information is needed.



NFPA No. 654

Safety Precautions

- Avoid skin contact and inhalation of all chemicals.
- Review Material Safety Data Sheet (MSDS) to promote the safe handling of chemicals in

 USE
- Restrict the use of all chemicals to designated areas with good ventilation.
- Chemicals are flammable and reactive.
- Noxious fumes released when combusted.
- Operate equipment in a ventilated environment only.
- Uncured liquid resins are highly flammable unless specifically labeled otherwise.
- Cured laminate, accumulations of overspray, and laminate sandings are highly combustible.
- Do not operate or move electrical equipment when flammable fumes are present.
- Ground all equipment.
- If a spark is seen or felt, immediately halt operation. Do not operate the equipment until the issue has been identified and repaired.
- Contaminated catalyst may cause fire or explosion.
- Containers may explode if exposed to fire / heat.
- Use and store chemicals away from heat, flames, and sparks.
- Do not smoke in work areas or near stored chemicals.
- Do not mix Methyl Ethyl Ketone Peroxide (MEKP) with materials other than polyethylene.
- Do not dilute MEKP.
- Keep food and drink away from work area.







FLAMMABLE



GROUNDING



EXPLOSIVE



DANGER



DANGER



Physical Hazards

- Never look directly into the spray gun fluid tip. Serious injury or death can result.
- Never aim the spray gun at or near another person. Serious injury or death can result.
- Chemical compounds can be severely irritating to the eyes and skin.
- Inhalation, ingestion, or injection may damage internal organs and lead to pulmonary disorders, cancers, lymphomas, and other diseases or health conditions.
- Other potential health effects include: irritation of the eyes and upper respiratory tract, headache, light-headedness, dizziness, confusion, drowsiness, nausea, vomiting, and occasionally abdominal pain.
- Eye contact: Immediately flush with water for at least 15 minutes and seek immediate medical attention.
- Skin Contact: Immediately wash with soap and water and seek immediate medical attention.
- Inhalation: Move the person to fresh air and seek immediate medical attention.
- Do not remove shields, covers, or safety features on equipment that is in use.
- Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can shoot liquid through the skin.
- Keep hands and body parts away from any moving equipment or components.
- Do not stand under plunger
- An improperly loaded drum may lead to an imbalance, causing a unit to tip over





Personal Protective Equipment (PPE)

- MVP recommends the use of personal safety equipment with all products in our catalog.
- Wear safety goggles, hearing protection, a respirator, and chemical resistant gloves.
- Wear long sleeve shirts or jackets and pants to minimize skin exposure.
- PPE should be worn by operators and service technicians to reduce the risk of injury.



For Additional information, contact the Occupational Safety and Health Administration (OSHA). https://www.osha.gov/about.html



Symbol Definitions



Indicates the risk of contact with chemicals that are hazardous, which may lead to injury or death.



Indicates the risk of contact with voltage / amperage that may lead to serious injury or death



Indicates that the materials being used are susceptible to combustion



Indicates the risk of contact with moving components that may lead to serious injury or death.



Indicates that the system or component should be grounded before proceeding with use or repair.



Indicates the use of lit cigarettes or cigars is prohibited, because the materials being used are susceptible to combustion.



Indicates that the materials and/or the process being performed can lead to ignition and explosion.



A recommendation for the use of Personal Protective Equipment (PPE) before using or repairing the product.



Polymer Matrix Materials: Advanced Composites

Potential health hazards associated with the use of advanced composites can be controlled through the implementation of an effective industrial hygiene and safety program.

https://www.osha.gov/dts/osta/otm/otm_iii/otm_iii_1.html#t iii:1_1

Resins					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Epoxy resins	Skin, lungs, eyes	Contact and allergic dermatitis,			
<u> Ероху гезінз</u>	Okin, langs, cycs	conjunctivitis			
Polyurethane resins	Lungs, skin, eyes	Respiratory sensitization, contact			
_		dermatitis, conjunctivitis			
Phenol formaldehyde	Skin, lungs, eyes	As above (potential carcinogen)			
Bismaleimides (BMI)	Skin, lungs, eyes	As above (potential carcinogen)			
Polyamides	Skin, lungs, eyes	As above (potential carcinogen)			
Reinforcing materials					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Aramid fibers	Skin (lungs)	Skin and respiratory irritation, contact			
	_	dermatitis (chronic interstitial lung disease)			
Carbon/graphite fibers	Skin (lungs)	As noted for aramid fibers			
Glass fibers (continuous	Skin (lungs)	As noted for aramid fibers			
filament)	Gimi (iaiigo)				
Hardeners and curing agents					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Diaminodiphenylsulfone	N/A	No known effects with workplace			
· -	-	exposure			
Methylenedianiline	Liver, skin	Hepatotoxicity, suspect human carcinogen			
Other aromatic amines					
Composite Component	Organ System Target	Known (Possible) Health Effect			
	(Possible Target)				
Meta-phenylenediamine (MPDA)	Liver, skin (kidney,	Hepatitis, contact dermatitis (kidney and			
-	bladder)	bladder cancer)			
Aliphatic andcyclo-aliphatic	Eyes, skin	Severe irritation, contact dermatitis			
amines					
Polyaminoamide	Eyes, skin	Irritation (sensitization)			
Anhydride	Eyes, lungs, skin	Severe eye and skin irritation, respiratory			
9 222	,, ·	sensitization, contact dermatitis			



Catalyst - Methyl Ethyl Ketone Peroxide (MEKP)

MEKP is among the more hazardous materials found in commercial channels. The safe handling of the "unstable (reactive)" chemicals presents a definite challenge to the plastics industry. The highly reactive property which makes MEKP valuable to the plastics industry in producing the curing reaction of polyester resins also produces the hazards which require great care and caution in its storage, transportation, handling, processing and disposal. MEKP is a single chemical. Various polymeric forms may exist which are more or less hazardous with respect to each other. These differences may arise not only from different molecular structures (all are, nevertheless, called "MEKP") and from possible trace impurities left from the manufacture of the chemicals, but may also arise by contamination of MEKP with other materials in its storage or use. Even a small amount of contamination with acetone, for instance, may produce an extremely shock-sensitive and explosive compound.



WARNING

Contamination with promoters, materials containing promoters (such as laminate sandings), or with any readily oxidizing material (such as brass or iron) will cause exothermic redox reactions which can be explosive in nature. Heat applied to MEKP or heat buildup from contamination reactions can cause the material to reach its Self-Accelerating Decomposition Temperature (SADT).

Researchers have reported measuring pressure rates-of-rise well over 100,000 psi per second when certain MEKP's reach their SADT. For comparison, the highest-pressure rate-of-rise listed in NFPA Bulletin NO.68, "Explosion Venting", is 12,000 psi per second for an explosion of 12% acetylene and air. The maximum value listed for a hydrogen explosion is 10,000 psi per second. Some forms of MEKP, if allowed to reach their SADT, will burst even an open topped container. This suggests that it is not possible to design a relief valve to vent this order of magnitude of pressure rate-of-rise. The user should be aware that any closed container, be it a pressure vessel, surge chamber, or pressure accumulator, could explode under certain conditions. There is no engineering substitute for care by the user in handling organic peroxide catalysts. If, at any time, the pressure relieve valve on top of the catalyst tank should vent, the area should be evacuated at once and the fire department called. The venting could be the first indication of a heat, and therefore, pressure build-up that could eventually lead to an explosion. Moreover, if a catalyst tank is sufficiently full when the pressure relief valve vents, some catalyst may spray out, which could cause eye injury. For this reason, and many others, anyone whose job puts them in an area where this vented spray might go, should always wear full eye protection even when laminating operations are not taking place.

Safety in handling MEKP depends to a great extent on employee education, proper safety instructions, and safe use of the chemicals and equipment. Workers should be thoroughly informed of the hazards that may result from improper handling of MEKP, especially regarding contamination, heat, friction and impact. They should be thoroughly instructed regarding the proper action to be taken in the storage, use, and disposal of MEKP and other hazardous materials used in the laminating operation. In addition, users should make every effort to:

- Store MEKP in a cool, dry place in original containers away from direct sunlight and away from other chemicals.
- Keep MEKP away from heat, sparks, and open flames.
- Prevent contamination or MEKP with other materials, including polyester over spray and sandings, polymerization accelerators and promoters, brass, aluminum, and non-stainless steels.



- Never add MEKP to anything that is hot, since explosive decomposition may result.
- Avoid contact with skin, eyes, and clothing. Protective equipment should be worn at all times. During clean-up of spilled MEKP, personal safety equipment, gloves, and eye protection must be worn. Firefighting equipment should be at hand and ready.
- Avoid spillage, which can heat up to the point of self-ignition.
- Repair any leaks discovered in the catalyst system immediately, and clean-up the leaked catalyst at once in accordance with the catalyst manufacturer's instructions.
- Use only original equipment or equivalent parts from Magnum Venus Products in the catalyst system (i.e.: hoses, fitting, etc.) because a dangerous chemical reaction may result between substituted parts and MEKP.
- Catalyst accumulated from the purging of hoses or the measurement of fluid output deliveries should never be returned to the supply tank, such catalyst should be diluted with copious quantities of clean water and disposed of in accordance with the catalyst manufacturer's instructions.

The extent to which the user is successful in accomplishing these ends and any additional recommendations by the catalyst manufacturer determines largely the safety that will be present in his operation.

Clean-Up Solvents and Resin Diluents



WARNING

A hazardous situation may be present in your pressurized fluid system! Hydro carbon solvents can cause an explosion when used with aluminum or galvanized components in a closed (pressurized) fluid system (pump, heaters, filters, valves, spray guns, tanks, etc.). An explosion could cause serious injury, death, and/or substantial property damage. Cleaning agents, coatings, paints, etc. may contain Halogenated Hydrocarbon solvents. Some Magnum Venus Products spray equipment includes aluminum or galvanized components and will be affected by Halogenated Hydrocarbon solvents.

There are three key elements to the Halogenated Hyrdocarbon (HHC) solvent hazard.

- The presence of HHC solvents.
- Aluminum or Galvanized Parts.
- 3. Equipment capable of withstanding pressure.
- 1,1,1 Trichloroethane and Methylene Chloride are the most common of these solvents. However, other HHC solvents are suspect if used; either as part of paint or adhesives formulation, or for clean-up flushing. Most handling equipment contains these elements. In contact with these metals, HHC solvents could generate a corrosive reaction of a catalytic nature.
- When HHC solvent contact aluminum or galvanized parts inside a closed container such as a pump, spray gun, or fluid handling system, the chemical reaction can, over time, result in a build-up of heat and pressure, which can reach explosive proportions. When all three elements are present, the result can be an extremely violent explosion. The reaction can be sustained with very little aluminum or galvanized metal; any amount of aluminum is too much.



- The reaction is unpredictable. Prior use of an HHC solvent without incident (corrosion or explosion) does NOT mean that such use is safe. These solvents can be dangerous alone (as a clean-up or flushing agent) or when used as a component or a coating material. There is no known inhibitor that is effective under all circumstances. Mixing HHC solvents with other materials or solvents such as MEKP, alcohol, or toluene may render the inhibitors ineffective.
- The use of reclaimed solvents is particularly hazardous. Reclaimers may not add any inhibitors. The possible presence of water in reclaimed solvents could also feed the reaction.
- Anodized or other oxide coatings cannot be relied upon to prevent the explosive reaction. Such
 coatings can be worn, cracked, scratched, or too thin to prevent contact. There is no known way
 to make oxide coatings or to employ aluminum alloys to safely prevent the chemical reaction
 under all circumstances.
- Several solvent suppliers have recently begun promoting HHC solvents for use in coating systems. The increasing use of HHC solvents is increasing the risk. Because of their exemption from many state implementation plans as Volatile Organic Compounds (VOCs), their low flammability hazard, and their not being classified as toxic or carcinogenic substances, HHC solvents are very desirable in many respects.



WARNING

Do not use Halogenated Hydrocarbon (HHC) solvents in pressurized fluid systems having aluminum or galvanized wetted parts.

Magnum Venus Products is aware of NO stabilizers available to prevent HHC solvents from reaction under all conditions with aluminum components in closed fluid systems. HHC solvents are dangerous when used with aluminum components in a closed fluid system.

- Consult your material supplier to determine whether your solvent or coating contains Halogenated Hydrocarbon solvents.
- Magnum Venus Products recommends that you contact your solvent supplier regarding the best non-flammable clean-up solvent with the heat toxicity for your application.
- If, however, you find it necessary to use flammable solvents, they must be kept in approved, electrically grounded containers.
- Bulk solvent should be stored in a well-ventilated, separate building, 50 feet away from your main plant.
- You should only allow enough solvent for one day's use in your laminating area.
- NO SMOKING signs must be posted and observed in all areas of storage or where solvents and other flammable materials are used.
- Adequate ventilation (as covered in OSHA Section 1910.94 and NFPA No.91) is important wherever solvents are stored or used, to minimize, confine and exhaust the solvent vapors.
- Solvents should be handled in accordance with OSHA Section 1910.106 and 1910.107.



Catalyst Diluents

Magnum Venus Products spray-up and gel-coat systems currently produced are designed so that catalyst diluents are not required. Magnum Venus Products therefore recommends that diluents not be used to avoid possible contamination which could lead to an explosion due to the handling and mixing of MEKP and diluents. In addition, it eliminates any problems from the diluent being contaminated through rust particles in drums, poor quality control on the part of the diluents suppliers, or any other reason. If diluents are absolutely required, contact your catalyst supplier and follow his instructions explicitly. Preferably the supplier should premix the catalyst to prevent possible "on the job" contamination while mixing.



WARNING

If diluents are not used, remember that catalyst spillage and gun, hose, and packing leaks are potentially more hazardous since each drop contains a higher concentration of catalyst and will therefore react more quickly with overspray and the leak.

Cured Laminate, Overspray and Laminate Sandings Accumulation

- Remove all accumulations of overspray, Fiberglass Reinforced Plastic (FRP) sandings, etc. from the building as they occur. If this waste is allowed to build up, spillage of catalyst is more likely to start a fire; in addition, the fire would burn hotter and longer.
- Floor coverings, if used, should be non-combustible.
- Spilled or leaked catalyst may cause a fire if it comes in contact with an FRP product, oversprayed chop or resin, FRP sandings or any other material with MEKP.

To prevent spillage and leakage, you should:

roving guides so that the fiberglass

strands DO NOT rub against any of

the hoses at any point.

_		
1.	Maintain your Magnum Venus Products System.	Check the gun several times daily for catalyst and resin packing or valve leaks. REPAIR ALL LEAKS IMMEDIATELY.
2.	Never leave the gun hanging over or lying inside the mold.	A catalyst leak in this situation would certainly damage the part, possibly the mold, and may cause a fire.
3.	Inspect resin and catalyst hoses daily for wear or stress at the entry and exits of the boom sections and at the hose and fittings.	Replace if wear or weakness is evident or suspected.
4.	Arrange the hoses and fiberglass	If allowed to rub, the hose will be cut through,

If allowed to rub, the hose will be cut through, causing a hazardous leakage of material which could increase the danger of fire. Also, the material may spew onto personnel in the area.



Toxicity of Chemicals

- Magnum Venus Products recommends that you consult OSHA Sections 1910.94, 1910.106, 1910.107 and NFPA No.33, Chapter 14, and NFPA No.91.
- Contact your chemical supplier(s) and determine the toxicity of the various chemicals used as well as the best methods to prevent injury, irritation and danger to personnel.
- Also determine the best methods of first aid treatment for each chemical used in your plant.

Equipment Safety

Magnum Venus Products suggest that personal safety equipment such as EYE GOGGLES, GLOVES, EAR PROTECTION, and RESPIRATORS be worn when servicing or operating this equipment. Ear protection should be worn when operating a fiberglass chopper to protect against hearing loss since noise levels can be as high as 116 dB (decibels). This equipment should only be operated or serviced by technically trained personnel!



CAUTION

Never place fingers, hands, or any body part near or directly in front of the spray gun fluid tip. The force of the liquid as it exits the spray tip can cause serious injury by shooting liquid through the skin. NEVER LOOK DIRECTLY INTO THE GUN SPRAY TIP OR POINT THE GUN AT OR NEAR ANOTHER PERSON OR AN ANIMAL.



DANGER

Contaminated catalyst may cause fire or explosion. Before working on the catalyst pump or catalyst accumulator, wash hands and tools thoroughly. Be sure work area is free from dirt, grease, or resin. Clean catalyst system components with clean water daily.



DANGER

Eye, skin, and respiration hazard. The catalyst MEKP may cause blindness, skin irritation, or breathing difficulty. Keep hands away from face. Keep food and drink away from work area.

Treatment of Chemical Injuries



CAUTION

Refer to your catalyst manufacturer's safety information regarding the safe handling and storage of catalyst. Wear appropriate safety equipment as recommended.

Great care should be used in handling the chemicals (resins, catalyst and solvents) used in polyester systems. Such chemicals should be treated as if they hurt your skin and eyes and as if they are poison to your body. For this reason, Magnum Venus Products recommends the use of protective clothing and eye wear in using polyester systems. However, users should be prepared in the event of such an injury.



Precautions include:

- 1. Know precisely what chemicals you are using and obtain information from your chemical supplier on what to do in the event the chemical gets onto your skin or into the eyes, or if swallowed.
- 2. Keep this information together and easily available so that it may be used by those administering first aid or treating the injured person.
- 3. Be sure the information from your chemical supplier includes instructions on how to treat any toxic effects the chemicals have.



WARNING

Contact your doctor immediately in the event of an injury. If the product's MSDS includes first aid instructions, administer first aid immediately after contacting a doctor.

Fast treatment of the outer skin and eyes that contact chemicals generally includes immediate and thorough washing of the exposed skin and immediate and continuous flushing of the eyes with lots of clean water for at least 15 minutes or more. These general instructions of first aid treatment may be incorrect for some chemicals; you must know the chemicals and treatment before an accident occurs. Treatment for swallowing a chemical frequently depends upon the nature of the chemical.

Emergency Stop Procedure

In an emergency, follow these steps to stop a system:

1. The ball valve located where the air enters the power head of the resin pump, should be moved to the "OFF" or closed position.

Note The "open" or "on" position is when the ball valve handle is parallel (in line) with the ball valve body. The "closed" or "off" position is when the ball valve handle is perpendicular (across) the ball valve body.

- 2. Turn all system regulators to the "OFF" position (counter-clockwise) position.
- 3. Verify / secure the catalyst relief line, located on the catalyst relief valve.
- 4. Verify / secure the resin return line, located on the resin filter.
- 5. Place a container under the resin pump ball valve to catch ejected resin.
- 6. Locate the ball valve on the resin pump.
- 7. Rotate the ball valve 90 degrees to the "On" or open position.

Grounding

Grounding an object means providing an adequate path for the flow of the electrical charge from the object to the ground. An adequate path is one that permits charge to flow from the object fast enough that it will not accumulate to the extent that a spark can be formed. It is not possible to define exactly what will be an adequate path under all conditions since it depends on many variables. In any event, the grounding means should have the lowest possible electrical resistance.



Grounding straps should be installed on all loose conductive objects in the spraying area. This includes material containers and equipment. Magnum Venus Products recommends grounding straps be made of AWG No.18 stranded wire as a minimum and the larger wire be used where possible. NFPA Bulletin No77 states that the electrical resistance of such a leakage path may be as low as 1 meg ohm (10 ohms) but that resistance as high as 10,000 meg ohms will produce an adequate leakage path in some cases.

CAUTION



Whenever flammable or combustible liquids are transferred from one container to another, or from one container to the equipment, both containers or container and equipment shall be effectively bonded and grounded to dissipate static electricity. For further information, see National Fire Protection Association (NFPA) 77, titled "Recommended Practice on Static Electrical". Refer especially to section 7-7 titled "Spray Application of Flammable and Combustible Materials".

Introduction

This manual provides information for the operation, maintenance, and simple repair of the MVP Cipher Gun. The following procedures are included:

- Step-by-step assembly and disassembly
- Troubleshooting information



Please read this manual carefully and retain for future reference. Follow the steps in the order given, otherwise you may damage the equipment or injure yourself.

Disassembling the Gun

Initial Disassembly



WARNING

Always remove air and fluid pressure before disconnecting the gun or attempting to work on equipment.


- 1. Remove catalyst, resin, and flush fluid pressure from the system.
- 2. Remove catalyst, resin, and flush lines form the gun block




- 3. Remove the hex screw from the trigger stud.
- 4. Remove trigger stud from the gun handle and trigger.
- 5. Remove the trigger from the gun assembly.
- 6. Remove the cap screw located at the back center of the gun block and remove the gun block assembly from the gun handle assembly.

Disassemble Gun Handle

7. Remove spring retainers and springs.




- 8. Remove valve body assembly from handle.
- 9. Remove spring and poppet assembly.



Disassemble Gun Block

10. Pull the catalyst and resin needles from their housings.





Caution Be careful not to bend the needles. The gun will not function properly with bent needles.

- 11. Remove the nozzle cap, nozzle, and turbulent mixer.
- 12. Remove the two cap screws and remove the mix housing.
- 13. Take the catalyst injector out of the distribution ring.
- 14. Remove the mix housing seal and distribution ring from the mix housing.
- 15. Unscrew the catalyst and resin needle housings from the gun head.
- 16. Remove the flush valve assembly.
- 17. Remove the catalyst plug.
- 18. Remove the resin fitting and the catalyst fitting.

Disassemble Flush Valve

- 19. Remove and discard the flush valve split seal from the flush valve body.
- 20. Remove the flush elbow assembly from the flush valve neck.
- 21. Remove the flush valve neck and the flush valve seal from the flush valve body.
- 22. Discard the flush valve seal.
- 23. Remove the flush seal body from the flush valve button.
- 24. Remove the compression spring from the flush valve body.
- 25. Remove and discard the O-ring from the flush seal body.
- 26. Remove and discard the O-ring from the flush valve button.

Disassemble Catalyst Injector

- 27. Remove injector seal from injector body.
- 28. Unscrew plunger retainer from the injector plunger.
- 29. Remove the compression spring from the injector plunger.
- 30. Remove the injector plunger from the injector body.
- 31. Discard all parts replaced by the repair kit.
- 32. Thoroughly clean all remaining parts, inspect for damage, and replace if needed.

Assembling Gun

Assemble Flush Valve

- 1. Install the O-ring onto the flush valve button.
- 2. Install the O-ring onto the flush seal body.
- 3. Install the compression spring into the flush valve body.



- 4. Push the flush valve button through the compression spring located in the flush valve body.
- 5. Screw on and tighten the flush seal body.
- 6. Install the flush valve seal onto the flush valve body and thread through the flush valve neck.
- 7. Install the flush elbow assembly onto the flush valve neck.
- 8. Install the flush valve split seal onto the flush valve body.

Note O-ring 7301-13-008 EPR is for use with acetone only. DO NOT use grease with EPR O-ring.

Assemble Gun Head

- 9. Place new O-rings on the catalyst and resin fittings.
- 10. Install both fittings into the gun, making sure they are on the correct sides of the gun block.
- 11. Install a new seal onto the plug, then thread the plug into he the gun block.
- 12. Install the flush valve assembly into the resin side of the gun block.
- 13. Install the distribution ring (with larger holes to the back) into the mix housing.
- 14. Install a new mix housing seal into the mix housing.
- 15. Insert the catalyst injector assembly into the distribution ring.
- 16. Attach the mix housing to the gun block with cap screws.
- 17. Install a new O-ring into the catalyst needle seat area of the gun block.
- 18. Install a new O-ring on the catalyst needle housing and thread into the gun block.
- 19. Install a new O-ring into the resin needle seat area of the gun block.
- 20. Install a new O-ring on the resin needle housing, lightly grease the threads, then thread into the gun block.
- 21. Install new O-rings onto both of the piston needles.
- 22. Insert one piston needle into the catalyst needle housing and one into the resin needle housing.

Assemble Gun Housing

- 23. Apply lubricant to springs and insert into the gun handle.
- 24. Thread the spring retainers over the springs and into the gun handle.
- 25. Slide the spring onto the end of the poppet assembly.
- 26. Insert the poppet assembly into the valve body.
- 27. Slide an O-ring over the poppet assembly and secure with the packing retainer.
- 28. Screw the assembled valve body into the gun handle.

Assemble Catalyst Injector

29. Slide the injector plunger through the injector body.



- 30. Slide a compression spring over the injector plunger.
- 31. Screw the plunger retainer onto the injector plunger.
- 32. Install a new injector seal onto the injector body.

Attach Gun Head to Handle

- 33. Attach the gun block assembly to the gun handle using a cap screw.
- 34. Slide the trigger into place against the needles and line up the holes with the handle.

Use caution not to bend the needles. Note

35. Push the trigger stub through both the trigger and the gun handle and retain with the hex screw.



Adjusting and Starting Up

- 1. Make sure trigger and trigger bar are not worn, loose, or damaged.
- 2. Adjust the resin needle guide and jam nut so they will open just before the catalyst needle (never catalyst first).

Note How much you open the resin needle will depend on the resin viscosity and may have to be changed as the resin temperature changes.

3. Test the gun by putting 100 psi (7 bar) of air to the catalyst and resin fittings and submerging the gun in water.



Troubleshooting

Catalyst Problems					
Symptom	Possible Cause	Remedy			
Catalyst leaking around needle (inside needle	O-ring on needle worn or damaged Excessive pressure in catalyst	Replace O-ring Relieve catalyst pressure from system			
housing)	system	Theneve datalyst pressure from system			
Catalyst leaking around needle housing	O-ring on needle housing worn or damaged	Replace O-ring			
	Catalyst piston needle worn or damaged	Replace needle			
	Catalyst seat worn or damaged	Replace catalyst seat			
Catalyst leaking form the mix housing/front of gun	O-ring under catalyst seat worn or damaged	Replace O-ring			
	Damaged or weak return spring	Replace as needed			
	Excessive pressure in catalyst system	Relieve pressure in catalyst system			



Catalyst Problems					
Symptom	Possible Cause	Remedy			
Catalyst leaking from around plug on side of gun head	Plug seal worn or damaged	Replace plug seal			
	Trigger is not connecting with catalyst needle	Adjust trigger			
No catalyst from gun	Catalyst injector not operating properly	Inspect injector and adjust or replace as needed			
	Blockage in gun block	Disassemble and clean the gun block			
	Catalyst pump not operating	Refer to catalyst pump manual to adjust			
	properly	pump as needed			
Catalyst leaking between fitting and gun block	O-ring on fitting worn or damaged	Replace O-ring			

Resin Problems					
Symptom	Possible Cause	Remedy			
Resin leaking around needle inside needle housing	O-ring on needle worn or damaged	Replace O-ring			
Resin leaking around needle housing	O-ring on needle housing worn or damaged	Replace O-ring Replace piston needle as needed Replace needle housing Replace O-ring as needed			
	Piston needle worn or damaged	Replace piston needle as needed			
Resin leaking form the	Resin needle housing worn or damaged	Replace needle housing			
mix housing/front of gun	O-ring under the resin needle housing worn or damaged	Replace O-ring as needed			
	Damaged or weak return spring	Adjust spring and replace as needed			
	Excessive pressure in resin system	Relieve system pressure			
No regin coming from gun	Trigger is not pulling resin needle back/open	Adjust trigger as needed			
No resin coming from gun	Gun block obstructed	Clear any blockages from the gun block			
	Resin pump malfunctioning	Check resin pump for proper operation			
Resin leaking between fitting and gun block O-ring on fitting worn or damaged		Replace O-ring			

Flush Problems				
Symptom	Possible Cause	Remedy		
Solvent leaking from around flush button inside flush body	O-ring on valve button worn or damaged	Replace O-ring		



Flush Problems					
Symptom	Possible Cause	Remedy			
Solvent leaking from around flush neck next to gun block Split seal worn or damaged		Replace split seal			
Solvent leaking from between flush neck and flush body Flush valve seal worn or damaged F		Replace flush valve seal			
Solvent leaking around	Flush swivel elbow fitting loose	Tighten fitting			
elbow flush fitting	Nylon seal worn or damaged	Replace seal			
elbow hash fitting	Flush swivel elbow fitting damaged	Replace fitting			
	Debris in seal area or damage to flush body	Clean and replace parts as needed			
Solvent leaking from mix housing/front of gun	O-ring on flush seal body worn or damaged	Replace O-ring			
	Excessive pressure in flush system	Relieve flush system pressure and set to			
		no more than 80 psi			

General Problems			
Symptom	Possible Cause	Remedy	
Material leaking from around the mix chamber	Mix housing seal worn or damaged Catalyst injector seal worn or damaged	Replace seal	
Air leaking from around poppet needle	Poppet needle retainer loose	Tighten poppet valve body Note Do not overtighten; this will make the poppet needle move slowly or not at all	
	O-ring worn or damaged	Replace O-ring	
Air leaking from around poppet valve body	Poppet valve body loose	Tighten valve body into the gun handle	
	Retainer too tight or holding valve open	Adjust retainer	
Air leaking from fitting on handle or to chopper	Poppet assembly worn or damaged	Inspect and replace poppet assembly as needed	
	Poppet valve body seat area worn or damaged	Inspect and replace parts as needed	
Material leaking from around nozzle or nozzle	Nozzle cap loose	Tighten nozzle cap Note Do not overtighten or you may damage the turbulent mixer	
сар	Turbulent mixer loose	Hand tighten turbulent mixer; hand tight only	




General Problems					
Symptom	Possible Cause	Remedy			
	Turbulent mixer worn or damaged	Replace turbulent mixer as needed			
	Front of mix housing damaged	Replace parts as needed			
	Trigger damaged	Inspect and replace parts as needed			
	Trigger stud and screw damaged or	Remove and lubricate trigger stud and			
	dry	screw; replace as needed			
Trigger action stiff or	No adla suida and anvince damaged	Remove and lubricate needle guides and			
hard	Needle guide and springs damaged	springs; replace as needed			
naru	Spring retainer worn or damaged	Replace parts as needed			
		Check needles and needle housings for			
	Needles or needle housings dirty	hardened or sticky material and remove as			
		needed			

Parts Drawings

The following parts breakdown drawings are included for reference:

Parts Drawings				
Part Number	Description			
CPR-2000	CIPHER GUN			
CPR-2000-INT	CIPHER GUN – INTERNATIONAL			
CPR-2000-SIG	INTERNAL MIX GUN			
CPR-2000-W	CIPHER GUN – WETOUT			
CPR-2000-W-INT	CIPHER GUN – WETOUT – INTERNATIONAL			
CPR-2000-W-SIG	INTERNAL MIX WETOUT GUN			
CPR-2000-W-SIG-INT	INTERNAL MIX WETOUT GUN – INTERNATIONAL			
CPR-2000-SK	CIPHER GUN SEAL KIT			
5104-03-01	SYSTEM ONE INJECTOR ASSY - GB1S1			






Page | 23

CPR-2000 CIPHER GUN 02-11-05 PARTS KEY

ITEM	PART #	DESCRIPTION	TY	SEAL KI	r sold sep	ARATELY:
l 2 3 4	7701-6-18 54350-3 00145 54630-1	ELBOW GUN HANDLE SCREW STUD	1 1 1	K		SEAL KIT CLUDES 5104-13-1 INJECTOR RT 19. 5104-03-01
5 5	MAX-2040 04039-1	TRIGGER SPRING	1 2	OPTIONAL	L EQUIPMEN	T:
7 B	54000-1 53900-1	RETAINER NEEDLE GUIDE	2	VP	G-1001	STATIC MIXER HOUSING
9 10 11*	53800-1 EPR-2005-01 0-5-006	JAN NUT PICES NOTZIP D-RING	2 2 2	VP	G-1002	DIFFUSER/GASKET (PLACE BETWEEN TIP AND HOUSING)
12 13*	10-4004 1-2-012	NEEDLE HOUSING (MAT.) O-RING	6	VP	G-1003	STATIC MIXER
14 15	EPR-2003-02 EPR-2001-01	NEEDLE HOUSING (CAT.)	1	51	04-07-D1	BALL VALVE FLUSH
17 18* 19 20 21 22*	F-CS-04C-12 5104-12-1 5104-03-01 5104-17-1 5104-20-1 5107-27-3	CAP SCREW SEAL INJECTIOR DISTRIBUTION RING MIX HOUSING TURBULENT MIXER	1 1 1 1 1	CP	R-2012-01	CATALYST HOUSING/SEAT ASSEMBLY - INCLUDES ITEM 13. O-S-OL2 (OTY 2), ITEM 14. EPR-2003-02 AND ITEM 41. CPR-2012-02
23 24 25	F-CS-1024-05 VFIT-6025 B704-4-1	CAP SCREW FIT NCZZLE NCZZLE CAP	2 I 1	04	040−ι	HEAVY SPRING TO REPLACE 04039-1
25 27* 28 29	53110-1 02441-1 04070-1 MG-2031	SEAL SPRING NEEDLE	1 1 1			
30 31*	54440-1 0-2-104A	VALVE BODY D-RING	1 1 1			
32 33	54420-1 02883-8	RETAINER PIN	I I			
34 35	56190-1 04420-1	SCREN SPRING	1			
36 37	F-HN-1024 56100-l	NUT NUT	1			
3B 39	MAX-2019 MAX-2022	CATALYST FITTING MATERIAL FITTING	1			
40 41	5104-01-01 CPR-2012-02	FLUZH VALVE	1			
42 43	F-MS-832-04 EPR-2060-01	IKICCE ZIDE MYCHINE ZOSEM	2 1			






Page | 25

CPR-2000-INT CIPHER GUN 08-14-06 PARTS KEY

ITEN	PART #	DESCRIPTION	qTY	SEAL KIT SOLD SEPARATELY:
l 2 3 4	7701-6-18 54350-3 00145 54630-1	ELBOW GUN HANDLE SCREW STUD	1 1 1	 CPR-2000-SK SEAL KIT KIT ALSO INCLUDES 5104-13-1 INJECTOR SEAL FOR PART 19. 5104-03-01
5 6	MAX-2040 04039-1	TRIGGER SPRING	1 2	OPTIONAL EQUIPMENT:
7 B	54000-1 53900-1	RETAINER NEEDLE GUIDE	2	VPG-LOD1 STATIC MIXER HOUSING
9	53 8 00-t	TUN NAL	2	VPG-LOD2 DIFFUSER/GASKET < PLACE
10 11*	CPR-2005-01 0-5-006	PISTON NEEDLE O-RING	2	BETWEEN TIP AND HOUSING)
12	CPR-2004-01 0-5-012	NEEDLE HOUZING (MA	T.)1	VPG-LOD3 STATIC MIXER
14 15	CPR-2003-02 CPR-2001-01	MEEDLE HOUSING (CA	T.)1 I	5104-07-D1 BALL VALVE FLUSH
17	F-CS-04C-12	CAP SCREW	1	CPR-2012-01 CATALYST HOUSING/SEAT
18* 19	5104-12-1 5104-03-01	INTECLOS ZEYF	1 1	MET 2 - INCLUDES TEM 13. 0-2-012 (DTY 2),
20 21	5104-17-1 5104-20-1	DNIS MOLTUBISTZIO DNIZUOH XIM	1 1	ITBN 14. CPR-2003-02
22* 23	5107-27-3 F-CS-1024-06	TURBULENT MIXER	1 2	AND ITEM 41. CPR-2012-02
24 25	VFIT-6025 8704-4-1	FIT NOZZLE NOZZLE CAP	I 1	04040-1 HEAVY SPRING TO REPLACE 04039-1
25	53110-1	PLUG	1	
27* 2B	02441-1 04070-1	SEAL SPRING	1 1	
29 30	MG-2031 54440-1	NEEDLE VALVE BODY	1	
3[∗	0-Z-L04A	O-RING	1	
32 33	54420-1 02883-8	RETAINER PIN	1 1	
34 35	56190-1 04420-1	SCREW SPRING	1 1	
36 37	F-HN-1024 56100-1	NUT NUT	1	
3B	MAX-2019	DATTIT TZYJATAJ	1	
39 40	MAX-2022 5104-01-01-INT		1	
41 42	EPR-2012-02 F-MS-832-04	MACHINE SCREW	1 2	
43	EPR-2060-01	TRIGGER STOP	1	






CPR-2000-SIG CIPHER GUN 04-07-05 PARTS KEY

ITEN	PART #	DESCRIPTION	QTY	SEAL KIT SOLD	SEPARATELY:
1	7701-5-18	ELBOV	L	* EPR-2000	
2	54350-3	GLIN HANDLE	ı		INCLUDES 5104-13-1 INJECTOR
3	00145	SCREV	L	SEAL FOR	PART 19. 5104-03-01
4	54630-1	QUT2	ı		
5	MAX-2040	TRIGGER	Ĺ	OPTIONAL EQUIP	MINT.
6	04039-1	SPRING	2	William Equi	2011
7	54000-1	RETAINER	2	VPG-1001	STATIC MIXER HOUSING
8	53900-1	NEEDLE GUIDE	2	110 1001	STATE MINER HOUSING
9	53800-1	JAM NUT	2	VPG-1002	DIFFUSER/GASKET (PLACE
10	CPR-2005-01	PISTON NEEDLE	2	110 1002	BETWEEN TIP AND HOUSING)
[]*	D-Z-006	D-RING	. 2		CETHEEN TEI AND HOUSENED
12	₽R-2004-01	NEEDLE HOUSING (MA		VPG-1003	STATIC MIXER
13*	0-2-015	D-RING	_ 6	VI G 1005	STATIC HINER
14	CPR-2003-02	NEEDLE HOUSING (CA	1.)[5104-07-0	DI BALL VALVE FLLISH
16	EPR-2001-01	GUN HEAD	ı,	5101 07 1	or the transfer to the transfe
17	F-CS-04C-12	CAP SCREW	L	CPR-2012-	OL CATALYST HOUSING/SEAT
18*	5104-12-1	SEAL	ı	CIK EUIE	METI ZEGULIZIF - YJEMEZZA
19	5104-03-01	INJECTOR	ı		(3. D-S-012 (BTY 2),
20	5104-17-1	DIZTRIBUTION RING	ı		ITEM 14. CPR-2003-02
21	5104-20-1	MIX HOUSING	ŗ		AND ITEN 41. CPR-2012-02
22*	5107-27-3	TURBULENT MIXER	Ī		AND THEN ALL ELK EUTE GE
23	F-CS-1024-06	CAP SCREW	2	04040-1	HEAVY SPRING TO REPLACE
24	VFIT-6025	FIT NOZZLE	ı.	01010 1	04039-1
25	6704-4-1	NDZZLE CAP	ı.		5-033 3
26	53110-1	PLUG	Ļ		
27*	02441-1	ZEAL	1		
28	04070-1	SPRING	1		
29	MG-2031	NEEDLE	Ļ		
30	54440-1	VALVE BODY	1		
31*	D-Z-104A	D-RING	i		
32	54420-1	RETAINER	Ļ		
33	02883-8	PIN	į.		
34	55190-1	2CKEA	i,		
35	04420-1	SPRING	i.		
35	F-HN-1024	NUT	Ļ		
37	56100-I	NUT	1		
38	MAX-2019	CATALYST FITTING	ļ.		
39	MAX-2022	MATERIAL FITTING	÷		
40	5104-01-01	FLUSH VALVE			
41	E-R-2012-02	CATALYST SEAT	2		
42	F-NS-832-04	MACHINE SCREW	2		
43 44	DPR-2060-01	TRIGGER STOP	XD		
45	PF-ST-02-BR	STREET TEE	l L		
43	7701-6-14	TUBE FITTING	L		






CPR-2000-W CIPHER WETOUT GUN 01-12-09 PARTS KEY

ITEM	PART #	DESCRIPTION	QTY	OPTIONAL EQUIPME	NT:
1	PF-AP-02	PLUG	t	VPG-1001	DNIZUDH SEXIM DITATZ
2	54350-3	GUN HANDLE	I		
3	00145	SCREW	1	VPG-1002	DIFFUSER/GASKET (PLACE
4	54630-1	DUTZ	ι		BETWEEN TIP AND HOUSING)
5	MAX-2040	TRIGGER	1		
6	04039-1	SPRING	2	VPG-1003	STATIC MIXER
7	54000-1	RETAINER	2		
8	53900-1	NEEDLE GLIDE	2	5104-07-01	BALL VALVE FLUSH
9	53800-1	TIN MAL	2		
10	CPR-2005-01	PISTON NEEDLE	2	□PR-2012-01	CATALYST HOUSING/SEAT
11*	D-Z-006	O-RING	2		YZZEWBLA - INCITIOEZ IJEW
12	CPR-2004-01	NEEDLE HOUSING (MAT.	. > 1		13. D-S-012 (DTY, 2),
13*	D-S-012	D-RING	6		ITEM 14. CPR-2003-02
[4	CPR-2003-02	NEEDLE HOUSING (CAT) [AND ITEM 41, CPR-2012-02
16	CPR-2001-01	BUN HEAD	1		
17	F-CS-04C-12	RETAINING NUT	ι	D4040-1	HEAVY SPRING TO REPLACE
18*	5104-12-1	SEAL	1		04039-1
19	5104-03-01	INJECTOR	ı		
20	5104-17-1	DISTRIBUTION RING	I		
21	5104-20-1	MIX HOUZING	1		
22*	5107-27-3	TURBULENT MIXER	ι		
23	F-CS-1024-06	CAP SCREW	2		
24	VFIT-6025	FIT NOZZLE	ı		
25	B704-4-1	NOZZLE CAP	I.		
26	53110-1	PLUG	1		
27*	0244[-1	ZEAL	1		
33	02883-8	PIN	1		
34	56190-1	SCREW	i.		
35	04420-1	SPRING	ı		
36	F-HN-1024	NUT			
37	56100-1	NUT	Ļ		
36	MAX-2019	CATALYST FITTING	i.		
39	MAX-2022	MATERIAL FITTING	į.		
40 41	5104-01-01 CPR-2012-02	FLUZH VALVE CATALYST SEAT	i		
42	F-MS-832-04	MACHINE SCREW	2		
42	EPR-2060-01	MOUNT MACHINE 2CKEM	1		
43	LFK-2000-01	FLUNT	· ·		

SEAL KIT SOLD SEPARATELY:

* CPR-2000-SK SEAL KIT
KIT ALSO INCLUDES 5104-13-1 INJECTOR
SEAL FOR PART 19, 5104-03-01





Page | 31


CPR-2000-W-INT CIPHER WETOUT GUN 04-11-07 PARTS KEY

ITEN	PART #	DESCRIPTION	QTY	OPTIONAL EQUIPME	NT:
t	PF-AP-02	РШG	1	VPG-10D1	DNIZUOH REXIM DITATZ
2	54350-3	GUN HANDLE	1		
3	00145	SCREM	1	VPG-1002	DIFFUSER/GASKET (PLACE
4	54630-1	DUT2	1		(DNIZUOH ONA 9IT NEEWTEB
5	MAX-2040	TRIGGER	1		
6	04039-1	SPRING	2	VPG-1003	STATIC MIXER
7	54D00-1	RETAINER	2		
8	53900-1	NEEDLE GLIDE	2	5104-07-D1	BALL VALVE FLUSH
9	53B00-1	TUN MAL	2		
10	CPR-2005-D1	PISTON NEEDLE	2	CPR-2012-02	CATALYST HOUSING/SEAT
1[*	D-Z-006	O−R ING	2		ASSEMBLY - INCLLIDES ITEM
12	CPR-2004-D1	NEEDLE HOUSING ()	MAT. > 1		13. 0-S-012 (DTY, 2),
13+	0-Z-015	O-RING	6		ITEM 14. CPR-2003-02
14	CPR-2003-02	NEEDLE HOUSING (1	CAT.)1		AND ITEM 41. CPR-2012-D2
16	CPR-2001-D1	GLIN HEAD	1		
17	F-CS-04C-12	RETAINING NUT	1	04040-1	HEAVY SPRING TO REPLACE
18*	51D4-l2-1	SEAL	1		04039-l
19	5104-03-01	INJECTOR	1		
20	51D4-l7-1	DIZIBIBUTION RING	7.0		
21	51D4-20-1	MIX HOUSING	1		
22*	5107-27-3	TURBLLENT MIXER	1		
23	F-CS-1024-06	CAP SCREW	2		
24	VFIT-6025	FIT NOZZLE	1		
25	87D4-4-1	NOZZLE CAP	1		
26	53110-1	РШG	1		
27*	D2441-1	SEAL	1		
33	02883-8	PIN	1		
34	56190-1	SOREW	1		
35	D4420-1	SPRING	1		
36	F-HN-1024	NLT	1		
37	56100-1	NLT	1		
39	MAX-2019	CATALYST FITTING			
39	MAX-2022	MATERIAL FITTING			
40	51D4-01-01-INT		1		
41	CPR-2012-02	CATALYST SEAT	1		
42	F-MS-B32-D4	MACHINE SCREW	2		
43	CPR-2060-D1	MOLINT	1		

SEAL KIT SOLD SEPARATELY:

* CPR-2000-SK SEAL KIT KIT ALSO INCLUDES 5104-13-1 INJECTOR SEAL FOR PART 19, 5104-D3-01





Page | 33


CPR-2000-W-SIG CIPHER WETOUT GUN 04-07-05 PARTS KEY

ITEN	PART #	DESCRIPTION	qty	OPTIONAL EQUIPME	NT:
l 2	MPH-2534 54350-3	PLUG GUN HANDLE	1	VPG-1001	STATIC HIXER HOUSING
3	DD145	SCREW	Ī	VPG-1002	DIFFUSER/GASKET (PLACE
4	54530-t	DUTZ	1		BETWEEN TIP AND HOUSING)
5	MAX-2040	TRIGGER	1		
Б	04039-L	SPRING	2	VPG-1003	STATIC MIXER
7	54000-t	RETAINER	2		
В	53900-t	NEEDLE GUIDE	2	5104-07-01	BALL VALVE FLUSH
9	53800-t	JAN NLT	2		
10	EPR-2005-01	PISTON NEEDLE	2	CPR-2012-02	
11*	B00−2−0	O-RING	2		METI ZEDULINI - YLEMEZZA
12	EPR-2004-01	NEEDTE HONZING (WYL			(3. U-S-012 (UTY. 2),
13*	D-Z-012	O-RING	6		ITEM 14. CPR-2003-02
14	CPR-2003-02	MEEDLE HOUZING (CAT			AND ITEM 41. CPR-2012-02
15	EPR-2001-01	GUN HEAD	1		
17	F-C5-04C-12	RETAINING NUT	1	04040-1	HEAVY SPRING TO REPLACE
1B+	5104-12-1	SEAL	1		D4039-1
19	5104-03-01	INJECTOR	1		
20	5104-17-1	DISTRIBLITION RING	1		
21	5104-20-1	MIX HOUSING	1		
22*	5107-27-3	TURBULENT MIXER	1		
23	F-CS-1024-06	CAP SCREW	2		
24	VFIT-6025	FIT NOZZLE	1		
25	8704-4-1	NOZZLE CAP	1		
26 27∗	53110-1	PLUG	1		
2B	02441-1	SEAL	1		
29	04070-1 54501-1	SPRING NEEDLE	1		
30	54440-1	VALVE BOOY	1		
31*	0-S-104A	O-RING	ī		
32	54420-L	RETAINER	1		
33	02883-8	PIN	ī		
34	56190-t	SCREV	1		
35	D4420-1	SPRING	î		
36	F-HN-1024	NUT	î		
37	56100-t	NUT	î		
3B	MAX-2019	CATALYZT FITTING	î		
39	MAX-2022	MATERIAL FITTING	1		
40	5104-01-01	FLUSH VALVE	1		
41	EPR-2012-02	CATALYST SEAT	1		
42	F-MS-832-04	MACHINE SCREW	2		
43	CPR-2060-01	HOUNT	1		

SEAL KIT SOLD SEPARATELY:

EPR-2000-SK SEAL KIT
 KIT ALSO INCLUDES 5104-13-1 INJECTOR
 SEAL FOR PART 19, 5104-03-01





Page | 35

CPR-2000-W-SIG-INT CIPHER WETOUT GUN 04-11-07 PARTS KEY


2 54 3 00 4 54 5 N/ 6 04 7 54 8 53	4350-3 0145 4630-1 4X-2040 4039-1	PLUG GUN HANDLE SCREW STUD TRIGGER SPRING	1 1 1	VPG-1001 VPG-1002	STATIC MIXER HOUSING
3 00 4 54 5 84 6 04 7 54 8 53	0145 463D-1 4X-2040 4039-1	SCREW STUD TRIGEER	1	VPG-1002	Warranton and the same of the
4 54 5 NA 6 04 7 54 8 53	463D-1 4X-2040 4D39-1	STUD TRIGGER	1	VPG-1002	
5 NA 6 04 7 54 8 53	4X-2040 4D39-1	TRIGGER	7.		OIFFUSER/GASKET (PLACE
6 04 7 54 8 53	4D39-1				BETWEEN TIP AND HOUSING)
7 54 8 53		SPRING	1		
8 53	4D0D-1		2	VPG-1003	SAXIM DITATS
		RETAINER	2		
	3 9 00-1	NEEDLE GUIDE	2	5104-07-01	BALL VALVE FLUSH
9 53	3B0D-1	JAN NAL	2		
LO CF	PR-2005-01	PISTON NEEDLE	2	CPR-2012-02	CATALYST HOUSING/SEAT
[]* []-	-2-006	D-RING	2		ASSEMBLY - INCLUDES ITEM
12 CF	PR-2004-01	NEEDLE HOUSING (MAT.) 1		13. D-S-012 (DTY. 2),
13+ 0-	-S-D12	D-RING	Б		ITEM 14. CPR-2003-D2
14 CF	PR-2003-02	NEEDLE HOUSING (CAT.) 1		AND ITEM 41. CPR-2D12-02
LB CF	PR-2001-01	GUN HEAD	1		
[7 F-	-CS-04C-12	RETAINING NUT	1	D4040-L	HEAVY SPRING TO REPLACE
18* 51	lD4-12-l	SEAL	1		04039-1
19 51	LD4-03-01	INJECTOR	1		
		DIZLKIBNLION KIND	1		
21 51	lD4-20-l	MIX HOUSING	1		
22+ 51	107-27-3	TURBLENT MIXER	1		
23 F-	-CS-1024-06	CAP SCREW	2		
24 VF	FIT-6025	FIT NOZZLE	1		
25 87	7D4-4-1	NDZZLE CAP	1		
26 53	311D-1	PLUG	1		
27* 02	2441-l	SEAL	1		
28 04	4D7D-1	SPRING	1		
29 54	4501-l	NEEDLE	1		
30 54	444D-1	VALVE BODY	1		
	-S-104A	D-RING	1		
	442D-1	RETAINER	1		
33 02	2883-8	PIN	1		
34 56	519D-L	SCREW	1		
35 04	442D-1	SPRING	1		
36 F-	-HN-1024	NLIT	1		
37 56	510D-L	NLIT	1		
		CATALYST FITTING	1		
10.77		MATERIAL FITTING	1		
	LD4-01-01-INT	FLUSH VALVE	1		
		CATALYST SEAT	1		
		MACHINE SCREW	2		
43 CF	PR-2060-01	MOUNT	1		

SEAL KIT SOLD SEPARATELY:

CPR-2000-SK SEAL KIT
 KIT ALSO INCLUDES 5104-13-1 INJECTOR
 SEAL FOR PART 19, 5104-03-01



					Ciph	er Gun Ope	erations Manual
1 PC	1 PC	1 PCS	1 PC	6 PC	1 PC	2 PC	CPR-
			0	0	0	0	CPR-2000-SK SEAL KIT
5107-27-3 TURBULENT MIXER	5104-12-1 MIX HOUSING SEAL	02441-	5104-1	0-5-012	0-S-104A 0-RING	0-S-006	
7-3 TUI	2-1 MIX	1 GUN F	3-1 INJE	2 O-RING)4A 0-	06 O-RING	
RBULENT	HOUSING	HEAD PL	5104-13-1 INJECTOR SEAL	SING	RING	RING	
MIXER	G SEAL	02441-1 GUN HEAD PLUG SEAL	ξΈΑL				
		100					
1 PC	1 PC	1 PCS	1 PC	6 PC	1 PC	2 PC	SEAL
					0	0	CPR-2000-SK SEAL KIT
量		0	0				-SK
5107-2	5104-1	02441-	5104-1	0-S-0	0-S-1	0-S-0	
27–3 דו	2-1 MI	-1 GUN	13-1 IN	0-S-012 0-RING	0-S-104A 0-RING	0-S-006 O-RING	
JRBULEN	K HOUSI	HEAD P	5104-13-1 INJECTOR SEAL	RING	-RING	RING	
5107-27-3 TURBULENT MIXER	5104-12-1 MIX HOUSING SEAL	02441-1 GUN HEAD PLUG SEAL	SEAL				
N 4 N 7 E		F					ı aye j or



MAGNUM VENUS PRODUCTS

6-BLADE WEDGE ROTOR ASSY - RC1S1	5103-04-01
	ALGEBRA STATE SERVICE AND ACCUSED TO



6-Blade Wedge Rotor Assy - RC1S1 5103-04-01 PARTS LIST

ITEM	PART NO.	QTY	DESCRIPTION
1	5103-30-1	1	ROTOR HUB - 6-BLADE
2	5103-31-1	3	WEDGE INSERT - 6-BLADE
3	7102-13-6	3	SOCKET FLAT HEAD SCREW
4	7102-11-6	2	SOCKET CUT POINT SET SCREW
5	5103-8-1	6	CHOPPER BLADE
6	D5103-04-1	1	6-BLADE WEDGE ROTOR ASSY - RC1S1 DWG

ASSOCIATED PARTS AND ASSEMBLIES

ITEM	PART NO.	QTY	DESCRIPTION
5A	9210-1-100	1	BLADES (PACKAGE OF 100)
5B	5103-8-1000	1	BLADES (PACKAGEOF 1000)

FIGURE 1-1



